

恒正

The diagram shows the AirGrip device, which consists of a long, thin, curved tube. At one end is a control panel with several buttons and a microphone. The other end is a long, thin, curved tube that ends in a small, round, flexible tip. The control panel has the following components labeled with numbers 1 through 7:

- 1. Volume/Previous song
- 2. Indicator light
- 3. Microphone
- 4. Volume/Next song
- 5. Power button
- 6. Type-C charging port
- 7. Volume/Next song

Charging

GENEVE-T1 is built in with rechargeable battery. We highly recommend you to charge the battery to full when using for the first time.

- 1) Charge the headset at a computer or in a wall outlet by using included charging cable
 - Red light on: Charging
 - Blue light on: Finish charging
- 2) It will take about 1.5-2 hours to fully charged

Functions	Operation
Turn on flashlight	Press and hold the power button for about 3 seconds
Turn off flashlight	Press and hold the power button for about 3 seconds
Enter pairing mode	Press and hold the light and power buttons together
Bluetooth pairing is successful	The indicator light is on
Increase live volume	Click the Volume + button
Decrease the volume	Click the Volume - button
Previous song	Double click the Volume - button
Next song	Double click the Volume + button
Mute play/pause	Click the power button once
Answer the call	Click the power button once
Hang up the call	Click the power button once
Reject the call	Click and hold the power button
When charging fully charged	The indicator light is on

Bluetooth version: Bluetooth V2.0	
Chipset: Broadcom BCM2079	
Frequency: 2.4 GHz, BLE, A2DP v1.1, HSP, HFP v1.2, AVRCP v1.3, and SPP	
Control mode: 3 physical buttons	
Power consumption: Standby frequency: 240KHz band, 2402-2480MHz	
Receiving sensitivity: -90dBm	
Transmitting power: Class 1	
Headphone amplifier type: bit built-in	
Audiodata signal-to-noise ratio: 5/N	
Audio response: 30Hz~20kHz ±1dB	
Microphone sensitivity: -42dBmV, max. 320	
Microphone impedance: 47±2Ω	
Battery: Li-ion battery, 1100mAh	
Standby time: about 30 days	
Usage time: about 10 hours (normal)	
Charging time: about 2 hours (80% volume)	
Charged up standard DC5V 500mA Type C	
Charge time: about 1.5~2h	
Charging cycle: full charge and discharge cycle 300	
Sizes: 89x30x26mm	
Weight: 15g	
Material: Silicon+ABS+Metal	

[illegible]

Diagram of a laryngeal mask airway (LMA) with numbered labels:

- 1. Latistylker Vorheizer / Song
- 2. Kontrilleuchte
- 3. Mikrolon
- 4. Typ-C-Lubsmoless
- 5. Ein/Aus-Taste
- 6. Latistylke-/Nichtster

Aufladen

Aufladen

BENEW-TL ist mit wiederaufladbarem Akku ausgestattet. Wir empfehlen Ihnen dringend, den Akku bei der ersten Verwendung vollständig aufzuladen.

1) Laden Sie das Headset mit dem mitgelieferten Ladekabel an einem Computer oder an einer Steckdose auf.

- Rotes Licht an: Aufladen
- Blaues Licht an: Ladevorgang beenden

2) Es dauert ungefähr 1,5-2 Stunden, bis es vollständig aufgeladen ist.

[illegible][illegible][illegible]

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction