



Horus Visual & Laser GNSS Receiver User Manual

2025.11.24V1.0

CONTENTS

1	INTRODUCTION	1
1.1	Environmental Requirements	1
1.2	About Horus	1
1.3	Front Panel	2
1.4	Back View	3
1.5	Lower Housing	3
1.6	Power Supply	4
2	RTK WORKFLOW	5
2.1	About Software	5
2.1.1	Installation of SingularPad	5
2.1.2	Software Registration	5
2.2	Create a New Project	7
2.3	Device Connection	11
2.3.1	NFC Connection	11
2.3.2	Bluetooth Connection	11
2.4	About Device Registration	14
2.5	Concepts About RTK	15
2.5.1	Overview	15
2.5.2	High Real-Time Precise	15
2.5.3	Corrections over NTRIP	16
2.6	Quick Setup Your Receiver	16
2.6.1	Internal Radio Mode (SingularXYZ Base + Horus Rover)	17
2.6.2	PDA CORS Mode (Single Horus Rover)	27
2.6.3	PPP Mode	32
2.6.4	SBAS Mode	35
3	RTK SURVEY – FIELD DATA COLLECT	37
3.1	SingularPad Top Status Bar Introduction	37

3.2	Point Survey	38
3.3	Calibrate Point	45
3.4	Localization	48
3.5	*Laser Survey*	54
3.6	*Photographic Survey——Visual Survey*	60
3.7	Tilt Survey	65
3.8	Detail Survey	68
3.9	Control Point Survey	69
3.10	Point Stakeout	70
3.11	*Visual AR Stakeout*	74
3.12	Line Stakeout	79
3.13	CAD Mapping and Stakeout	81
3.14	DSM Stakeout	85
3.15	Point Database	86
3.16	Data Import/Export	87
	3.16.1 Import Points Data	87
	3.16.2 Export Points Data	90
4	STATIC SURVEY	93
4.1	Static Data Collection	93
4.2	Static Data Download	97
4.3	RINEX Convert	98
5	WEB UI INTRODUCTION	101
5.1	Access the Web Interface	101
5.2	Work Management	101
5.3	Firmware Upgrade	103
6	TROUBLESHOOTING	105
6.1	How to Find Serial Number	105
6.2	How to Get Debug Data & Project File	106
	6.2.1 Save Debug File	106
	6.2.2 Share Project File	107

1 INTRODUCTION

The SingularXYZ Horus Visual & Laser GNSS Receiver User Manual is aimed to help you get familiar with the GNSS receiver and start your project effectively. We highly recommend you to read this manual before start your surveying, even you have used other GNSS RTK receivers before.

1.1 Environmental Requirements

- **Operating Temperature:** -30 °C to +65 °C
- **Storage Temperature:** -55 °C to +85 °C
- **Humidity:** 100% Non-condensing
- **Waterproof & Dustproof:** IP67, fully protected against dust and water, suitable for harsh environments.
- **Drop Resistance:** Designed to withstand a 2-meter drop onto concrete.

1.2 About Horus

The Horus GNSS receiver integrates photogrammetry, laser measurement, and AR stakeout functions. It combines powerful performance, seamless connectivity, and user-friendly design, making it the ideal tool for achieving accurate, reliable results in a wide range of surveying and mapping applications.

Key Features:

- **Full-Constellation Support:**

Horus supports Full-Constellation satellite tracking with 1408 channels, enabling simultaneous tracking of GPS, BDS, GLONASS, Galileo, QZSS, IRNSS, and SBAS. This ensures centimeter-level positioning accuracy across a variety of environments.

- **Next-Gen IMU:**

Equipped with a next-generation Inertial Measurement Unit (IMU), Horus enhances reliability in various surveying tasks, including pole surveying, AR stakeout, laser surveying, and visual surveying, offering greater stability and precision.

- **Enhanced UHF Communication:**

With enhanced UHF capabilities, Horus can reach up to 15 km in optimal conditions, minimizing the need for external radios and ensuring stable communication over long distances.

- **Versatile Connectivity:**

Horus supports a wide range of connectivity options, including Bluetooth, Wi-Fi, NFC, and USB, allowing for flexible interaction with the devices to suit different needs and workflows.

- **12-Hour Battery Life:**

Powered by a 6600mAh built-in battery, Horus offers an impressive 12+ hours of continuous working time, while the fast 3.5-hour charging time ensures minimal downtime for your field operations.

- **Web UI Access:**

Access Horus via Wi-Fi through an intuitive web interface to configure work modes, download data, perform firmware upgrades, and monitor device status remotely, making it easier than ever to manage your device on-site.

1.3 Front Panel

The Horus contains three indicator LEDs and one power button on the front panel.



1.4 Back View

The receiver has a laser receiver and laser emitter on its back, as well as a camera for photogrammetry.



1.5 Lower Housing

Receiver lower housing contains a Type-C port, SMA connector and a camera.



1.6 Power Supply

The Receiver is equipped with internal batteries.

- 6600 mAh, up to 12 hours working time
- Fast charge of 3.5 hours charging time

© **Important Notice:** *If the receiver is not used for an extended period, it is recommended to charge it every three months to prevent potential damage to the lithium battery cells.*

2 RTK WORKFLOW

This chapter introduces how to conduct RTK surveying with SingularPad Software. SingularPad is a professional Android-based surveying software developed by SingularXYZ team. SingularPad is fully functional as a field surveying software, equipped with complete work modes and necessary functions for surveyors.

2.1 About Software

2.1.1 Installation of SingularPad

SingularPad has been pre-installed on SingularXYZ data collector before shipping, if you want to download on your own device, please contact SingularXYZ team to obtain the installation package.


2.1.2 Software Registration

After the software is installed, you can check your software registration status (network connection required) by following steps:

Go to **Project >>> About Software** and check the **Expiration Date**.


-If it shows **2999-12-31**, this indicates a permanent registration of the software.

-If it shows **Inactivated**, please click **Software Activation**, then enter the permanent license to register and activate all software functions.



2.2 Create a New Project

Click **Project Manager**, click the **New** to create a new project file and input project name, set coordinates systems parameters and click **OK** to save the project.



SingularPad includes many countries' coordinate systems, you can find what you need by country name or coordinate system name. The following steps give an example of how to find predefined coordinate systems in SingularPad.

Click the button located after **Name** in Coordinate System Parameters interface.

Coordinate System Parameters

Coordinate System Type Local System >

Name Input 

Ellipsoid Parameter

CGCS2000
Semimajor Axis:6... 1/f:298.257222101 >

ITRF Conversion

None >

Projection Parameter

UTM
Central Meridian E123°00'00" >


Datum Parameter

None >


Horizontal Adjustment

Share Save As OK

In the Coordinate System Favorites interface, click the **Template** below to enter the Predefined Projections interface.



Click **Country** to select the country name or enter a keyword after **Search** to find desired coordinate system.



After finding the required coordinate system, click **Apply** to add it to coordinate

system parameters, click **OK** to apply it to the current project.

Predefined Projections

Country: **AUSTRALIA**

Search:

Data Content

AGD66-ACT/AMG zone 48 E102-108	Australian National... AUSTRALIA	Transverse_Mercator 105°00'00.0000"E
AGD66-ACT/AMG zone 49 E108-114	Australian National... AUSTRALIA	Transverse_Mercator 111°00'00.0000"E
AGD66-ACT/AMG zone 50 E114-120	Australian National... AUSTRALIA	Transverse_Mercator 117°00'00.0000"E
AGD66-ACT/AMG zone 51 E120-126	Australian National... AUSTRALIA	Transverse_Mercator 123°00'00.0000"E
AGD66-ACT/AMG zone 52 E126-132	Australian National... AUSTRALIA	Transverse_Mercator 129°00'00.0000"E

Basic Information

Coordinate System Type: Local System

Name: T/AMG zone 48 E102-108

Ellipsoid Parameter

Australian National Spheroid
Semimajor Axis: 6356583.747 m 1/f: 298.25

ITRF Conversion

None

Projection Parameter

UTM(Southern Hemisphere)
Central Meridian: E105°00'00"

Datum Parameter

Helmert

Buttons: Back, OK

If you don't find the required coordinate system in Predefined Projections, you can click **Add** or **Import** to create new coordinate system.

New Project

Basic Information

Coordinate System Type: Local System

Name: T/AMG zone 48 E102-108

Data Content

AGD66-ACT/AMG zone 48 E102-108
Australian National... AUSTRALIA
UTM(Southern Hem... 105°00'00.0000"E

Ellipsoid Parameter

Australian National Spheroid
Semimajor Axis: 6356583.747 m 1/f: 298.25

ITRF Conversion

None

Projection Parameter

UTM(Southern Hemisphere)
Central Meridian: E105°00'00"

Datum Parameter

Helmert

Buttons: Back, OK, Add, Import, Download, Template

2.3 Device Connection


2.3.1 NFC Connection

Equipped with an NFC chip, users can easily connect the Horus receiver to the data collector with just one touch, as shown in the figure below.



2.3.2 Bluetooth Connection

After creating a new project, switch to *Device* interface, click *Communication*.



Select the corresponding parameters according to the following requirements:


Device Type: GNSS

Device Manufacturer: SingularXYZ


Mode Type: RTK (P2/X1/Z1/E1/E1PRO/SV100/ORION ONE/L1/Horus/Xbase)

Connection Type: Bluetooth

Make sure Bluetooth is enabled on the controller. Click **Currently Paired Device** to find the serial number (SN) of your Horus receiver. Click **Connect**.



After connecting Horus receiver, you can check the information of the receiver (like firmware version) in *Device Information*.



Tips:

If you fail to connect with receiver through SingularPad, you can follow the prompts to enter the system Bluetooth settings interface of the PDA/data collector to ensure that the Bluetooth pairing is successful. Sometimes you need to cancel the device Bluetooth pairing, restart the receiver or SingularPad software and perform the pairing process again.

2.4 About Device Registration

The device can only function properly if it is in an activated state. Please check the device's expiration date in Device Activation.

-If the Expiration Date shows **21250101**, the device is permanently licensed and valid indefinitely.

-If the displayed date has **expired**, a registration code is required for registration, please contact SingularXYZ team to obtain a license code. Then enter the it to register, ensuring the device functions properly.

← Device Activation

Device Information

Device SN H1-6125T0001

Expiration Date 21250101

Enter License

1 2 3 A B

4 5 6 C D

7 8 9 E F

0 Backspace

Activate

2.5 Concepts About RTK

2.5.1 Overview

RTK(Real-Time Kinematic) is a positioning technique used to improve the accuracy of a standalone GNSS receiver. A conventional GNSS receiver, like the one in a smartphone, could only provides the position accuracy within 2–4 meters (7– 3 feet). RTK technology enhances this accuracy to the centimeter level. GNSS receivers measure how long it takes for a signal to travel from a satellite to the receiver. Transmitted signals travel through the ionosphere and atmosphere and are slowed down and perturbed on the way. For example, travel time on a cloudy day and in clear sky conditions would be different. That is why it is difficult for a standalone receiver to precisely determine its position. RTK is a technology that solves this issue.

2.5.2 High Real-Time Precise

Two receivers are used in RTK. One of them is stationary, the other moves freely. These receivers are referred to as the base station and rover. The base station is

installed at a fixed, known location and continuously transmits correction data to the rover. Rover uses that data to achieve centimeter precise position. Any number of rovers can connect to one base if their input settings match the base's output.

2.5.3 Corrections over NTRIP

You do not necessarily need a second unit for RTK all the time. Usually, there are local services that share base corrections over the Internet. The technology is called NTRIP (Networked Transport of RTCM via Internet Protocol). NTRIP is a good option for areas with strong 3G/LTE coverage and a vast network of NTRIP bases nearby. In other cases, using the second receiver as a local base station has two advantages:

- Autonomy in remote areas as there's no need in the Internet connection;
- Independency from local providers, no additional NTRIP subscription fees.

2.6 Quick Setup Your Receiver

With the help of this section, you can easily configure your Horus and achieve accurate positioning for your subsequent surveying tasks. This chapter introduces four work modes, allowing you to select the one that best suits your working conditions and accuracy requirements.

Work Mode	Use Conditions	Accuracy
Radio Mode	Two GPS RTK units (base and rover) required	Centimeter level
PDA CORS Mode	- Network required - RTK correction service subscription / CORS account needed	Centimeter level
SBAS Mode	No network or RTK correction service needed - SBAS coverage required	Submeter level
PPP Mode	No network or RTK correction service needed	10 - 20 cm
Static Mode	≥3 GNSS units required for stable triangulation network	Millimeter level

	adjustment	
--	------------	--

Note: The cost and coverage area of the CORS service depend on your local service provider.

2.6.1 Internal Radio Mode (SingularXYZ Base + Horus Rover)

If you've purchased one unit of SingularXYZ RTK Base (like X1-Series, Z1, etc.) and one Horus GNSS receiver as rover, you can conduct internal radio work mode. During configuration, you need to connect your PDA device or data collector to the base and rover respectively. When work as a Base station, SingularPad supports transmit the correction data in Internal Radio mode.

Internal Radio: This mode uses internal radio to transmit the correction data from Base.

- Protocol:** Supports CSS, TRIMTALK, TRIMMK3, TT450S, TRANSEOT and SATEL.
- Frequency:** select a channel or customize a frequency, the range of frequency is 410-470 MHz.
- Baud rate:** 4800, 9600, 11000, 12000, 15000, 18000, 19200, 115200.
- Power:** High and low (low power will reduce the transmission range).

Tips:

Condition of the base station setup

Ideal Environment:

- Clear outdoor sky view, free from obstructions.
- Place GPS and radio antennas as high as possible to reduce signal interference and increase range.

Avoid:

- Obstacles: buildings, vehicles, towers, trees, etc.

- Interference: high-power radar, TV, cellular towers, power lines or electrical facilities.


The following steps give an example of how to configure internal radio base mode.

Note:

Set Internal Radio Work Mode:

Connect the whip antenna to both your base station and rover. The Horus is equipped with non-contact laser surveying and camera AR stakeout capabilities and is commonly used as a rover for surveys. The X1-Series and Z1 RTK are recommended as the base choices for Horus rovers due to their reliable GNSS, communications and durability features.

1. Go to **Device** >>> **Base**. Set **Base ID** and choose the **Diff Format** firstly.



←

General Parameters

Base ID

123

✕

Diff Format

RTCM32

>

OK

- Click **Base Startup Mode** to select the base startup way.

←

Base Mode Settings

General Parameters

Base ID: Diff Format:RTCM32 >

Base Startup Mode Single Point >

Static

Disable >

Datalink Settings

Datalink Device Internet >

Connecting Mode:NTRIP

IP: Server Port:8080 >

Password:*****

Base Access Point Input

Share

Save

Start Base

←

Base Mode Settings

General Parameters

Base ID: Diff Format:RTCM32 >

Base Startup Mode Single Point >

Static

Disable >

Datalink Settings

Datalink Device Internet >

Connecting Mode:NTRIP

IP: Server Port:8080 >

Password:*****

Base Access Point A0C624112135567

Share

Save

Start Base


Single Point: Start the base station at unknown coordinates.

Assigned Base Coordinates: Start the base station at known coordinates, and you need to enter the latitude, longitude and the height.

Use Current Coordinates: Automatically start the base station at the current coordinates.

***Note:** Please setup the base station at a known point. Select **Base Startup Mode** as **Assigned Base Coordinates** and input the known point coordinates. Make sure the current coordinates of the instrument is within 50 meters of the known point coordinates. Otherwise, you will need to conduct 3.3 Calibrate Point after or before surveying.*

Typically, select **Base Startup Mode** as **Assigned Base Coordinates** and start the base station at known coordinates.



←
Assigned Base Coordinates

Assigned Base Coordinates 📍

Name	Pt5297
Latitude	31°10'00.9290"N >
Longitude	121°17'22.9420"E >
Altitude	12.699

Antenna Parameters

Antenna Measuring Height	1.8 m
Antenna Measuring Type	Pole Height >
Antenna Height	1.844 m

OK

You can assign the coordinates from point database (input points/measured points) or click the survey icon to measure the current base location directly. Always use the same coordinates when starting base at the same location.

←
61%
Age0
AUTONOMO...
11/11
V:5.599

Name Pt5298 ✕ Code Input ⋮

Layer 0 > 📏 1.6+0.000m >

B	31°09'59.7807"N	N	3449326.243
L	121°17'21.2784"E	E	336954.164
H	33.968	Elev	33.968

Tilt Angle 178°35'51.1519"

Dist. to Ref None

←
61%
Age0
AUTONOMO...
11/11
V:5.599

Name Pt5298 ✕ Code Input ⋮

Layer 0 > 📏 1.6+0.000m >


B	31°09'59.7807"N	N	3449326.243
L	121°17'21.2784"E	E	336954.164
H	33.968	Elev	33.968

Tilt Angle 178°35'51.1519"

Dist. to Ref None



3. After setting the base coordinates, set the Antenna Parameters for accurate elevation. Click to select *Antenna Measuring Type*, there are three main types:




Pole Height: Pole height is the vertical height from the receiver bottom to the ground point. If you are using a range pole with bipod for base set up, you can fill the pole scale reading as the software *Antenna Measurement Height* when the pole is perpendicular.

Slant Height: If you are using a tripod to set up the device, you can measure the distance from ground point to antenna slant height measurement mark (marked in the figure below). Fill the reading into the Antenna Measurement Height, then the software will calculate the actual height.


Phase Center Height: The phase center height is the distance from the ground point to the antenna phase center, but the antenna phase center is a virtual point of the instrument's electromagnetic wave, and cannot be measured directly.

4. Set *Data Link* as *Internal Radio*.

Set parameter settings, Channel, Frequency, Protocol, Baud Rate and Power.




5. When start Base succeed, it will show as below in SingularPad.




Note: After base settings, please disconnect the base device and then search for the SN of rover to connect and configure the rover device. Select the same protocol and frequency with the Base.

The following steps give an example of how to configure internal radio rover mode.


1. Go to **Device** >>> **Rover**. Set **Data Link** as **Internal Radio**.



2. **Parameter Settings.** Set Channel, Frequency and Protocol the same as the Base.



3. **Base Coordinates Change Alert:** SingularPad will alert when the base station coordinates change while you are working. This may be because the rover is mistakenly connected to another base station or the base station has been moved.



4. Click **Apply** to start the Rover mode.

After completing the configuration, please check the RTK status in the top status bar. Once the status changes to “FIXED” and the differential delay “Age” is within the range of 1-2 seconds, you have obtained reliable centimeter-level RTK positioning. Now you can proceed to **3.2 Point Survey** to start surveying.




2.6.2 PDA CORS Mode (Single Horus Rover)

When works as a rover, SingularPad supports receive the correction data in *Phone Internet Mode*.

Phone Internet: This mode uses the phone internet to transmit the correction data from Base to Rover. Please make sure the PDA device is in good network conditions, such as 4G (SC200/SC300 data collector can obtain a 4G network signal by inserting a SIM card), Wi-Fi or hot spot.

Go to *Device* >>> *Rover*. Set *Data Link* as *Phone Internet*.



Set **Connect Mode**, for Horus receiver supports NTRIP and TCP Client. Input the server IP, Port, User and Password in the **CORS Settings**.



Note:

The IP & port in the picture is only for example, please enter your local CORS account instead. You can purchase a third party RTK corrections service account in your local area to obtain an RTK FIX solution.

Click **Get** button on the right to get the **Mountpoint** list and choose the **Mountpoint**.

← Rover Mode Settings

Datalink Settings

Datalink Phone Internet >

Connecting Mode: NTRIP

IP: 47.103.96.216 Server Port: 8080 >

User: 123 Password: *****

Mountpoint Settings

Get

Mountpoint Office >

RX Data Status

Start

Auto Connect to Network


Share Save Apply

Note:

The mount point "Office" in the figure is an example. Please find out the appropriate mount point via the website of your local NTRIP/CORS provider. Make sure that the baseline doesn't exceed 50km.

If you are unable to obtain a mountpoint, it may be due to a problem with your account. Please check if the IP address and port are entered correctly, or confirm with your local NTRIP/CORS provider whether the account is available.


Click **Start** button on the right to receive data from CORS/RTK correction service. Then you can see the rover is receiving data.




Note:

If you have clicked Start but there is no response in RX Data Status, please check the parameter information above.


Auto connect to network: When this option is opened, SingularPad will connect to network automatically so that user don't need to click start to connect network.



Base Coordinates Change Alert: SingularPad will alert when you connect with different base station. When you are using VRS, please don't turn this on.





Click **Apply** to start the rover mode. After completing the configuration, please check the RTK status in the top status bar. Once the status changes to **"FIXED"** and the differential delay **"Age"** is within the range of 1-2 seconds, you have obtained reliable centimeter-level RTK positioning.




2.6.3 PPP Mode

Enter **Device >>> Rover**, select **Datalink** as **PPP**, and you can choose **Data Type** as HAS, B2B, BHS, then click **Apply**.



After configuration, the PPP mode will take around 10 minutes converging to typical accuracy. You can see the positioning state in the top status bar will change and remain in **Converging** for around 10 minutes.




After the positioning state changes to **PPP** mode, you can then conduct surveying tasks.




2.6.4 SBAS Mode

Click the *satellite icon* in the top status bar to enter the *Position Information* interface, then click *Settings* on the top right corner. *Enable* SBAS and click *OK*.

After configuration, you can see the positioning state in the top status bar will change to **DGNSS**, you can then conduct surveying tasks.





3 RTK SURVEY – FIELD DATA COLLECT

This section describes the basic survey functions of SingularPad, including Point Survey, Calibrate Point, Localization, Tilt Survey, Point Stakeout and etc. Before RTK survey, you need to connect to the receiver and get a fixed solution.

3.1 SingularPad Top Status Bar Introduction

After completing your Horus RTK setup, check current RTK solution status at the top pf the SingularPad software.



RTK Solution Status	Description
	Horus is receiving RTK corrections stably and obtaining a Fixed RTK solution with centimeter-level accuracy.
	Single-point satellite positioning without receiving RTK correction data. The accuracy is around meter-level.
	Horus receives corrections from the Base/CORS, but due to obstructions or magnetic field interference the signal reception is not very stable and the accuracy is sub-meter level.

Note:


*If you are using radio mode communication and the location status displays "**AUTONOMOUS**," this is likely because the radio parameter settings of the Base station and the Rover are inconsistent. Please go back and check the parameter settings to ensure that the channel, protocol, and baud rate used by the Base station and the Rover are the same.*



The satellite icon shows calculated satellites number/tracked satellites number. You can click it to check satellite map and more information.



Age means the time since the last differential data was received. When connecting to a CORS account for measurement work, please ensure the “Age” is within the range of 1-2. When using the radio mode for measurement work, please ensure the “Age” is within the range of 2-5. A high “Age” will result in poor measurement point accuracy.



There are HRMS and VRMS on the top of the interface, click it you can check more details.

Note:

If you connect the device but the software shows 0 satellites being detected, this is most likely because the device is not activated. Please refer to section [2.4 About Device Registration for details](#).


3.2 Point Survey

In the Survey interface, click [Point Survey](#) and enter point name, code and antenna height, then click  to measure a point.




Note:

Our software supports 3 antenna measuring types. please refer to [chapter 2.6.1 Internal Radio Mode](#) for details.




Pole Height: Typically, select the Antenna Measuring Type as Pole Height and enter the height of your centering pole.

In the floating window of the survey interface, you can see the display information. The default display information is NEH and Base distance, and click the floating window you can set them as you need. You can also click  to enter the display information settings interface and select the information you need to display. Except default display information, SingularPad supports Longitude, Latitude, Altitude, etc.



- Click  to select different map types or do map calibration. SingularPad supports Google Map (Standard Map/Satellite Map), OpenStreetMap and WMS Map.



- Click  to jump to map center.



- Click  to show the all points on the interface.
- Click  to enter the point database and view the coordinates of the measured points. You can add, recover, import and export data. After selecting a point, you can view the details and take notes or take photos.

Points Database	
NEh	BLH
Name	Input
Pt3 Smooth Point	T:2024-11-26 10:05:20.280
N:3449293.743	Elev:13.591
E:336991.812	Code:
Pt2 Smooth Point	T:2024-11-26 10:05:15.118
N:3449293.819	Elev:13.561
E:336991.986	Code:
Pt1 Smooth Point	T:2024-11-26 10:05:08.884
N:3449293.783	Elev:13.495
E:336991.881	Code:

AddRecoverImportExport

- Click  to enter Settings interface

In **Settings** interface, you can modify **Tolerance Setting** such as solution limit, HRMS limit, VRMS limit and etc. and modify **Smooth** parameters and configure **Settings** options.

← Settings

Settings

Display Info

Tool Bar

Tolerance Setting

Solution	FIXED >
HRMS	0.05m >
VRMS	0.1m >
PDOP	3 >
AGE	5s >
Tilt Angle	Unlimited >

Average

Survey Delay	0s >
Average Points	5 >
Horizontal	0.02m >
Vertical	0.03m >

More Settings

Pop Up the Survey Confirmation Page ☐

Remind When Point Name Repeat ☐

Point Name Increment 1 >

Default Code Same as Last Point >

Default

OK

← Settings

Settings

Display Info

Tool Bar

Average

Survey Delay	0s >
Average Points	5 >
Horizontal	0.02m >
Vertical	0.03m >

More Settings

Pop Up the Survey Confirmation Page ☐

Remind When Point Name Repeat ☐

Point Name Increment 1 >

Default Code Same as Last Point >

Default

OK

In *Display Info* interface, you can set the display information to the floating window, such as longitude, latitude, altitude, etc.

← Settings

Settings

Display Info

Tool Bar

Options


Long	Lat
Altitude	Ant. H
Forward Azimuth	Speed
Time	Base distance(2D)
Laser Dist.	Point Dist
Pt H Dist	Pt Elevation Offset
NRMS	ERMS
PDOP	HDOP
VDOP	Tilt Angle
Projection Angle	Pitch

Backspace

Default

OK



In **Tool Bar** interface, you can add or delete options that displayed on the point survey interface. You can customize the interface layout to suit your usage habits.



3.3 Calibrate Point

When changing the position of the base station, there will be offsets between surveying points base on different base stations. Users can use the Calibrate Point to calibrate the offset.

Go to **Project >>> Calibrate Point**. Add a point measured under the previous base station as **Known Point Coordinates**, and measure the same point under current base station as **GNSS Point Coordinates**.



For the GNSS Point Coordinates, you can click the surveying icon to measure under the current base directly.

Note: Please confirm the RTK status is FIXED.

← Calibrate Point

GNSS Point Coordinates

📍

☰

Name

Latitude

Longitude

Altitude

Known Point Coordinates

📍

☰

✎

Name

Northing

Easting

Elevation

Previous Base

3449293.743m

336991.812m

13.591m

Result

Calibration parameters applied to all projects

🔍

Clear

OK

←

94%

Age1

FIXED

27/40

H:0.019

V:0.027

Name

ous Base

✕

Code

Input

☰

Antenna Height

1.8+0.000m

>

B	31°09'58.7471"N	N	3449293.832
L	121°17'22.7064"E	E	336991.483
H	13.11	Elev	13.11

Dist. to Ref

409.781m

Save to Point Database

⚙️

☰

🔑

📍

Or measure the GNSS point under the current base station in advance and click to select from the point database.

← Calibrate Point

GNSS Point Coordinates

📍

☰

Name

Latitude

Longitude

Altitude

Known Point Coordinates

📍

☰

✎

Name

Northing

Easting

Elevation

Previous Base

3449293.743m

336991.812m

13.591m

Result

Calibration parameters applied to all projects

🔍

Clear

OK

← Coordinate Select

NEh

BLH

☰

Point Coordinates

Survey Point

Name

>

Input

📶

📍	Previous Base	S...	T:2024-11-26 10:05:20.280
N:	3449293.743	Elev:	13.591
E:	336991.812	Code:	
📍	Current Base	Sm...	T:2024-11-26 10:05:15.118
N:	3449293.819	Elev:	13.561
E:	336991.986	Code:	


Add

Recover

Import

Export

Then click **OK** to complete the Calibrate Point.



GNSS Point Coordinates	
Name	Current Base
Base ID	22
Latitude	31°09'58.7469"N >
Longitude	121°17'22.7254"E
Altitude	13.561m

Known Point Coordinates	
Name	Previous Base
Northing	3449293.743m >
Easting	336991.812m
Elevation	13.591m

Result	
Adjust Time	2024-11-26 10:16:14
North Offset	-0.078m
East Offset	-0.201m
Height Offset	0.030m

Calibration parameters applied to all ☐

Clear OK

3.4 Localization

When starting a new project, if you are using the local small-scale coordinate system, you can use this function to transform the geodetic coordinates system to your local system.

Go to **Project >>> Localization**, add at least 3 pairs of points for the Localization.

Note:

A pair of points are the known local coordinates and the surveying coordinates of the same point.



Click **Add** to add the corresponding pairs. Input the **Known Point Coordinates**.

Known Point Coordinates	
Name	K1
Northing	3450141.4360 m
Easting	622951.6845 m
Elevation	14.3341

GNSS Point Coordinates	
Latitude	
Longitude	
Altitude	

Options	
Use Horizontal Control	☐
Use Vertical Control	☐

Buttons: Add, Import, Export, Calculate, OK

Then select the corresponding GNSS coordinates of the known point.

← Localization

Name

K1

Known Point Coordinates

Northing

3450141.4360 m

Easting

622951.6845 m

Elevation

14.3341

GNSS Point Coordinates

Latitude

Longitude

Altitude

Options

Use Horizontal Control

Use Vertical Control

OK

← Coordinate Select

Point Coordinates

Survey Point

Name

> Input

A3 Input Point

T:2024-10-03 19:25:14.000

N:3450110.466

E:622947.648

Elev:14.324

Code:

A2 Input Point

T:2024-10-03 19:23:44.000

N:3450138.466

E:622946.392

Elev:14.349

Code:

A1 Input Point

T:2024-10-03 19:23:10.000

N:3450141.458

E:62251.591

Elev:14.318

Code:

Add

Recover

Import

Export

← Localization

Name

K1

Known Point Coordinates

Northing

3450141.4360 m

Easting

622951.6845 m

Elevation

14.3341

GNSS Point Coordinates

Latitude

31°05'28.2453"N

Longitude

4°35'08.2266"W

Altitude

14.318m

Options

Use Horizontal Control

Use Vertical Control

OK



Add the remaining point pairs in sequence. You can also enter the known point in point database in advance and select the input points.




After adding all the point pairs, click *Calculate*.



Select the convert method and the accuracy limit according to your project requirements.





You can click Export Report to save the projected coordinate system parameters.
Click **Apply** to apply the localization.

←

Localization Calculating Result

Conversion Residual

K1

HRMS:0.029 VRMS:-0.000

K2

HRMS:0.032 VRMS:0.000

K3

HRMS:0.006 VRMS:-0.000

Ellipsoid Parameter

WGS-84

Semimajor Axis:637... 1/f:298.257223563

Projection Parameter

UTM

Central Meridian

E123°00'00"

Horizontal Adjustment

Horizontal Adjustment(TGO)

Translate Northing(m)

1380.049052

Translate Easting(m)

49.207755

Rotation

0°04'14.9976"

Scale


1.0000273161828885

Export Report

Apply


3.5 *Laser Survey*

Connect Horus receiver to SingularPad software via Bluetooth and ensure a fixed RTK solution is achieved.





Before performing laser surveying, you need to complete IMU initialization of Horus according to the software prompts. When the survey status icon shows **Ready**, the accuracy of the laser surveying meets the requirements.

Tips: Laser surveying is based on IMU, so shake it more times than usual to ensure that the IMU is initialized successfully.




Turn on the laser surveying function in the Point Survey interface. After you click the Aim icon, the controller will automatically connect to the device's Wi-Fi. Then the Horus laser can be clearly seen, and the rear camera will be activated. And you can zoom in and out on the screen to change the camera magnification, with a maximum zoom level of 5x.

Once the camera is enabled, you will then see a red crosshair will appear in the image window, and a standard deviation value will be displayed at the bottom of the window. To ensure the accuracy, laser survey should be performed when the standard deviation is less than 0.2. If the standard deviation exceeds 0.2, it is recommended to hold the vertical centering pole and walk a few steps, then stop and check if the standard deviation has decreased.





Tips: It is recommended to use a **bipod** for laser survey to reduce the shaking caused by human factors and lead to inaccurate precision.



Now click the measure button and you can perform laser survey normally. Measured points using the laser can be viewed in the Points Database (Please refer to [section 3.15 Point Database](#)). You can view the corresponding photo of that point in [Photo and Sketch](#), where annotations and markings can be added.

Points Database

xyh

BLH

Name

>

Input

Pt4 Laser Point*	T:2025-12-18 16:48:17.000
N:3450632.665	Elev:16.068
E:21336934.337	Code:
Pt3 Tilt Point	T:2025-12-11 17:09:35.600
N:3450594.999	Elev:9.138
E:21336784.829	Code:
Pt2 Tilt Point	T:2025-12-11 17:09:02.400
N:3450595.007	Elev:9.151
E:21336784.830	Code:
Pt1 Tilt Point	T:2025-12-11 17:03:42.200
N:3450603.527	Elev:9.283
E:21336798.480	Code:

Add

Recover

Import

Export

Point Details

Name

Pt4

X

Code

Input

Layer

0

>

B	31°09'57.4063"N	N	3450632.665m
L	121°17'23.0357"E	E	21336934.337m
H	16.068m	Elev	16.068m
Tilt Angle	13°51'41.4629"		
Projection Angle	172°41'52.03"		
Scale Factor	1.0003253376		
Laser Dist.	4.675m	Azimuth	259°26'18.30"
Horizontal Dist	4.976m	Elev. Offset	0.477m
Local Time	2025-12-18 16:48:17.000		

Photo And Sketch*

OK

Photo And Sketch--Pt4

Cancel


OK

Tips: The laser of Horus can reach a distance of about hundreds of meters, but it does not mean that effective measurement accuracy at those ranges. For optimal accuracy, laser surveying is recommended to use within approximately 10 meters.

3.6 *Photographic Survey——Visual Survey*

Horus supports photogrammetric measurement with a centimeter-level accuracy. When the positioning status shows as FIXED and the Age value is around 1-4 seconds, you can start measuring.

Go to **Survey** >>> **Photographic Survey** to enter the photogrammetry module.




The **pole height** needs to be set before shooting begins. When "**Ready**" is displayed on the screen, you can tap the shutter button below to take pictures.

During image acquisition, you need to slowly move the device. The device will automatically take pictures, or you can manually take pictures by clicking the button to the right of the shutter button at the bottom of the screen.

After images are captured, you can drag the cursor on the screen to the point on

the image you want to measure, and the coordinates of that point will be displayed at the bottom of the screen. You can click **Save** to save the point.


Once you have taken a sufficient number of pictures (at least five images are required), tap the shutter button again to stop taking pictures. The captured images will then be stored as a Task, and you can view the coordinates of points of interest within these pictures.






Additionally, other images marked with a “✓” indicate that the coordinates of that point are also present in that image.

When you need to select a point on another image, please click *Cancel* first to deselect the current point, then select a new point.



After the measurement is complete, you can also view the pictures you just took in *Survey* >>> *Images Database*.



Note:


-When using the Horus photogrammetry module, please note the following guidelines:

1. Ensure the area to be measured is present in every captured image.
2. Do not move the receiver too quickly during image acquisition.
3. At least five images should be taken per task, capturing more images makes coordinate calculation easier.
4. Avoid moving people or objects within the camera's field of view.
5. Areas without obvious feature points (including glass, water surfaces, or similar scenes) may not be measurable.
6. Photogrammetry cannot be performed under low-light conditions.

-If you encounter problems with the IMU or the camera function is unavailable during use, it's most likely because the IMU registration validity period has expired. In this case, you need to contact your sales representative to obtain a registration code. The registration steps are as follows:

Log in to the web page. (For details on the login process, please refer to section [4.2 Static Data Download](#).)

Go to [Device Configuration](#) >>> [IMU Register](#), enter the registration code, and then click [Register](#).



3.7 Tilt Survey

The Horus GNSS receiver has a built-in IMU module that supports tilt surveying up to 60°. The system will accurately calculate the actual offset based on the tilt angle, reducing the user's burden on centering pole at each measurement.

The tilt function option  will appear in each survey/stakeout function interface. You can click to turn this function on/off.

Tilt initialization is required when using it for the first time or when its calibration expires.

The following steps give an example of how to use tilt survey.

Open IMU: Go to [Survey](#) >>> [Point Survey](#) >> click the  button to open.


After clicking the tilt IMU button, the system will prompt you to check the antenna information, please check whether the antenna height is correct.



Initialization: After clicking the IMU button, you can follow the guidance on the interface to complete it.

During operation, ensure that the receiver can search for satellites and obtain a fixed RTK solution.

Note: If the receiver is powered off or reset, it will need to be reinitialized.



In survey interface, you can find the bubble and angle value showing how you tilt the pole in real time. To ensure the accuracy, please keep the tilt angle less than 60°. When the pole tilts within 60°, the built-in IMU precisely calculates the actual offset, the accuracy of which can be accurate to $\pm 2.5\text{cm}$.



Tips: Do not shake or rotate the receiver violently, otherwise you need to re-initialize.

3.8 Detail Survey

After completing your Horus RTK setup, check current RTK solution status at the top of the SingularPad software.

In detail survey interface, both local coordinates and Latitude/Longitude will be displayed when measuring.

- Click  to start or stop collecting data
- Click  to set settings, display info and tool bar.
- Click  to check point database; you can add note, info, arrow drawing and photo.
- Click  to open IMU to do tilt survey.


- Click  to open Fast Code Survey. You can input Remark and Code into it, then click the button that just created to start quick-collecting.

     			
Name	Pt2	Code	Input 
Antenna Height		1.8+0.068m >	
B	31°09'58.0908"N	N	3449274.006
L	121°17'21.7717"E	E	336966.42
H	15.981	Elev	15.981
Tilt Angle		4°25'01.2929"	
Projection Angle		252°52'56.5372"	
Dist. to Ref		66.731m	



3.9 Control Point Survey

By measuring the coordinates of the same point multiple times and taking the average, you can get more accurate coordinates. This function is usually used to measure control points.



- Click  to start or  stop collecting data.
- Click  to set settings, display info and tool bar.
- Click  to check point database; you can add note, info, arrow drawing and photo.

3.10 Point Stakeout

Go to **Stake point** interface, add or import the point coordinates you need to stake out, you can also click Button Library to select from the point database.

- Click **Add** to input coordinates

← Stake Point

← New Point

Point Coordinates

To-Stake-Point

Preview Map

Name

> Input

Name

Code

Northing

Input m

Easting

Input m

Elevation

Input m

Property Type

Stake Point >

Pt1

Add

Database

Import

Export

OK

- Click *Database* to choose one.

← Stake Point

← Coordinate Batch Select

Point Coordinates

To-Stake-Point

Preview Map

Name

> Input

Name

> Input

☐ Select All(0)

Pt1

Smooth Point T:2024-11-27 14:23:3...

N:3449274.017

Elev:15.967

E:336966.415

Code:

☐

Pt2

Control Point T:2024-11-27 14:30:3...

N:3449272.473

Elev:15.908

E:336967.132

Code:

☐

Pt3

Smooth Point T:2024-11-27 14:32:4...

N:3449274.110

Elev:15.963

E:336966.779

Code:

☐

Pt4

Smooth Point T:2024-11-27 14:32:4...

N:3449274.108

Elev:15.970

E:336966.771

Code:

☐

Pt5

Smooth Point T:2024-11-27 14:32:4...

N:3449274.111

Elev:15.977

E:336966.770

Code:

☐

Pt6

Smooth Point T:2024-11-27 14:32:4...

Add

Database

Import

Export

Add

Import

OK

- Click *Import* to import point data in different file types. You can also define a

71

Horus Visual & Laser GNSS Receiver User Manual

new format according to your needs.

The image shows two side-by-side screenshots of the SingularPad application interface.


The left screenshot is titled "Stake Point" and features three tabs: "Point Coordinates", "To-Stake-Point" (which is the active tab), and "Preview Map". Under the "To-Stake-Point" tab, there is a "Name" label followed by a right-pointing chevron and an "Input" button.

The right screenshot is titled "Import Data" and features a "Choose Import File Format" section with "Cass Format(dat)" selected. Below this, it lists the fields "Point Name, Code, Easting, Northing, Elevation" followed by a right-pointing chevron. There is also an "Import Parameters" section with "Distance Unit" set to "Meter" and a right-pointing chevron.

At the bottom of the interface, there is a navigation bar with five buttons: "Add", "Database", "Import" (which is highlighted with a red border), "Export", and "Next".

Select a point to stake out. SingularPad provides a navigation map while staking out points/lines. The software alerts you when you approach the target point to the set range value.

For Horus receivers, you can use the IMU stakeout feature. In IMU stakeout, you can turn on the IMU feature without keeping the receiver perpendicular to the ground. The maximum tilt angle is 60°.



There is a direction prompt on the floating window.

- Click  to start or stop stake points
- Click  to open or close IMU
- Click  to scale automatically to full map
- Click  to jump to current point
- Click  to jump to next point
- Click  to jump to previous point
- Click  to set stake out settings, display info and tool bar, you can edit the prompt range and range error

- Click  to open compass



3.11 *Visual AR Stakeout*

After completing your Horus RTK setup, check current RTK solution status at the top of the SingularPad software.

Get a fix solution: When using Visual AR Stakeout, you need to connect to Horus's Wi-Fi.


If you are using CORS (using Phone Internet to obtain the network), please insert a SIM card into the controller instead of connecting the controller to Wi-Fi or Hot Spots.

If you are using radio communication (no network required), no additional network configuration is needed.


The AR stakeout function uses the Wi-Fi connection to transmit visual data.

Go to *Survey >>> Stakeout Point*, you can import points (refer to the previous section), or select existing points, and then click *Stakeout*.

After importing or entering stakeout points, enter the staking interface.




Then click the *AR staking icon*, the controller will automatically connect to the Horus device's Wi-Fi. Then the Horus's rear camera will be activated.




Follow the software prompts to ensure the receiver is facing backward. The rear camera will then be activated, and the software will display the specific location of the stakeout point overlaid on the camera view, providing AR guidance.



When you are within 3m of the stakeout point, the camera view will automatically switch from the rear camera to the bottom camera for better AR guidance.





When you approach the point to be staked, the software will mark its location on the screen. At this time, align the tip of the pole with the position of the stakeout point. Then click the survey button to stake out.



Note:

The distance at which the rear camera switches to the bottom camera can be manually adjusted. Go to *Stakeout Point*, click *Settings* >>> *Stakeout Settings* >>> *AR Stakeout switch camera distance*. You can choose a preset distance or add one manually. Click *OK* to apply the setting.



3.12 Line Stakeout

Go into **Line Stake** interface, add or import lines you need to stake out.



- Click Add to input line parameters
- Click Import to import point data in different file types. You can also define a new format according to your needs.




Choose a line to stakeout, set Offset, Cross-Section Slop and Stakeout by Pile-to-Pile Coordinate parameters.


- Click  to jump to next line
- Click  to jump to previous line

3.13 CAD Mapping and Stakeout


When using this function for the first time, the CAD interface has no layers and floating window to display the features you need to stake.




- Click  to create or import a CAD file, supporting *.dxf, *.dwg format.



- Click  to draw features, there are 12 types and methods you can choose, follow the prompts and draw.



- Click  on the Find tools. They can help you to work smoothly.



In the CAD interface, you can choose a feature you want to stake, it will show up in blue. You can know the details about it, including length, start point, end point and center point. And choose the way to stakeout.

- **Setting:** Set the method of stake out, offset distance, interval etc.
- **Start station:** If you set the start station as 5m, then the final mileage will plus 5m.
- **Offset:** If you set the offset 5m, then you will stake the line 5m away from the line you choose. The plus and minus represent different sides of the line.
- **Setting out by pile by coordinate:** including station number, station distance and segment
- **Station distance:** Stake the line at a specified distance, for example, if the line is 40m, you set the specified distance as 8m, then you will stake the line at 8m distance every segment.
- **Segment:** For example, if you set the segment as 4, then you will stake the line

at 4 segments, every segment length is the same.

- Station number: You will stake the line at the station at each interval point. You can stake it out according to the direction.
- Key node: It will stake out the line with starting point, ending point, midpoint, fold point, etc.

3.14 DSM Stakeout

You can stakeout a surface by staking out elevation of each point on the surface.

If you haven't used a surface file before, you need to create one by adding, importing, or selecting from the database.

You can get a preview map of the surface after adding points and don't forget to save it.

At the content list interface, you can find the surfaces you created, and you can edit, share and stake them.




If the current position is not within the design surface, it will prompt “Out of surface!”. If the current position is within the design surface, it will show the fill

or excavation value.

3.15 Point Database

The points, which are surveyed, staked, added, imported, and input from display map, will be stored in point database. The surveyed points will be shown under one base while surveying. Also, no matter where you need to select a point, all the points of the database are available.



- Add: Support to add Input Point, and display type supports local coordinate and geodetic coordinate
- Recover: After deleting the points, you can recover them in deleted points interface
- Import: Import points by different formats of files
- Export: Export points by different formats of files
- Search: Enter the name of the point you want share or delete

Tap any point to view the detailed information. The information includes antenna height, solution status, WGS84 Coordinate, local grid coordinate, base id and measure time. If the point has been calibrated, the offset parameters will be displayed.

Point Details

Name

Pt7

X

Code

Input

Antenna Height

1.8+0.068m

>

Solution

FIXED (44/46)

B

31°09'58.0945"N

N

3449274.114m

L

121°17'21.7848"E

E

336966.769m

H

15.969m

Elev

15.969m

Scale Factor

0.9999253493

Speed

1

Heading

0.000

PDOP

0.900

HRMS

0.012m

HDOP

0.400

VRMS

0.029m

VDOP

0.800

AGE

1

Average Points

5

Cut-Off Angle

5

UTC Time

2024-11-27 06:32:50.600

Photo And Sketch

OK

3.16 Data Import/Export

SingularPad supports to export/ import data including grid coordinate, Lat/Lon coordinate with various data format, and supports importing *.dat/*.csv/*.kml file and exporting result of *.dxf/*.kml/*.shp/*.xls/*.csv.

3.16.1 Import Points Data

Tap Import data in project interface, there are some predefined data formats, click More to get more predefined formats.

Import Data

Data Type: Points Database >

Choose Import File Format

Local Coordinates Format(csv,d... >
Point Name,Northing,Easting,Elevation,Code

Import Parameters

Property Type: Input Point >

Distance Unit: Meter >

Format Select

File Format

Cass Format(dat)
Point Name,Code,Easting,Northing,Elevation

Local Coordinates Format(csv,dat,txt)
Point Name,Northing,Easting,Elevation,Code

Geodetic Coordinates Format(csv,dat,txt)
Point Name,Latitude,Longitude,Altitude,Code

More

Next New OK

- Data Type: support point database, transformation parameters file and code library
- Import File Format: support *.csv, *.dat, *.txt, *.kml, etc.
- Distance Unit: support meter, US survey feet and international feet

Besides, you can click now to create a User defined type.

← Custom Format

Format Name Input

Extension Name dat >

Field Delimiter Comma(,) >

Custom Format Description


Options

(Null)	Point Name
Code	Northing
Easting	Elevation
Latitude	Longitude
Altitude	

Backspace OK

- Format name: Enter the name for the format
- Extension name: support *.csv, *.dat, *.txt, *xlsx format
- Delimiter: support comma (,), semicolon (;), space (), tab (Tab)

Click to choose elements in the options list, click backspace to eliminate the previous element selected. The elements include: code, northing, easting, elevation, latitude, longitude, altitude. Choose one format to import data. The default export path is internal Storage/ SingularPad/Import. You can also change to any other path where the file is. Click preview to take an inspection whether the format is right.



3.16.2 Export Points Data

Tap Export in Project interface to export point data. Also, click More formats to export the survey points in various formats like stake points/ lines, DXF, SHP, KML, RAW, RW5, HTML, CASS feature result.

- Export Path: the default export path is internal storage/SingularPad/export; you can also change to any other path where the file is
- File Name: support project name, operator, data, data time
- Export File Format: support *.csv, *.dat, *.txt, *.kml, etc.
- Distance Unit: support meter, US survey feet and international feet
- Road section data: open to export road section data

Besides, you can click New to create a user defined type. The elements include: id, name, code, latitude, longitude, altitude, northing, easting, elevation, N, E, Z, type, local time, UTC time, solution status, AGE, max delay, min delay, use satellites, tracked satellites, cut-off angle, mount point, measurement method, repeat, start data, end time, RMS, HRMS, VRMS, PDOP, VDOP, speed, heading, antenna type, measuring type, measuring height, antenna height, base id, base

latitude, base longitude, base altitude, distance to ref, original latitude, original longitude, original altitude, undulation height, station correction h, inclination correction, pitch, roll, yaw, inclined angle, projected angle, stakeout type, target, station, offset, north diff, east diff, elevation diff.

For the points, lines and polygons you surveyed in point survey, you can export dxf file, then you can edit them in third party CAD software, or import to base map to check, or import to CAD to stake. Choose the data that you want to export including survey point, input point, control point, stake point, line and polygon, and the layer properties include name, code and height.

←

Custom Format

Format Name

Input

Extension Name

dat >

Field Delimiter

Comma(,) >

File Header

☐

Custom Format Description

Options

Point ID	Point Name
Code	Code Remark
Line Name	Northing
Easting	Elevation
Local Time	Point Attributes

Backspace

OK

4 STATIC SURVEY

This chapter describes how to conduct static survey through Horus receiver and SingularXYZ Converter software. For static survey, Horus supports 3 data formats: binary XYZ, Rinex 3.02 and Rinex 3.04. SingularXYZ binary format (*.XYZ) is a raw observation data format and you can convert it to RINEX format via SingularXYZ Converter Software. (Contact SingularXYZ support team for the tool).

If you need post-processing software, please contact the support email at <support@singularxyz.com> for assistance


4.1 Static Data Collection

Static survey is mainly used for the control point survey. To reach millimeter accuracy, follow as below:


- At least 3 GNSS receivers are required to form a stable triangulation network.
- It is better to collect static data on the known point.
- Power off the receiver before moving to other observation site.
- For the convenience of post-process static observation raw data, record the station name, receiver SN, antenna height, start and end time for each observation site.

The following steps give an example of static survey:

1. Go to *Device* >>> *Static and collect points*. Choose the Record mode, there are two record modes and they can record static data at the same time.



2. Options Settings interface: Input Record name and Point name. Set the Collection Interval, Observation Time and Data Format.



3. Turn on/off the **Circular Record** according to your needs. If this option is turned on, the receiver will delete the earliest recorded data to keep recording when the record space is full.



4. Turn on/off the **Auto Record Static** according to your needs. If this option is turned on, the receiver automatically records static data after it is power on.



5. Set the *Record Space* in the end (unit: MB). It will limit the amount of data that receiver record.



6. Click **Start** to start static survey.

← 93% FIXED 40/41 H:0.012 V:0.023

Mode Record1 >

Option Settings

Name SingularXYZ

Point Name singularxyz

Interval 1S >

Observation Time 1 hour >

Data Format XYZ >

Circular Record ☐

Auto Record Static Data ☐

Storage Space 3000

Antenna Parameters

Start

4.2 Static Data Download


The raw observation data is saved in internal memory of Horus receiver, when connected with PC via TYPE-C cable, the Horus receiver can work as a USB Flash Disk, which means you can copy the static data to PC directly.

📁 > USB flash drive (E) > 1-REC1 > 2023293			
Name	Modified Date	Type	Size
📄 1823E00052930339.XYZ	10/20/2023 3:43 AM	XYZ	690 KB
📄 1823E00052930344.XYZ	10/20/2023 3:45 AM	XYZ	166 KB
📄 1823E00052930345.XYZ	10/20/2023 3:45 AM	XYZ	147 KB
📄 1823E00052930547.XYZ	10/20/2023 5:59 AM	XYZ	2,460 KB
📄 1823E00052930600.XYZ	10/20/2023 6:28 AM	XYZ	5,183 KB

In addition, you can download the static data via Web UI, connect your PC or phone to the Wi-Fi of the Horus receiver (WLAN name: the SN of Horus) and log

in the web page in browser via IP 192.168.10.12 (Username: admin, Passwords: admin).

Go to **Work Management** >>> **File Download**, select the corresponding record name, file type and date to filter and download the static data.




4.3 RINEX Convert

The raw observation data is saved in internal memory of Horus receiver, when connected with PC via TYPE-C cable, the Horus receiver can work as a USB Flash Disk, which means you can copy the static data to PC directly.


After copy raw observation data to PC, you can convert the data from SingularXYZ binary format (*.XYZ) to Rinex in SingularXYZ Converter software.

The following steps give an example of Rinex convert:



1. Start **SingularXYZ Converter** software.
2. Set the output path and select to import the binary file.



3. After import the binary file, click set then input the marker name and choose the measure type of antenna height, and the antenna type is automatically identified as SITE 1 for Horus receiver



4. Click **Convert** to start convert XYZ to Rinex, and the Rinex files will be output to the output file path.




Note: The output path of the conversion software and the storage path of the files to be converted can only contain English letters and numbers.

5 WEB UI INTRODUCTION

This chapter mainly introduces the function of Web UI.


5.1 Access the Web Interface

Connect PC or mobile devices to Horus's Wi-Fi (Name: SN of Horus, Password: 12345678). Open browser and enter the web page via IP 192.168.10.12 (Username: admin, Password: admin).




5.2 Work Management


In Data Transmission, you can manually set the transmission method of data.




In Data Recording, you can set the parameters of the collected static data and start record. You can also format memory in this interface.



In File Download, you can download record static data.



In Device Control, you can choose to reboot or freset your device.




5.3 Firmware Upgrade

This function interface is used to upgrade the firmware version of the device.

1. **Select** the firmware file in this interface and click **Update** to update the firmware.
2. After the upload complete, the device will automatically restart and the upgrade is finished.

Note: If the page displays an update failure or gets stuck, you can try clearing the browser cache

or performing the firmware upgrade in another browser.



6 TROUBLESHOOTING

If you encounter any issues not addressed in this manual, please contact our support team for assistance. In this chapter, we will outline the basic information you need to provide to help our support team understand and resolve your issue quickly.

Please send the following information to our support team for further assistance.

- Serial number of your Horus device
- Problem description with supplementary video/screenshots
- Debug logs and project file

6.1 How to Find Serial Number

The serial number is a unique combination of numbers and letters assigned to your Horus receiver.

Find serial number

Find the serial number of your Horus as shown in the image below.




6.2 How to Get Debug Data & Project File

6.2.1 Save Debug File

The Debug data provides information about your current Horus Series internal state, helping support team facilitate troubleshooting.

After connecting the device, you can access the Debug section.


Enter **Device** >>> **Communication** >>> **Debug**, then enable Save option to save debug file, which will be stored in the System folder (/SingularPad/Debug).



6.2.2 Share Project File

The project file and its parameters will also help us identify the issue. You can share your project with us by following these steps:

Enter **Project >>> Project Manager**, select your project and click Share.



FCC Warning

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 50cm between the radiator and your body.