

6K
ULTRA HD

Digital Camera Easy Guide



Contents

WARNING	1
CAUTION	1
About the camera	2
System requirement	2
Parts and controls.....	2
Charging the battery.....	5
Touch function.....	6
Power on/off the camera	7
Set the camera	7
Insert and format the memory card	9
Format the memory card	9
Using the camera	10
Focus function.....	12
Auto focus.....	12
Manual focus.....	12
Fixed focus	12
Fill light.....	12
Playback	13
Connect to computer	14
USB Drive Mode	14
USB Camera.....	14
Charging Mode.....	14
WIFI APP Usage Guide	15
Camera cleaning and maintenance.....	15
Troubleshooting	15
Additional notes	16

WARNING

To reduce the risk of fire or electric shock,

1. Do not expose the unit to rain or moisture.
2. Do not place objects filled with liquids, such as vases, on the apparatus.
3. Do not expose the batteries to excessive heat such as sunshine, fire or the like.
4. Do not ingest battery, chemical burn hazard.
5. Keep new and used batteries away from children. If the battery compartment does not close securely, stop using the product and keep it away from children.
6. If you think batteries might have been swallowed or placed inside any part of body, seek immediate medical attention.

CAUTION

If the battery is mishandled, the battery pack can burst, cause a fire or even chemical burns. Observe the following cautions.

Do not disassemble.

Do not crush and do not expose the battery pack to any shock or force such as hammering, dropping or stepping on it.

Do not short circuit and do not allow metal objects to come into contact with the battery terminals.

Do not expose to high temperature above 60°C (140°F) such as in direct sunlight or in a car parked in the sun.

Do not incinerate or dispose of in fire.

Do not handle damaged or leaking lithium ion batteries.

Keep the battery pack out of the reach of small children.

Keep the battery pack dry.

Replace the battery with the specified type only. Otherwise, burst, fire or injury may result.

Dispose of used batteries according to the instruction.

Use a nearby wall outlet (wall socket) when using the AC Adapter/Battery charger.

If any malfunction occurs, disconnect the plug from the wall outlet immediately to disconnect from the power source. If you use the product with a charge lamp, note that the product is not disconnected from the power source even when the lamp turns off.

Do not use the AC adapter/Battery charger placed in a narrow space, such as between a wall and furniture.

If static electricity or electromagnetism cause data transfer to discontinue midway (fail), restart the application or disconnect and connect the communication cable (USB, etc.) again.

About the camera


System requirement

Users can transfer videos and photos to computers with the following configurations:

Intel Pentium 2.0GHz or higher/ Microsoft Windows XP or higher operating system 2GB RAM 40GB above available disk memory/ Standard USB interface / 1GB GPU or higher 1920x1080 pixel or higher resolution.


Parts and controls

Rear view




- 1: Charging/working indicator light
- 2: Digital zoom in
- 3: Digital zoom out
- 4: Up Button/shortcut button for fill light
- 5: Right Button
- 6: OK Button

Front view




- 7: Menu Button
- 8: Down Button/Delete Button
- 9: Playback Button
- 10: Left Button
- 11: Display Screen
- 12: Fill light
- 13: Lens

Top side view




- 1: Video Button
- 2: Power Button
- 3: Photo Button
- 4: Mode Dial

Bottom side view



- 5: Cold Shoe Mount
- 6: Loudspeaker
- 7: Battery Compartment
- 8: Tripod Interface
- 9: Memory Card Slot

Left side view



- 1: Microphone Interface
- 2: Type-C USB Interface

Buttons/ Indicators	Functions
POWER	Long press to turn on/off the camera
	Short press to pause video recording
PHOTO	Take photo/Half-press to focus
VIDEO	Start recording/end recording
Mode dial	Switch shooting mode
T	Zoom in
W	Zoom out
Indicator light	Red charging indicator light/blue working indicator light
Up	Upward
	Turn on/off the fill light
	Long press to turn on WiFi
Right	Rightward
Down	Downward
	Delete photo/video
	Short press to turn the display on or off
Left	Leftward
OK	Confirm
Playback	Open/Exit Media Playback
MENU	Open / Close menu settings
USB	USB cable charging
	Connect the computer with USB cable

Charging the battery

1. Power off your camera, open the battery cover and insert the battery in the direction as the shown of following picture, then close the battery cover.



2. You can use supplied USB cable to charge your camera via a adapter (5V/1A~5V/2A) .



- * The charging indicator will be turned on in red when the battery is in charging.
- * The charging indicator will be turned off automatically when the battery is fully charged.

Normally it takes around 2 hours to full charging of the battery.

When the battery is fully charged, the battery life is around 60 minutes for recording.

Touch function


The display screen can touch the operation icon, and the corresponding functions are as follows.

Icon	illustrate
	Switching White Balance (Auto/Sunny/Cloudy/Incandescent/Fluorescent)
	Switch Filter (Normal/Black and White/Negative/Nostalgia/Brown/Warm/Cool/Bright/Red/Green/Blue/Purple/Cyan/Yellow/Low Saturation/High Saturation/Dark Tones/Japanese color)
	Switch Metering Mode(Average Metering/Center Metering/Spot Metering)
	Switching ISO(Auto/100/200/400/800/1600/3200)
	Enter menu settings
	Enter Media Library
	Enter system menu setting
	Return/Exit
	Open video file
	Open photo file
	View the previous photo/video/page
	View next photo/video/page
	Delete photos/videos
	Start/pause playing video

Touch the blank area of the display screen to hide all icons, and touch again to display all icons. All “sub menus” in menu settings can be operated by touch.

Power on/off the camera

Press the power button, the camera will turn on automatically.



To turn off the camera, press and hold the power button for 3 seconds.


Note: When you turn on the camera for the first time, you need to press and hold the power button to turn it on.

When there is no battery in the battery compartment, you need to press and hold the power button to turn on the camera after inserting the battery.


Set the camera

You can make custom settings of the camera.

After the camera is turned on, press the menu button to open the menu settings.



Menu Settings



1 :Sub-menu for current mode

2 :System settings

Sub-menu	Menu content
Backlight	Low/Middle/High
Frequency	50Hz/60Hz
LED indicator light	50Hz/60Hz
Automatic screen saver	Close/30S/1Min/2Min
Automatic shutdown	Close/3Min/5Min/10Min
Prompt tone setting	High/Middle/Low/Close
Turn on music	Open/Close(Press OK button to switch)
Icon Display	Open/Close(Press OK button to switch)
WIFI	Open/Close
Language	Simplified Chinese/traditional Chinese/English/ Japanese/Korean/ Russian/German/French/Italian/ Spanish/Portuguese/Thai
Time format	Year/Month/Day Month/Day/Year Day/Month/Year
Time setting	Hour Minute Second
Date setting	Year Month Day
Format card	Cancel/Confirm(Micro SD Card)
Device information	Product model and version number
Factory reset	Cancel/Confirm

Insert and format the memory card

A class 10 or higher speed memory card is recommended to normal use.

1.Insert the memory card into the memory card slot until you hear a "click".





Insert the memory card in the direction shown in the diagram, paying attention to the edges and corners.

2. Remove the memory card: Push the memory card inward and it will pop out automatically.

Format the memory card

It is recommended to format the memory card before the first use.

To format the memory card, press the Menu button to open the menu system. Then press the Left or Right button to switch to the System Settings. Press Up or Down to find "Format" and press OK to get the submenu. Select "Confirm" to format the memory card.



Note: If the file system in the memory card is not supported, the screen will pop up a prompt: "Unsupported file system, do you want to format?" Please follow the above steps to format the memory card.

Formatting a memory card will erase all data stored on it, and the data will be irrecoverable. Save important data on a PC before formatting.

Using the camera

After turning on the camera, rotate the mode dial to select the desired mode.



icon	Mode	illustrate
	Photo	Take a single photo normally
	Auto	Automatically cycle take photos after a specified number of seconds
	Timed	Take a single photo after a specified number of seconds
	Burst	Take a specified number of photos in succession
	Video	Normal recording mode
	Slowly	Slow motion shooting
	lapse	Compress time to record video
	Loop	Recording infinite loop
	Video+Photo	During the recording video, you can capture according to the set capture interval single photo

Note: The camera supports setting the corresponding mode menu in different modes. After selecting the desired mode, press the menu button to open the menu and select the desired setting if desired.

Press the photo button to take a photo, and the photo will be automatically saved to the memory card.

Press the Record button to start shooting video, then press the Record button to end shooting video, you can press Power to pause or continue video shooting while shooting video.



1: Photo button (Taking pictures/focusing)

2: Video button (Start recording/End recording)

3: Indicator light

The working indicator light flashes when recording

4: Digital zoom button

T button digital zoom zoom in/W button digital zoom zoom out

Focus function

This function includes 3 focus modes: Auto Focus/Manual Focus/Fixed Focus. Press the Menu button to open the current mode menu page, then press the Up/Down button to find the "Focus Mode" submenu, then press the OK button to enter the focus mode and select the mode you need.

Auto focus

In this mode, you only need to keep the camera steady when taking pictures or videos, and the camera will automatically focus. Once done, press the capture button.

Manual focus

In this mode, when taking a photo or recording a video, half-press the photo button and the focus frame will appear on the display until the camera focuses clearly. Then press the photo button all the way down to take the clearest photo or start recording with the clearest image.

Fixed focus

In this mode, point the camera at the subject. When a clear subject is displayed on the camera screen, hold the camera steady and press the picture button to finish taking pictures and videos.

Fill light

In video mode, pressing the up button can quickly turn on or off the fill light.

In photo mode, the fill light has three flash modes and pressing the up button can quickly switch between the three modes.


	No flash
	Auto flash
	Mandatory flash

Note: When the fill light is in automatic flash mode, it will only flash when taking photos in a relatively dark environment. When switched to forced flash mode, the fill light will always be on.

Playback

Press the Play button to enter the media library. Select the video or photo file you want to view, and then press the OK button to enter the corresponding file to view the videos and images stored in the camera's memory card.


Figure 1



1

2

Figure 2



3

4

5

Figure 1: Video file

Figure 2: Photo file

1: Click the icon to exit playback or click the playback button to exit

2: Video file recording time


3: Current/total number of pages

4: Current photo resolution

5: Current/total number of photos


If you want to delete the video or photo you have taken, you can press the menu button, and then the camera page will pop up with the following options. You can choose to delete the file or cancel according to your needs.

Note: Once the video or photo file is deleted, it cannot be restored.




Connect to computer

1. Connect the Type-C USB port of the camera and the USB port of the computer with supplied USB cable.



2. The camera will turn on automatically and the screen will display the available options.

Press the Up/Down button to select the desired option, then press the OK button to confirm the option.



USB Drive Mode

Select "U Drive Mode" and the computer will display the camera's memory card disk. You can transfer the stored files to the computer. You can also transfer the photos and videos taken by the camera to the computer for viewing or sharing with friends.

USB Camera

Select the "USB Camera" mode, and the camera can be used as a webcam to record videos or live broadcasts, etc.

Note: When the camera is used as a webcam, only the digital zoom button on the camera can be operated, and other functions cannot be used.

Charging Mode

Select "Charging Mode" and the camera will be fully charged. You can use the camera normally in this mode.

Note: If you charge after turning off the camera, the battery will be fully charged faster.

WIFI APP Usage Guide

Press the MENU button to enter the menu, press the left/right button to enter the system settings, then press the up/down button to find the "APP Usage Guide" submenu bar, and then press OK to enter the scan to view the tutorial. To download WiFi, you can scan the QR code on the right below.



WIFI APP User Guide QR Code



WIFI App download QR code

Camera cleaning and maintenance

- (1) If you do not use the camera for a long time, take out the camera battery and place it in a dust-free, dry environment with a temperature no higher than 30 °C .
- (2) In order to extend the service life of the battery, please discharge it completely before storage.
- (3) Please fully discharge the battery at least once every 3 months after it has been fully charged.
- (4) If there is dust or dirt on the lens or screen, gently wipe it with a clean, soft lens cleaning cloth.
- (5) As this machine is a precision instrument, please do not drop it or suffer from strong impact or vibration.

Troubleshooting:

If you encounter problems with the camera, please refer to this section.

1. The camera cannot be turned on after installing the battery

- (1) The battery power is insufficient, please replace the battery with a new one or charge the battery.
- (2) The battery is installed in reverse, please confirm that the battery is installed in the correct way.
- (3) The battery insulating paper is not removed.

2. The battery is not charging

- (1) If the red light of the charging indicator flashes, the battery is not in place or the contact is poor. Please re-install the battery until the indicator light is on (the indicator light goes out when the battery is fully charged)
- (2) The charging indicator light is off and the charger is not plugged in properly. Please check whether the charger is connected normally.
- (3) The ambient temperature is lower than 10°C, which may lead to slow charging or failure to charge.

3. Camera crashes

Quickly pressing each button of the camera may cause the camera to freeze. After it crashes, unplug the battery and reboot.

Tip: When the camera is recording or taking pictures, do not quickly press the camera button. Under normal circumstances, the camera will display a waiting icon.

4. The memory card cannot be recognized:

- (1) Please check whether the memory card complies with Micro SD card (class10), the maximum is not more than 256G.
- (2) Please check whether the memory card is inserted backwards.
- (3) When the memory card is used on the camera for the first time, it is recommended to format it first.

Additional notes

- (1) Do not insert any object into the slot except the memory card.
- (2) After the power is turned on, the camera may show an unstable image about for a few seconds, but this is not a fault.
- (3) Due to the optical properties of the lens, there may be color dispersion (magnification of chromatic aberration) at the edges of the image. This is not a camera fault.
- (4) It is normal for the memory card to get hot after a long period of use.
- (5) It is normal for the camera's screen to heat up after a long period of use.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction