



iPollo

V1 mini Classic Series

Server Setup Manual

V1 mini Classic Series have 4 models:

- (1) iPollo V1 mini Classic;
- (2) iPollo V1 mini Classic WiFi;
- (3) iPollo V1 mini Classic Plus;
- (4) iPollo V1 mini Classic Plus WiFi.

During use, only the network settings are different, and the versions are divided into WiFi version and wired connection version.

I. V1 mini Classic WiFi: Check Before Use

1. Sign For Inspection

- (1) When signing for the new server, please check whether the appearance of the package is damaged. If there is any damage, please take a picture and contact our after-sales service.
- (2) After opening the package, please check whether the server case is deformed, whether the fan and connecting cable are damaged, and whether the cable is damaged. If there is any damage, please take a picture and contact our after-sales service.
- (3) Please check whether there is any abnormal sound on the server. If there is any abnormal sound, please contact our after-sales service.



2. After-sales contact information

- (1) Official Website: www.ipollo.com
- (2) Official Wechat Account: iPollo
- (3) Facebook: @iPolloGlobal
- (4) Twitter: @iPolloGlobal
- (5) E-mail: support@ipollo.com

3. Notes

- (1) Recommended ambient temperature range: 10°C-25°C.
- (2) The hashrate is subject to the 24-hour hashrate of the Mining Pool.

- (3) Pay attention to dust and foreign matter, so as not to corrode the computing board or affect the heat dissipation of the server.
- (4) It is recommended to use Google browser or Firefox browser to browse the server background.
- (5) It is strictly forbidden to plug and unplug the power cable and signal cable under power. The AC side of the power supply of the server must be reliably grounded.

II. V1 mini Classic WiFi: Product Introduction

1. Main Components



- (1) “1”: WiFi signal receiver
- (2) “2”: power cable
- (3) “3”: V1 mini Classic WiFi
- (4) “4”: power adapter (the pictures are for reference only, please refer to actual products.)

2. Interface Introduction



Fault	The fault warning light. In most cases, when this light flash, it indicates that a fault has occurred
Normal	Running indicator light. In most cases, when this light is on, it indicates that the machine is working normally
Reset	Server factory reset button
IP Report	Use the show IP software to feed back the IP of this server to the computer
TF card	SD card slot
Power	Power interface
ANT	WIFI antenna

ETH

Network interface

3. Notes

- (1) In the process of running the server, please place it as shown in the picture below, that is, keep it flat to avoid any damage to the server.




- (2) The socket shall be installed near the server and shall be easily accessible.
- (3) The two 6PIN power ports must be connected at the same time before the supplying power.
- (4) This product requires a power input of 100~240VAC to make the product work normally. When the server is powered off, the power switch must be turned off first.
- (5) For your safety, it is forbidden to remove any screws on the server.
- (6) Do not press the metal buttons on the casing.

III.V1 mini Classic WiFi: Use and Configuration

1. Server Connection

(1) Power Connection


The V1 mini Classic WiFi dedicated power supply has two 6PIN DC outputs, and the input of the power supply is 100~240VAC. The server can work normally after confirming that the connection is good.



(2) Internet Connection

(2-1) Wired Connection

The interface marked “ETH” on the server interface panel is the network cable interface. Pay attention to the direction when inserting the cable. Please insert the crystal head in place. After inserting it in place, you will usually hear a light “click” sound.



(2-2) WiFi Connection

The red box in the picture is the WiFi antenna ,WiFi signal can be connected, For details, please visit “ipollo.com/support”.




2. Log in to the Server

2.1 Find the server IP

After the server is powered on and connected to the Internet, it starts to start. After the server's normal starts to light up, you can find the IP of the server. You can use the "show IP" software to find the server IP as follows:

- (1) Download software: <http://www.nano.cn/download/ShowIP.exe>
- (2) Double-click "show IP" to open the software.
- (3) Short press the "IP Report" button on the server for 1 second and release it.
- (4) The server IP information is fed back on the PC, as shown below:



Note: The server and PC must be in the same network segment, otherwise the IP information returned by the server cannot be received.

2.2 Enter the Server Backstage Management System

- (1) After finding the IP of the server, enter the obtained IP address in the browser (Google is recommended), press Enter to enter the server login interface, and enter the default administrator account and password: root




Username

Password

[Login](#)

- (2) press "Login" to enter the Server Backstage Management System as follows:



3. Server Settings

Click the "Miner Configuration" interface of "Configuration" to set the "Mining Pool" and "Network"



English ▼

Main
Running Overview
Information Overview
Configuration
Miner Configuration
Fan Configuration
Log
Running Log
Running Status
Error Log
System
Password Change
Firmware Upgrade
Diagnostics
System Reboot
Logout

iPollo C1
Firmware Version: v0.9.10 (s:6+ n:3)
IP:
MAC:
Uptime: 1d 18h 0m 42s
Restart

SN: DemoSN001
HBOSN: DemoHBSN001
HBISN: None
HBZSN: None

Pool Configuration

Pool	Url	Worker	Password
Pool 1	stratum+tcp://47.108.153.82:8008	ipollomini.001	123
Pool 2	stratum+tcp://etc.f2pool.com:8118	ipollomini.001	123
Pool 3	stratum+tcp://etc.f2pool.com:8118	ipollomini.001	123

Network Configuration

Protocol
DHCP
▼

Save & Apply
Save
Reset



3.1 Fill in the Mining Pool Information

Note: This manual takes the “antpool” as an example.

ETC mining address: stratum+tcp:// 47.108.153.82:8008

(1) Select "Pool Configuration" and fill in the Mining Pool Information

(1-1) The "Url" in "Mining Pool 1" is filled with the ETC AntPool mining link address: stratum+tcp:// 47.108.153.82:8008

(1-2) "Worker" in "Pool 1" fill in "ipollomini.001"; "ipollomini" is a custom "sub-account" in the corresponding Mining Pool account; the number suffixed with ".001" is the number used to distinguish the server;).

Note: For customization such as numbers or letter combinations, use English periods to separate them, only modify the corresponding characters, and do not increase or decrease spaces and punctuation)



English ▼

Main
Running Overview
Information Overview
Configuration
Miner Configuration
Fan Configuration
Log
Running Log
Running Status
Error Log
System
Password Change
Firmware Upgrade
Diagnostics
System Reboot
Logout

iPollo C1
Firmware Version: v0.9.10 (s:6+ n:3)
IP:
MAC:
Uptime: 1d 18h 13m 42s
Restart

SN: DemoSN001
HBOSN: DemoHBSN001
HBISN: None
HBZSN: None

Pool Configuration

Pool	Url	Worker	Password
Pool 1	stratum+tcp://47.108.153.82:8008	ipollomini.001	123
Pool 2	stratum+tcp://etc.f2pool.com:8118	ipollomini.001	123
Pool 3	stratum+tcp://etc.f2pool.com:8118	ipollomini.001	123

Network Configuration

Protocol
DHCP
▼

Save & Apply
Save
Reset




Note: In order to prevent “Pool 1” from being disconnected, causing the server to not work, it is recommended to set “Pool 2” and “Pool 3” at the same time, so as to ensure that the system will automatically switch to “Pool 2” or “Pool 3” for normal operation when “Pool 1” goes offline.

3.2 Network Settings

Regarding network connection, V1 mini Classic Series products are divided into two models: "wired connection" and "WiFi connection". You can set the server according to the corresponding model obtained by following the instructions below:

3.2.1 Wired connection


(1) Select “Network Configuration” and fill in the network information:



The screenshot shows the iPollo web interface. On the left is a sidebar with navigation links: Main, Configuration (highlighted), Log, and System. Under Configuration, 'Miner Configuration' is highlighted with a red box. The main content area shows the 'iPollo C1' configuration page. At the top, there's a status bar with fields for Firmware Version, SN, HBOSN, HBISN, and HB2SN, along with a 'Restart' button. Below this is the 'Pool Configuration' table with columns for Pool, Url, Worker, and Password. The table lists three pools. Below the pool configuration is the 'Network Configuration' section, where the 'Protocol' dropdown menu is highlighted with a red box and shows 'DHCP' selected. At the bottom right of the network configuration section are buttons for 'Save & Apply', 'Save', and 'Reset'. A QR code is visible in the bottom left corner of the interface.

(2) In the protocol column, select one of “DHCP (dynamic)” or “Static” (optional).

(2-1) Select “DHCP (Dynamic)” State: The server automatically obtains an IP address




This screenshot is similar to the previous one, showing the iPollo web interface. The 'Protocol' dropdown menu in the 'Network Configuration' section is highlighted with a red box and shows 'DHCP' selected. A red arrow points to the 'DHCP' option in the dropdown menu. The rest of the interface, including the sidebar, status bar, and pool configuration table, is identical to the previous screenshot. A QR code is visible in the bottom left corner.

After setting, click “SAVE&APPLY”, the system will save and automatically restart to take effect, and the server will start to run normally.

End here, the configuration of the server has been completed, congratulations on your becoming a miner.


(2-2) Select “Static” State



The screenshot shows the iPollo web interface. On the left is a sidebar with navigation links: Main, Configuration, Log, and System. The main content area is titled 'iPollo C1' and displays system information: Firmware Version: v0.9.10 (s6+ n3), IP: 192.168.103.38, MAC: 02:81:79:10:CC:94, Uptime: 1d 18h 27m 7s, SN: DemoSN001, HBOSN: DemoHBSN001, HBTSN: None, HB2SN: None. Below this is the 'Pool Configuration' section with three rows for Pool 1, Pool 2, and Pool 3, each with fields for Name, Url, Worker, and Password. The 'Network Configuration' section is below, with a 'Protocol' dropdown menu open, showing 'Static' selected. A red arrow points to the 'Save & Apply' button.

(a) Enter the IP address, netmask, gateway, and DNS-Server in turn in the four boxes below, then click “SAVE&APPLY”.

(b) After the page buffering is completed, **the configuration of the server has been completed, congratulations on your becoming a miner.**




The screenshot shows the iPollo web interface. On the left is a sidebar with navigation links: Main, Configuration, Log, and System. The main content area is titled 'iPollo C1' and displays system information: Firmware Version: v0.9.10 (s6+ n3), IP: 192.168.103.38, MAC: 02:81:79:10:CC:94, Uptime: 1d 18h 30m 57s, SN: DemoSN001, HBOSN: DemoHBSN001, HBTSN: None, HB2SN: None. Below this is the 'Pool Configuration' section with three rows for Pool 1, Pool 2, and Pool 3, each with fields for Name, Url, Worker, and Password. The 'Network Configuration' section is below, with a 'Protocol' dropdown menu set to 'Static'. The IP, Netmask, Gateway, and DNS fields are filled out with the values: 192.168.103.38, 255.255.255.0, 192.168.0.1, and 192.168.0.1 respectively. A red arrow points to the 'Save & Apply' button.

Image (Static)


Note: The protocol information filled in "Network Configuration" in the figure (static) is for reference only, please refer to the on-site network protocol information for details.

3.2.2 WiFi connection


- (1) After the V1 mini Classic WiFi server is powered on, it will send out the WiFi signal "iPollo_XXXXXX"; turn on the laptop and connect to the wireless signal "ipollo_XXXXXX"



- (2) Browse the server's default IP address "192.168.2.1" on the website to enter the server login interface:




- (3) Enter Password "root" to enter the server background control interface, click "Wireless" to enter the wireless setting interface





The screenshot shows the iPollo V1 web interface. The left sidebar contains a menu with categories: Main (Running Overview, Information Overview), Configuration (Miner Configuration, Fan Configuration, **Wireless**), Log (Running Log, Running Status, Error Log), and System (Password Change, Firmware Upgrade, Diagnostics, System Reboot, Logout). The 'Wireless' option is highlighted with a red box. The main content area displays the 'Connect Router' section. At the top, it shows system status: iPollo V1, Firmware Version: v0.2122, ETH IP: null, WLAN IP: 192.168.2.1, Uptime: 0h 17m 7s, and a 'Restart' button. Below this, the 'Connect Router' section has a heading 'Enter SSID and Password to connect a router device'. It contains four fields: 'Encryption' (WPA2-PSK (strong security)), 'Cipher' (auto), 'SSID' (TP-LINK_BB66), and 'Password' (masked with dots). A 'Save & Apply' button is at the bottom right.

- (4) Modify the SSID and corresponding password (please make sure there can be no errors, otherwise the server cannot connect to the correct network)




This screenshot shows the same iPollo V1 web interface as the previous one, but with the 'Wireless' option selected in the left sidebar. The 'Connect Router' section is still visible. The 'SSID' field now contains 'TP-LINK_BB66' and the 'Password' field is masked with dots. A red box highlights the 'SSID' and 'Password' fields. The 'Save & Apply' button is still present at the bottom right.

- (5) Click "Save and Apply" after editing




(6) After the application, the server needs to be powered off and restarted;

(7) The laptop is connected to the wireless signal "Nano (the network of the environment where the computer belongs)"



(8) Open the showIP tool, and press the "IP report" button of the server to obtain the new IP address of the server, which is the IP of the WiFi setting.




(9) Use Google Chrome, log in to the IP displayed by the above tool showIP, you can enter the server management background, and fill in the mining pool information to complete the server settings.

3.3 Login Password Modification

If you need to change the server login password, the operation method is as follows:

- (1) The server is powered on and connected to the network;
- (2) Through the browser (Google), enter the server IP account password and login information in turn to enter the server web page background;
- (3) Click "System" and select " Password Change ";
- (4) Enter the modified new password in "New Password", and enter the modified new password again in "Confirmation", and then click "SAVE" below to take effect:



Note: The “Antpool” mining pool is used as an example above. If you use other mining pools, please modify it to the address of the mining pool you want to use and refer to the corresponding mining pool operation instructions.

IV. WARNING

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

--Reorient or relocate the receiving antenna.

--Increase the separation between the equipment and receiver.

--Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

--Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

This device contains license-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic

Development Canada's license-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Scienceset Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autoriséeaux deux conditions suivantes :

- (1) L'appareil ne doit pas produire de brouillage;
- (2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

RF Exposure Statement:

This equipment complies with Canada radiation exposure limits set forth for uncontrolled environments. This equipment should be installed and operated with a minimum distance of 20cm between the radiator and your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Cet équipement est conforme aux limites d'exposition aux radiations définies par le Canada pour des environnements non contrôlés. Cet équipement doit être installé et utilisé à une distance minimum de 20 cm entre l'antenne et votre corps.

Cet émetteur ne doit pas être installé au même endroit ni utilisé avec une autre antenne ou un autre émetteur.

V. Important Notice

1. After the machine is running normally, please use the "24-hour hashrate of the Mining Pool" as the criterion for stability.

2. It is recommended to use the original standard power supply to avoid damage to the machine or safety accidents.

3. Try to use the original standard power supply to suppress the voltage shock at the moment of power-on.

4. Please be careful not to spill water or other liquids on the machine, especially the non-case parts.

5. Please pay attention to ventilation and heat dissipation, do not block the vents, and do not place on flammable materials and fabrics.

6. If you need to disassemble the case to check the problem, please contact customer service support first. If you open the case without permission, the warranty will be voided.