

PRODUCT SPECIFICATION

PRODUCT

12VDC Dimmable PIR Sensor

MODEL NO

HB008VR-BT



12VDC Dimmable PIR Sensor

HB008VR-BT



- 12VDC Input PIR Sensor
- Bi-level Dimmable, Daylight Threshold

 On/Off Control

 Detection Area

 Daylight Sensor

 Daylight Harvesting

 Stand-by dimming level

 Hold Time

 Daylight Brightness Learning

 Mobile APP Control



 Stand-by period

 3 years Warranty

Technical Data




Operating Voltage 10.5-15V	Operating Current >30mA	Detection Angle Fresnel Lens ≤120° Fersnel Lens 360° Ceiling Mounted	Warm-up Period 10S
Operating Current <15mA	Mounting Height Max.6m/19.68ft	Ceiling Mounted	Programming Bluetooth APP
Stand-by power <0.5W	Detection Range Radius.2-4m/6.56-13.12ft	Operating Temperature -30°C~+60°C	
Connection Black white: 12V Pink: GND Purple: DIM	Sensitivity setting 25%/50%75%/100%	IP Rating IP20	
Control Method 0-10V Dim	Stand-by dimming level 10%/20%/30%/50%	Warranty 3 years	
Detection PIR Presence Sensor	Stand-by period 0s/5s/30s/1min/2min/3min/5min/10min/15min/20min/25min/30min/45min/60min/+∞		
Hold Time 5s/30s/1min/2min/3min/5min/10min/15min/20min/25min/30min/45min/60min/90min/120min			
Daylight Sensor Disable/400Lux/350Lux/300Lux/250Lux/200Lux/120Lux/80Lux/50Lux/30Lux/10Lux/2Lux			
Dimming Function ON/OFF Mode 10-100% Sensor Mode 60%-100%			
Daylight Harvesting In Sensor mode, preset daylight threshold as 50LUX or higher options, preset standby period as 0S, then press the DH button on the APP to perform this function.			
Daylight Brightness Learning In ON/OFF mode, slide the rotary bar to dim light till the wanted brightness then press DH button on the APP to perform it.			
Daylight Priority Preset standby dimming level as 10%/20%/30%, standby period as infinite (+∞) and daylight threshold as 400Lux/350Lux/300Lux/250Lux/200Lux/120Lux/80Lux/50Lux/30Lux			

Detection Patterns




Dimensions

Unit:mm




Mechanical structure



① Fresnel Lens





② Quick Connector

Wiring Diagram



Application of Daylight Harvesting

In Sensor mode, preset daylight threshold as 50LUX or higher options, preset standby period as 0S, then press the DH button on the APP to perform this function.




When ambient brightness is lower than preset lux level, sensor will turn on light automatically and keep dimming according to the change of the ambient brightness; when outside is getting darker, the inside will be brighter, and brighter darker.

Light OFF when ambient brightness becomes higher than the preset lux level.


Ambient Brightness Learning

Instead of giving a specific lux level, this function enables current ambient brightness to be learnt and set as a standard lux level; When ambient brightness is getting darker, the artificial light will be brighter; and brighter darker; When ambient brightness exceeds the standard level, light will turn off.




Performance


1. Automatically ON/OFF function



With sufficient daylight, even when motion detected, light remains OFF.




With insufficient daylight, the sensor turns light ON when motion gets detected.




The sensor turns OFF light automatically after the holdtime when there's no motion detected.

2. Daylight Disable


When daylight threshold is preset as "disable", the sensor turns light ON when motion gets detected, and OFF after hold-time.



The sensor turns light ON when motion gets detected.




The sensor keeps light ON for holdtime period after motion leaves.




The sensor turns OFF light automatically after the holdtime.


3. Corridor Function, Bi-level Dimmable




With sufficient daylight, the sensor keeps light OFF even when motion is detected.




With insufficient daylight, the sensor turns light ON when motion is detected.



After there's no motion detected, the sensor keeps light ON 100% for holdtime.



After holdtime, sensor dims light to standby dimming level for standby period.



The sensor turns OFF light automatically after the standby period when there's no motion detected.



Attention

1. Please read the instructions carefully before using this product and keep it well for all users to read at any time.
2. The sensor should be installed by qualified electrician and ensure power is off before the installation.
3. We reserve the right to modify any incorrect text, image and necessary technical parameters.
4. Any unauthorized modification is forbidden, otherwise all guarantees will be immediately invalid.

Installation precautions

1. Turn the power off at the circuit breaker before installing the sensor.
2. Do not allow bare wires to show.
3. Assemble any necessary mounting accessories.
4. Have the sensor's lens lower than edge of the fixture and keep the sensor away from heating part.

Application Environment

1. Do not mount it outdoor, in case the outdoor temperature disturbs it.
2. Do not have it at places with suddenly changed temperature or airflow.
3. Do not have shelves between sensor to the presence area.

APP OPERATING INSTRUCTION

HAISEN ITL app, Owned by
SHENZHEN HAISEN TECHNOLOGY CO.,LTD



1

Press the + button at top right corner or ADD DEVICE button in the centre to add sensors.



2

Choose the middle one, Sensor with Bluetooth. Our APP will work with Zigbee or other wireless connection sensors in the future.



3


The APP starts to find the Bluetooth sensor, please make sure the light blinks and manually confirm it on the APP.



4

The APP shows all the sensors that have been found, add them by pressing the top right ADD ALL in blue or pressing + of each sensor to add them one by one.

*Please make sure the sensor is correctly connected/powered and stays available.



5

The APP shows all the sensors that have been added, press to name it or press top right FINISH button.



6


Added sensors will be shown on the first page of the APP.



7

Press any sensor and starts to control it.

1. Press ON/OFF button to turn on/off the light.
2. Slide to manually dim the light.
3. Read dimming level on top right corner. (10%~100% in always-ON mode, 60%~100% in sensor mode)
4. Press Top right corner to edit the sensor, create a group, delete it or else.
5. Press DH of left bottom to perform daylight harvesting function.
6. Press Sensor of center bottom to start programing the sensor.
7. Press Scene button of right bottom to quickly perform different scene function.



8

Press SENSOR button to program the sensor.

1.  - Quickly enter into sensor mode and perform the last-time saved function before switches to "always ON" mode.
2.  - Quickly enter into sensor mode and perform the default program as: 100% detection area, 5S holdtime, daylight disable, 0S standby period and 10% standby dimming level.
3. Roll to choose wanted option for Sensitivity, daylight threshold, holdtime, standby period and standby dimming level.



9

8 Optional scenes that supports programming and saving, choose to enter any of them.




10

Grouping

Choose to start a group and manually add wanted sensors.


Created groups will be shown on the first page with other sensors.

Choose the group and starts to program it.



11

Reset Operation



If the sensors have been connected to an APP and not available for new connecting, please follow below steps to reset them.

1. Has to work it with this HD03R remote.
2. Press  button on the remote, light blinks 3 times.
3. Now try to add the sensors to the APP again.

What should we do if we accidentally press  button or turn off the main power?

Keep main power OFF for more than 10S and turn it ON, the sensors get back connected to the APP.

Other Information

Max. **20M** distance between APP and sensor or sensor to sensor.

Sensor Qty max. for each family unit
200pcs

Group Qty max. for each sensor getting added
8 Groups

Sensor Qty max. for each group
Unlimited(Based on the truth of 200pcs sensors for each family)

Sensor Qty max. for each group
Unlimited(Based on the truth of 200pcs sensors for each family)

Sensor Qty max. for the Sigmesh Gateway
128pcs, but around **50pcs** is recommended.

Scan the QR Code to download the Test Version;
The official APP is being constructed and uploaded, will be available in this month.



Test Version

Caution:

This device complies with Part 15 of the FCC rules and Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications or change to this equipment. Such modifications or change could void the user's authority to operate the equipment.

This radio transmitter (identify the device by certification number or model number if Category II) has been approved by Industry Canada to operate with the antenna types listed below with the maximum permissible gain indicated. Antenna types not included in this list, having a gain greater than the maximum gain indicated for that type, are strictly prohibited for use with this device.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement.

To maintain compliance with FCC's RF exposure guidelines, this equipment should be installed and operated with a minimum distance of 20cm between the radiator and your body.