

Specifications

Voltage:	10-36V DC
Current draw standby:	4.5 m/a
Current draw active:	30 m/a
Frequency:	433.39 MHz
Remote storage:	50 remotes, 4 x e-Loops, 4 x keypads, 4 x entry buttons
Relay:	1-amp contact rating, COM and N/O connections x 1 relay
Modes:	Pulse, Latch and Hold

Coding device

1. To code device press and release **CODE** button. The Code LED will illuminate.
2. To code remote handset, press the remote button that you want to activate transceiver once. The Code LED will flash, indicating coding sequence.
3. Press remote button a second time, the Code LED will flash again and the coding sequence is now complete.
You can follow on with more remotes, wait 10 seconds for code sequence to automatically exit, or press the coded remote once more to exit.

NOTE: The first time a remote is coded into Transceiver, it sets the button allocation for that remote and all future remotes. So if you have chosen button 1 on the first remote, all following remotes will activate from that button no matter which button you coded the following remotes with.

Changing button allocation

1. Press and hold the **CODE** button on the Transceiver, the Code LED will illuminate.
2. Now take a coded remote and press the button you want the transceiver to work from. All LEDs will flash to indicate changed button allocation.
All remotes will now work from the new selected button.

Deleting remotes

1. Press and hold code button for 10 seconds. All LEDs will flash 3 times to indicate all remote devices have been cleared.

To code e-Loop first option

NOTE: Commercial e-Loop only.

1. Press and release **CODE** button on the Transceiver, the Code LED will illuminate.
2. Now place the magnet in the CODE recess on the e-loop, the Transceiver and the e-Loop will now pair.

If pairing was successful, the code LED will flash 3 times and exit code learn. if pairing fails, the RX LED will flash 3 times and exit code learn.



e-TRANS-50


SINGLE CHANNEL TRANSCEIVER

To code e-Loop second option

1. Place antenna of the Transceiver on top of the e-Loop.
2. Now press **CODE** button on the Transceiver.
If pairing was successful, the Code LED will flash 3 times and exit code learn.
If pairing fails, the Code LED will stay on as per standard coding sequence.

To change operational mode

1. Remove the power from the Transceiver by unplugging the terminal block.
2. Now hold the **CODE** button on the Transceiver, then plug in the terminal block. The Menu LED will display.
Now release the **CODE** button, the Code LED will also display indicating Pulse mode.
3. To change mode press **CODE** button, the Menu LED and RX LED will now display indicating Hold mode.
4. Press **CODE** again and all LEDs will display indicating Latch mode. (By pressing **CODE** button again it will take you back to Pulse mode).
Wait 5 seconds and menu will exit back to operational mode.



FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.