

USER'S Manual

SR-612U

CAUTION:

This Walkie-Talkie is the product with excellent design and advanced technology. The following suggestions will help you fulfill your obligations under warranty terms and understand the safety knowledge of using walkie-talkie.

1. Don't try to disassemble the walkie-talkie. Unauthorized disassemble may cause damage to the walkie-talkie.
2. This machine can use universal qualified mobile phone charger(5V).
3. Don't expose the machine to sun for a long time or put it on a overheated place.
4. Don't place it in a dusty or damp place.
5. Don't use strong chemicals, cleaning agents or strong lotions to clean walkie-talkie.
6. If it is found to emit peculiar smell or smoke, place it on the open ground to avoid injury, and contact the distributor in time.
7. Don't use the machine inflammable, explosive or other place where walkie-talkie is prohibited.
8. In order to obtain the best communication performance, it is recommended that least distance between walkie-talkies is 2 meters.
9. Please abide the local wireless management regulations, Contact with the distributor if you have any questions.
10. This radio is designed for and classified as "General population/uncontrolled Use" and Personal Radio Service.
11. The separation distance between user and the device or its antenna shall be at least 2.5 cm.
12. The highest reported SAR values for Face-held, body-worn are 0.14W/Kg, 0.58 W/Kg.

Checklist:

Open the package carefully, check the product and accessories according to the following list:

Please conduct your distributor immediately if any damaged or missing happened!

NO.	Item	QTY
1	Walkie-talkie	1
2	Charger	1
3	Charging line	1
4	Earphone	1

5	User manual	1
6	Sling	1

Function & Description:


Function	Description	Remark
Channel	Up to 22 channels	Default:22 channel
CTCSS/DCS	Normal: 38 CTCSS+61CDCSS Professional: 50CTCSS+105CDCSS	Can be adjusted in normal mode only. Professional is default mode.
Volume	Receiving vlume	1-8
Battery saving	Extending standby time	

Description for LCD Icon:



Indicative Sign	Name	Contents
	Channel/Hour /Volume level	Current Channel: Intercom mode Displaying time: Hours at Clock mode Volume Level: Current level when adjusting volume level
	CTCSS/DCS/Minute	CTCSS/CDCSS: Intercom mode Displaying time: Minutes at Clock mode
	Battery Meter	Higher number of grid, the more quantity of electricity
	Scan Indicator	Icon is lighted when scanning.

Unit Description




SR612

SR619

序号	Name	Description
①	Antenna	
②	Indicator	Red light is on: Transmitting signal Green light is on: Receiving Signal
③	USB Socket	Charging Interface
④	Display panel	Operation status indicator, clock, channel etc.
⑤	PTT key	Push to Talk
⑥	Down key	decrease channel/volume
⑦	Power / Menu key	Power on/off, Menu entrance
⑧	Up key	Increase channel/volume
⑨	Sling hole	Install the Sling
⑩	Ear Jack	Earphone Interface
(11)	MIC	Microphone
(12)	Speaker	Main Speaker

Fast Function guideline:

Function Introduction	Brief Description
Mode Switch (Power ON/OFF)	While power off mode, pressing the “M” key for 2 seconds, “Di” sound will be heard , LCD will be lighted, the radio turns on。 While power on mode, pressing the “M” key for 2 seconds, “Di” sound will be heard , LCD will be shut off, the radio turns off。
Intercom	Pressing the “PTT” key on the radio or “PTT” key on the earphone , and talking into the microphone。 The radio will enter receiving mode after releasing the “PTT” key。
Setup 	The transceivers must be set as same channel and CTCSS in order to intercom. 1、 Press the “M” key shortly while standby mode, Channel number “5” blinking, adjusting channel by using the “UP/DOWN” key; 2、 Press the “M”key shortly again, CTCSS/DCS number “01” is blinking, adjusting CTCSS/DCS by using the “UP/DOWN” key; 3、 Press the “M” key shortly to next or press ‘PTT’ key to save the setting and exit.
Volume setup 	1. Press “UP” or “DOWN” key shortly while standby mode, the LCD will be lighted as the left, ‘8’ is blinking; 2. Press “UP” / “DOWN” key to adjust the volume (Min: 1, Max: 8) 3. Press the “M” key shortly save the setting and exit.
Vox Setup 	After setting up CTCSS, pressing ‘M’ key shortly and the LCD will be lighted as the left, and the number ‘0’ is blinking: Press ‘UP’ or ‘DOWN’ to adjust, 0 for VOX is off, 1-3, for VOX is on (3 for high sensitivity). Press the “M” key shortly save the setting and exit.
Lock the key 	While standby mode, Press the “up” and “down” key at the same time for 2 seconds, the key is locked on/off as the icon is on/off. while the key is locked, Only the ‘PTT’ and ‘M’ key (Power on/off) can be used.

Battery Information:

■ Charge note

Please charge the transceiver when battery low.

Battery meter will be rolling while charging. The rolling will be stopped when the battery is full.

FCC WARNING:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

—For a Class B digital device or peripheral, the instructions furnished to the user shall include the following or similar

statement, placed in a prominent location in the text of the manual:

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.