

SHARPER IMAGE®

12+

Rechargeable 2.4GHz DX-1 MICRO DRONE



BC

**CHOKING HAZARD –**
SMALL PARTS NOT FOR CHILDREN UNDER 3 YEARS.
ADULT ASSEMBLY REQUIRED.

SHARPER IMAGE®

Rechargeable 2.4GHz DX-1 MICRO DRONE

INTRODUCTION

Congratulations on your purchase of the Sharper Image Rechargeable 2.4 GHz DX-1Micro Drone. Get ready to soar to new heights. Master the art of drone flying with remote control maneuverability. This lightweight micro drone will provide hours of fun.

SPECIFICATIONS

Drone Battery: 100 mAh Li-po
Remote Controller Battery: 2 x 1.5V AAA
Charging Time: Approximately 30 minutes
Maximum Recommended Altitude 65 ft.

TABLE OF CONTENTS

General Warnings

Contents and Remote Battery Installation

Charging LiPo and Drone Storage

Remote Overview

Operating Drone

Modes and Installing Blade Gaurds

Troubleshooting and FCC Warning

Page 1

Page 2

Page 3

Page 4

Page 5

Page 6

Page 7

Page i

SHARPER IMAGE®

Rechargeable 2.4GHz DX-1 MICRO DRONE

READ ALL WARNINGS AND PRECAUTIONS BEFORE USE

 **SAFETY WARNINGS:**

- Not recommended for children under 12 years of age. As with all electrical products, precaution should be observed during handling and use to reduce the risk of electrical shock.
- Adult supervision is required at all times
- Before each use, an adult should review the product and battery to determine that no damage or hazards exist
- **DO NOT TOUCH SPINNING PROPELLERS**
- Do not allow anything to intentionally make contact in any way with spinning propellers
 - Prevent contact with spinning blades by turning off remote prior to handling drone
- **Use caution and pay attention to your surroundings while operating drone**
- **Do not fly drone into animals, people, or inanimate objects**
- Keep drone away from power lines, buildings, trees, public areas, and any other potentially hazardous areas.
- Do not operate in rain, heavy wind, and or any type of severe weather
- Do not land drone on wet surfaces
- Never touch or allow others to touch drone while it is flying
- Always turn drone off when it is not in use
- Always fly drone in large open areas
- Never fly drones above or near people, sudden changes in wind or other conditions could lead to unexpected crashes.
- Always use caution when flying drone vehicles, obey relevant laws, respect the privacy and property rights of others.
- The drone shall never be modified or used for anything except its intended purpose.



PLEASE RECYCLE OR DISPOSE OF ELECTRONICS PROPERLY
RECYCLING INFORMATION IS AVAILABLE AT MSCUSTOMERCARE.COM

Page 1


SHARPER IMAGE®

Rechargeable 2.4GHz DX-1 MICRO DRONE


CONTENTS




DX-1 Micro Drone




Drone Controller




USB Connector



Blade Guards



Replacement Propellers



REMOTE BATTERY INFORMATION

1. Slide open battery compartment

2. Install 2 "AAA" batteries as shown in diagram shown above

3. Replace and close battery compartment

LITHIUM-POLYMER BATTERY WARNING

There is a risk of fire and personal injury if Li-Po battery is punctured, damaged or misused

- Never expose battery to extreme temperatures or moisture
- Do not subject battery to strong impacts
- Always keep battery away from flammable materials
- Only use manufacturer specified battery(ies), charger(s), and/or adapters, if applicable, specified by the manufacturer
- Battery is not serviceable
- Let battery cool to room temperature before charging
- While charging, never leave battery unattended
- Recycle or dispose of battery according to federal, state and local laws

KEEP THIS INSTRUCTION MANUAL FOR REFERENCE

BATTERY WARNING

- Do not mix old and new batteries
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries
- Insert batteries using the correct polarity. Do not short-circuit the supply terminal
- Only use manufacturer specified battery(ies), charger(s), and/or adapters, if applicable, specified by the manufacturer
- Always use, replace, and recharge if applicable) batteries under adult supervision

KEEP THE PACKAGE FOR REFERENCE AS IT CONTAINS IMPORTANT INFORMATION

Page 2

SHARPER IMAGE®

Rechargeable 2.4GHz DX-1 MICRO DRONE


CHARGING BATTERY

Note: The Battery Charger will light up when it is charging the battery and turn off when the battery is fully charged. Charge time is approximately 30 minutes.

Turn off the drone before charging.


Carefully connect the Drone to USB charging cord as the connector. Connector is delicate and must be handled with care.

Connect USB connector to power source.




Connect the Battery Charger to the Drone

Insert the USB connector into a USB power source



Correct

Incorrect




Drone can be charged and stored inside of controller:

Page 3

SHARPER IMAGE®

Rechargeable 2.4GHz DX-1 MICRO DRONE



Throttle Joystick
↑ Increases or decreases drone elevation
←→ Use L/R arrows for spin

ON/OFF Remote Switch

* Multi Direction Joystick

Spin Adjustment: Slide left to spin drone counterclockwise and slide right to spin drone clockwise

Auto Orientation ON

Auto Orientation OFF

Side to Side Adjustment: Slide left to adjust to the left and slide right to adjust to the right

Forward/ Backwards Adjustment: Slide up to adjust forward and slide down to adjust backwards

Page 4

SHARPER IMAGE®

Rechargeable 2.4GHz DX-1 MICRO DRONE

OPERATING DRONE

Step 1 – Pre Flight Checklist

1. Read all warnings and instructions

2. Install remote batteries, page 2

3. Make sure that drone and remote are powered off

4. Install Blade Guards, page 6.

5. Charge batteries, page 3.

Step 2 – Choosing a location

- Drone is designed to be flown indoors only
- Always make sure you have enough space to fly drone
- Always follow warnings, page 1

Step 3 – Starting Drone

1. Making sure your remote is off, slide drone switch to ON. Drone lights will begin to flicker

2. Choose a flat even surface and follow the diagram

3. Turn remote on. Bring the Throttle all the way up then bring it all the way down. Remote will beep and drone lights will flicker rapidly then turn on permanently once paired.

4. Drone is ready for flight.

Step 4 – Lift Off

1. Slowly and carefully bring the throttle up. Propellers will begin to spin and drone will begin to elevate. You can compensate for some of the drones drifting by using the Multi Directional Button or by following step 5. You may need to practice this step several times before successfully getting drone into the air.

Step 5 – Drone Begins to Drift


Follow this step if your drone begins to drift while take off or during flight

- Drone drifts backwards: Slide the Forward/Backwards Adjustment up
- Drone drifts forwards: Slide the Forward/Backwards Adjustment down
- Drone drifts left: Slide the Side to Side Adjustment to the right.
- Drone drifts right: Slide the Side to Side Adjustment to the left.
- Drone spins clockwise (viewing drone from top): Slide the Spin Adjustment to the left.
- Drone spins counter-clockwise (viewing drone from top): Slide the Spin Adjustment to the right.

Step 6 – Operating Drone in Flight

The drones range is approximately 100 feet

- Read and be aware of all warnings found on page 1.
- Maintain your desired elevation by using the Throttle
- Use the Throttle joystick in a circle motion to spin the drone
- Use the Multi Directional Joystick to move forwards, backwards, and side to side
- Review step 5 if your drone begins to drift



Always turn off remote prior to retrieving or picking up drone. This will help you avoid accidentally activating propellers.

Page 5

SHARPER IMAGE®

Rechargeable 2.4GHz DX-1 MICRO DRONE


MODES

Auto Landing


- This mode will activate when the remote loses signal or when remote is turned off or when battery gets too low.
- The ideal auto landing height is 15ft.
- This mode allows you to safely and slowly land your drone without having to control the speed. It is done for you automatically.

Auto Orientation


- Auto Orientation default setting is off. To enter this mode press Auto Orientation "+" button. Remote will beep twice.
- After drone success paired, the 2 white LED lights toward orientation will be the original forward orientation, when drone is in auto orientation mode, whatever the drone spin, the forward orientation will be previous original forward orientation.
- Remote will beep every 6s to indicate the drone is in Auto Orientation mode.
- To exit mode, press the "-" button. Remote will sound 1 long beep indicating that it has exited Auto Orientation mode.



1. Identify the number on the blade guard and match it to the number on the Drone.



2. Carefully align the propeller so it is horizontal to the leg of the Drone.



3. Coming from below, angle the Blade Guard to the propeller post.

4. Carefully clamp the Blade Guard around the propeller post. Press down on the base until it clicks.


5. Repeat on three remaining corners.

REPLACING PROPELLERS

1. Follow diagram to the right.

2. Make sure you installed the correct blade Each blade has a letter written on it

NOTE: Blade 1 turns counter clockwise and Blade 2 turns clockwise



Page 6

SHARPER IMAGE®

Rechargeable 2.4GHz DX-1 MICRO DRONE

TIPS

- Do not crash drone into sand or dirt. Drone gears may become clogged
- When first learning to fly, practice lifting off and hovering
- Stay several feet from walls and buildings
- Always Press Throttle all the way down after crashing or when something gets stuck in propellers
- Never fly drones above or near people, sudden changes in wind or other conditions could lead to unexpected crashes.
- Always use caution when flying drone vehicles, obey relevant laws, respect the privacy and property rights of others.
- The drone shall never be modified or used for anything except its intended purpose.

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

TROUBLESHOOTING:

When remote switch is turned on, the remote light does not illuminate:

1) Check that batteries in the remote are installed correctly OR

2) Replace with new batteries

When the remote is switched on, the remote LED is flashing and remote is beeping:

1) Remote batteries are low; replace them with new batteries

Drone and remote properly pair, but the drone will not lift-off:

1) Drone Li-Po needs charging. Use charging cable to connect the drone to power source.

After trimming the drone, the drone flight is very unstable and cannot fly properly:

1) One or more blades are most likely damaged.

2) Turn off the drone and remote.

3) Replace with the proper number replacement blade and try flying again.

After pairing, the drone is unstable:


1) Put the left remote control lever to the left bottom and put the right remote control lever to the right bottom at the same time which connected to the drone (diagram to right).

2) If the above does not resolve the issue, reboot the drone and controller and pair again.

Remote Controller and Drone can not be paired:

1) Check Point: Remote Controller must be closed to Drone, not exceed 4 meters.

Note: If there are 2 sets of Drones within 4 meters for Pairing, you must pair one successfully before pairing the second set.



This drone complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

© Sharper Image. All Rights Reserved.
SHARPER IMAGE® name and logo are registered trademarks manufactured and marketed by MerchSource, LLC under license. All other logos and trademarks are proprietary to their respective owners. The artwork and design of this package are protected by US copyright law and may not be reproduced, distributed, displaced, published or used for any purpose without prior written permission. Altering, removing or reproducing any of the trademark or copyright notices on this package is not permitted.

©2016 MerchSource, LLC. All rights reserved.
Distributed by MerchSource, LLC, Irvine, CA 92618.

PATENT PENDING
Printed in China

Page 7