



Glow Speaker



Operation Manual CRA-LEDRP

Thank you for purchasing the Crayola Glow Speaker. Please read all instructions carefully before using and retain this manual for future use and reference.

PACKAGE CONTENTS

- Glow Speaker
- Operation Manual
- Optional 3.5mm AUX Cable
- USB Charging Cable
- USB Connection Cable

KEY FEATURES

- Compatible with Bluetooth-enabled tablets & devices
- Built-in rechargeable battery
- LEDs lights change color with your music

SAFETY INSTRUCTIONS

Keep the unit away from heat sources, direct sunlight, humidity, water and any other liquids.

Do not operate the unit if it has been exposed to water, moisture or any other liquids to prevent against electric shock, explosion and/or injury to yourself and damage to the unit.

Do not use the unit if it has been dropped or damaged in any way.

Repairs to electrical equipment should only be performed by a qualified electrician. Improper repairs may place the user at serious risk.

Do not puncture or harm the exterior surface of the product in any way.


Keep the unit free from dust, lint, etc.

Do not use this unit for anything other than its intended use or purpose. Doing so may damage the device.

This product is not a toy. Keep out of reach of children.

Do not expose batteries, battery pack, or installed batteries to excessive heat, such as direct sunlight, or open flame.

Speaker Front



Speaker Rear



FEATURES/PARTS

1. Power / Play / Pause / Call Button
2. Multifunction / LED Control
3. Previous Song / Volume Decrease
4. Next Song / Volume Increase
5. Microphone
6. Micro USB Charging Port
7. USB Audio Input
8. 3.5mm AUX Port

CHARGING THE SPEAKERS

The speakers come with a built-in rechargeable battery. Before using it for the first time, we recommend you charge the battery fully. Only use the supplied USB cable to charge the speakers.

Connect the USB cable to a computer USB port and the USB plug to the charging jack of the headset. The red LED light will illuminate while the speakers are charging.

A full charge of the battery takes around 2 hours. When the battery is fully charged, disconnect the speakers at this point. The speakers will then be ready for use.

If your speaker begins to make a busy signal noise while you are using it, this is to notify you that your battery is low. Please recharge your speaker at this point.

In order to save power, the speakers will automatically turn off if not paired with a device after 5 minutes.

PAIRING THE SPEAKERS

1. Ensure the speakers are turned on. Press and hold the Multifunction button until the speakers turn on and the LED flashes blue. This will indicate your speakers are now in pairing mode.

2. Ensure Bluetooth® is enabled on your smart phone or music device.
3. Your device will start searching for Bluetooth devices.
5. The speaker will appear as "CRA-LEDRP" in the list of available Bluetooth® devices.
6. Select "CRA-LEDRP"
7. Enter password "0000" (if required) to confirm pairing.

Note: If pairing is unsuccessful, turn off the speakers first and re-pair following the aforementioned steps. Once you have paired the speakers with a device, the speakers will remember this device and will pair automatically when the device's Bluetooth® is activated and in range. You do not need to re-pair any previously connected devices.

LISTENING TO MUSIC

Once the speakers are paired to your device, you can stream music wirelessly to the speakers. Select the track you wish to play on your device and listen to via speakers. Should you encounter any problems while streaming, please refer to your device's user manual.

OPTIONAL AUX

The speakers can also play music using the enclosed AUX cable. Simply connect your audio device to the speaker using the 3.5mm jack and begin playing music.

NOTE: Media shortcuts may not work when playing the speaker using the AUX cable. You can control media and volume from your phone or tablet directly.

LED LIGHTS

The LED lights on the speaker will change automatically to the beat of your music. To see the lights on the speaker change, select upbeat music, or ensure that the volume of your audio device is turned up sufficiently.

MEDIA SHORTCUTS

To skip to the previous/next track, press the corresponding media shortcut once. To increase/decrease volume, press and hold the corresponding media shortcut until you reach your desired volume.

ANSWERING A CALL

Your speaker is equipped with a built-in microphone. When your music is playing, and you receive an incoming call, press the Call button once to answer call. Press the Call button again to end call.

CARE AND MAINTENANCE

- To prevent damage to speakers, do not expose them to liquid, moisture or humidity.
- Do not use abrasive cleaning solvents to clean the unit.

- Do not expose the unit to extremely high or low temperatures as this will shorten the life of the electronic device, destroy the battery, and/or distort certain plastic parts.
- Do not dispose of the unit in fire as it may explode or combust.
- Do not expose the unit to contact with sharp objects as this will cause scratches and damage.
- Do not let the unit fall from high places, as doing so may damage the internal circuitry.
- Do not attempt to disassemble the unit.

In the event that the unit does not function properly, return it to the store where it was purchased.

SPECIFICATIONS

Bluetooth: V2.1 + EDR
Operating Distance: Up to 33ft (10m)
Play Time: Up to 2 Hours
Standby Time: Up to 100 Hours
Battery: 3.7V / 1200mAh
Charging Time: ~3 Hours
BT ID: 52059
FCC ID: xxxxxxx

WARRANTY INFORMATION

The condition of this warranty and our responsibilities under this warranty are as follows:
Supplier's warranty is non-transferable. And this warranty

is limited to the original purchaser only.

*You must be able to prove the date of original purchase of the unit with a dated receipt.
*The warranty is not applicable if the product has been subject to physical abuse, improper installation, modification or repair by unauthorized third party.
*The responsibility of supplier's products shall be limited to the repair or replacement of the product as its sole discretion.

*Specifically, exempt from any warranty are limited-life consumable components subject to normal wear and tear such as batteries, decorations and other accessories.
*A supplier will not take any responsibility if the failure of the unit has resulted from accident, abuse, misuse, or any unauthorized repair, modification or disassembly.

*Modification and repair of the unit should be done by authorized and qualified service personnel, Center or returned to the manufacturer.

*This warranty gives you specific legal rights, and you may also have other rights which vary under local laws.

The following conditions comprise the requirements and scope of our warranty conditions and do not affect our legal and contractual warranty obligations. We offer a warranty on our products in accordance with the following conditions:

1) DGL™ products are covered by a 3 month warranty. We will resolve damages or defects on DGL™ products free of charge within 3 months of the purchase date under the following warranty conditions. For any damage or defect determined later than 3 months after the purchase date, proof of a manufacturing fault must be submitted for repair under warranty.

2) The warranty does not cover batteries and other parts, which are considered consumables, parts that break easily such as glass or plastic or defects based on normal wear and tear. There is no warranty obligation in the event of marginal differences compared to the target appearance and workmanship provided these have a negligible effect on the product's fitness for use, in the event of damage

caused by chemical or electrochemical effects, by water or generally from abnormal conditions.

3) The warranty will be performed in such a way that we shall decide whether to repair the defective parts or to replace them with working parts free of charge. DGL™ reserves the right to exchange the product for a replacement product of equal value if the product sent in cannot be repaired within a reasonable time or at a reasonable cost. Requests cannot be made for repairs to be carried out on site. Parts that have been replaced or exchanged become our property.

4) The warranty claim does not apply if repairs or other work is carried out by unauthorized persons or if our products are equipped with additional parts or accessories that are not approved for our product.

5) Warranties that have been activated do not cause the warranty period to be extended, nor do they trigger a new warranty period. The warranty period for any replacement parts installed ends with the warranty period for the entire product.

6) Any other further claims are excluded, especially those for replacement due to damage caused to the outside of the product, provided there is no obligatory legal liability. We therefore accept no liability for accidental, indirect or other consequential damage of any kind, which leads to usage restrictions, data loss, and loss of earnings or interruption to business.

Asserting a warranty claim:

1) To make use of the warranty service for hardware issues, you must contact the DGL™ Service Center by email at support@dglusa.com

2) DGL™ will try to diagnose and solve your problem. If it is determined that a warranty claim exists, you will be given an RMA number (Return Material Authorization) and will be asked to send the product to DGL™.

IMPORTANT: DGL™ will only accept parcels that have an RMA number.

Please observe the following when sending the product:

1) Send the product suitably packaged with carriage and insurance paid. Do not enclose any accessories with the product (cables, chargers, manuals, etc) unless the DGL Service Center specifies otherwise.

2) Mark the RMA number on the outside of the package in such a way that it is visible and clearly legible.

3) You must enclose a copy of the sales slip as proof of purchase.

4) Once DGL™ has received the product, it will meet its warranty obligations in accordance with the warranty conditions and will return the product to the sender with carriage and insurance paid.

Service outside of warranty
DGL™ can refuse any service claim made that is not covered by the warranty.

If DGL™ agrees to provide a service outside the warranty, the customer will be invoiced for all repair and transport costs. DGL™ will not accept any packages that have not first been approved by DGL™ by means of an RMA (Return Material Authorization).

DGL Group guarantees the quality of this Crayola product.

For questions or comments, please feel free to contact us at 888-987-3089 Monday - Friday, 10am - 3pm EST or via email at support@dglusa.com.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.