

IQ TILT S-LINE QUICK INSTALL GUIDE



OVERVIEW

The IQ Tilt is designed to tell you whether an overhead garage door is open or closed. The tilt sensor houses a cylinder with a metal bearing inside. When the sensor is tilted, the bearing rolls down the cylinder towards from the metal contacts. This connects a circuit and sends a signal to the panel saying that the garage has been opened. *NOTE: Improper orientation and/or placement of the bearing cylinder may result in false alarms or incorrect signals.*

STEP 1 REMOVE BATTERY TABS




STEP 2 APPLY ADHESIVE



STEP 3 TUBE ORIENTATION

The cylinder should be angled inside the sensor housing as shown



SPECIFICATIONS

Sensor: 2.5"H x 1"W x .5"D

Wireless signal range: 600ft (200M), open air.
Code outputs: tamper, tamper restore, alarm, alarm restore, low battery.
Transmitter frequency: 319.5 MHz
Unique code ID
Supervisory keep-alive interval: 70 minutes.
RF Peak field strength: typical 36000 uV/m at 3m


Operating Temperature: -10C-50C
Relative Humidity: 5-95% Non-Condensing
Storage Temperature: -40-80C

Replace battery with exact replacement every 5 years with 3V Lithium (x2).

- (2) -Panasonic CR2032
- Energizer CR2032
- Duracell DL2032

This is a quick guide for experienced installers only. Refer to <http://dealers.qolsys.com> (login required)

STEP 3
CHOOSE
INSTALL
LOCATION



Choose a mounting position on the top panel of the door.

STEP 4
SENSOR
PLACEMENT




Mount the sensor horizontally with the arrow facing UP, as shown.

Note: The "arrow" on the side of the sensor should be facing up.

STEP 5
LEARN
INTO
PANEL



Place your panel in
"autolearn" mode



Open and close the case
to "tamper" the device

ADD

Customize name and settings
as desired and touch "ADD"



ASK
JENNI
Qolsys



Document#: IQTILT-SQG-10-17
Revision#: 11/7/17
Issue Date: OCT 2017
Qolsys Product #: QS1131-840

Qolsys Inc. proprietary.
Reproduction without permission is not permitted.
FCC ID: 2ABBZ-RF-CHW-S
IC: 11817A-RFCHWS

GOT QUESTIONS?
CONTACT TECH SUPPORT
TechSupport@Qolsys.com

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Cet appareil est conforme avec Industrie Canada exempts de licence standard RSS (s). Son fonctionnement est soumis aux deux conditions suivantes: (1) cet appareil ne doit pas provoquer d'interférences et (2) cet appareil doit accepter toute interférence, y compris celles pouvant causer un mauvais fonctionnement de l'appareil.