

Precautions to Know Before Flying a Drone

1. It is recommended that you use the product for users over the age of 8.
It is recommended that first-time users be familiar with the manual and use it with sufficient practice.
2. The drone's propeller is so fast that it always requires attention and can cause physical and property damage.
For your safety, always maintain a certain distance from the drone.
3. Manufacturers and vendors are not responsible for accidents due to poor operation.
4. Fly in normal weather conditions with temperatures between 50 °F and 122 °F.
5. For operational and repair inquiries, please contact your place of purchase.

Before flying a drone, note

1.Before flying drones, always look around.
2. Fly within the user's vision.
3.The child should fly the drone from where the parents are looking.
4.When using multiple drones at the same time, be careful with the frequency.

Precautions

- * Be sure to check all items regularly before flying. Replace, repair and operate after damage.
- * Recharge using the charger provided.
- * Be sure to turn off and remove the power when removing dust from the product.
- * Do not randomly change the structure of this product.
- * Recycle battery or battery packs or dispose of them correctly according to waste disposal methods.
- * Be sure to turn off and store the power of the drones and the controls when storing.
- * Do not throw or drop drones and controls.
- * Read and familiarize yourself with the handling manual.

Do not fly drones in the following circumstances

Basic Component Guide

Name by Drone Part

No	Name	Quantity
1	CCW Propeller (B)	2
2	CW Propeller (A)	2
3	Housing	1
4	Frame	1
5	CCW Motor	2
6	CW Motor	2
7	Lithium Battery	1
8	Main Board	1
9	Rubber Damper	4

Pilot Guidance

When Pressed Briefly

When Pressed Long

When the drone does not have a battery, the buzzer sounds on the controller and the LED on the drone flashes.

Insert Controller Battery

*Open the battery cover.
Insert battery for polarity (+/-) indication.
Close the battery cover.

Caution:
A. Make sure the battery is inserted to the polarity mark.
B. Remove discharged batteries and do not use batteries of different types.

Connecting Drone

1. Connecting the Controller to the Drone

When the drone's battery is connected, the drone's LED flashes. The battery is automatically paired when connected and powered on. A beep will be heard and paired automatically.

* Important: The controller and the drone are basically paired. The battery is automatically paired when connected and powered on. You do not need to perform a pairing every time.

2. New Connecting the Controller to the Drone

If no drones and controls are connected, or if a new control and connection is required, new drone pairing is carried out.

1. Within 20 seconds of connecting the drone's battery, hold the drone in your hand and shake it quickly to enter pairing mode. (The LED flashes red/blue quickly when in pairing mode)

2. Put the drone in pairing mode on the floor and turn on the controller.

3. Pair the drone by pressing the PAIR button on the controller for more than 3 seconds.

4. When 4 drones are connected, a beep is heard and the LED color is fixed.

Precautions

The pairing mode can only be entered within 20 seconds of the battery connection and after 20 seconds the drone's battery must be reconnected.

Pilot Main Function Guidance

1. Power On/Off / Reset Sensor

Press and hold the power button in the middle of the controller for more than 3 seconds to turn it on and off. With the drone connected, press and hold the reset button to reset the sensor for the drone.

2. Throttle Lever & Directional Lever

Once the drone is connected to the controller, it can begin to operate the drone. For instructions on how to control each lever, see How to control a drone.

3. Trim Adjustment (F/B/L/R Button) & Mode 1/2 Change

To stabilize a drone during flight if it is tilted in either front/rear/left/right direction: Press the F (front)/B (back)/L (left)/R (right) trim button to operate. You can change the mode using the L (left) and R (right) buttons when you are not in the flight

Motor Start/Stop

You can start/stop the motor when it is not in flight.

Push both levers simultaneously as shown in the image and hold for at least 2 seconds.

Emergency stop

In the event of an emergency situation during flight, the emergency stop function can be used to stop the motor of the drone.

Press and hold the speed start/stop button and press the throttle lever down to make an emergency stop.

CAUTION: If the emergency stop function is used, the motor will stop and fall in the air, so the drone may be damaged. Only operate the function in an emergency.

Headless Mode

Activate the 'headless mode' for beginners.

The 'headless mode' is fixed in the direction of the drone's operation, regardless of the direction of the drone's front or rear.

'Headless mode' On when the LED on the controller flashes by pressing and holding the F button while landing.
'Headless mode' off when the controller's LED illuminates brightly by pressing and holding the B button while landing.

CAUTION: 'Headless mode' on/off can only be changed when landing; it cannot be changed during flight. When the headless mode is turned on by pressing the button, the direction the drone is facing is fixed forward.

Change Mode

Mode 1

Settings allow you to change to mode1 or mode2.

Pressing and holding the Ltrim button for more than 3 seconds while landing mode1
Pressing and holding the RTRIM button for more than 3 seconds while landing mode2

Caution: the default state is set to mode2 and if you change the mode, Be sure to familiarize yourself with the operation of that mode before flying.

Rotate 360 degrees (Mode)

When the start button is pressed and held, the controller will continuously beep.

Mode 2

Rotate Forward: up the rudder.
Rotate Back: Turn the Directional Levers Down
Left Rotation: The rudder is left.
Right Rotation : The directional lever to the right

Left Rotation

Right Rotation

Once familiar with the above three steps, practice a combination of precision control flights by simultaneously manipulating the three phases in the air.

=1=

=2=

=3=

=4=

=5=

Propeller Repacement

Periodically check the propeller status of the drones and replace them with new ones if damaged/damaged.

1. The drone has four propellers. Among them, yellow represents the front.
2. Refer to the image and make sure that the direction of rotation is the matching propeller.
3. IMPORTANT: Normal flight is not possible if the propeller is not in the correct direction.

A = Clockwise Yellow Propeller

B = Counterclockwise Yellow Propeller

B = Counterclockwise White Propeller

A = Clockwise White Propeller

To Charge

1. Disconnect the battery out of the drone. The included charging via the charger usb.

2. charging, the charging is completed, and indicators illuminated indicator will extinguish.

Precautions

A continuous beep sound from the controller during flight indicates that the drone's battery is running low. Charge the battery after landing.

Battery Charging

Connect to the adapter or PC to charge

Battery Precautions

Drone Battery: Please comply with the regulations for the use of lithium batteries.
Controller Battery: The controller requires two 'AAA' batteries.

Please read the precautions below carefully.

- Do not use any other type of battery.
- Do not use with a discharged battery.
- Do not charge disposable batteries.
- Take care when charging the battery.
- View the polarity indicator (+/-) and insert correctly.
- Do not heat the battery or put the battery in the fire.

Precautions

LED Display Information		Charging specification		
LED OFF	LED ON	Input	Charging current	Maximum Voltage
Charge Complete	Charging	5V	420~450mA	4.2 ± 0.03V

Battery Capacity and Charging Specifications

Battery Type	Battery Capacity	Time of Use	Charging time
Lithium Battery	3.7V 220mAh	Maximum flight time of 5 minutes	40 Minutes (approximately 0.5 Amps)

Guides and caveats for first-time users

Precautions

- Make sure the battery is fully charged.
- Make sure the propeller is correctly installed.
- Make sure that the control and the drones are connected as normal.
- Make sure there are no obstructions in the area.
- Practice the drones first for take-off and landing and emergency stop functions.
- Use a distance of more than 2 meters from the drone.

1. To practice take-off and landing

1. Place the drone on a flat surface and prepare for flight.

2. Press the automatic take-off/landing button of the controller for more than 3 seconds to take off.

3. The drone hovers.

4. During flight, press and hold the automatic take-off/landing button on the controller for more than 3 seconds to land. Please also be familiar with the emergency stop function in case of emergency.

2. To practice throttle lever

1. Place the drone on a flat surface and prepare for flight.

2. Press the automatic take-off/landing button of the controller for more than 3 seconds to take off.

3. The drone hovers.

4. During flight, press and hold the automatic take-off/landing button on the controller for more than 3 seconds to land.

Please also be familiar with the emergency stop function in case of emergency.

3. To practice directional control (Mode2)

1. Use the right-hand lever to slowly push forward/backward to practice front/backward control in the air.

2. Practice pushing the levers slowly to the left and right, as shown above.

4. Practice of rotation (Mode 2)

1. Slowly raise the left throttle lever to maintain altitude in the air.

2. Adjust the throttle lever to maintain constant altitude and slowly slide the throttle lever to the left or right to rotate.

If not in headless mode, the drone rotates and changes direction, so be aware of your flight.

5. Precision Control Exercise

Once you are familiar with the preceding 'practicing, practice your flight with a combination of fine-tuning and fine-tuning the various commandments in the air.

6. Trim

Take off the drone in a windless environment to see if it is flowing in the air.

1. Forward/Reverse Moving Trim: When a drone flows forward in the air without any operation Press the B button on the controller to adjust the trim. Conversely, if it flows backwards in midair without any control, press the F button on the controller to open the trim. Adjust it.

2. Left/Right Trim: When a drone flows from the air to the left without any operation Press the R button on the controller to adjust the trim. Conversely, if you're moving in midair to the right, press the L button on the controller. Adjust the trim.

NOTE: The controller will beep whenever the trim button is pressed. Once the maximum value of the trim setting is reached, there will be no more beeps. If normal flight is difficult even with trim setting, reset the drone sensor. (Press the drone on a level surface and briefly press the controller's power button to reset the sensor.)

7. Rotate 360 degrees (Mode2)

* Make sure you have enough free space before turning 360 degrees.

Press and hold the LED/FLIP button on the right side of the detector to hear a beep.

Push the right-hand lever in the desired direction and the drone rotates 360 degrees in that direction.

Stable and easy 360 degrees of rotation

8. Sensor Reset

If the drone is tilted to one side after the trim setting, or the drone does not fly normally, proceed to reset the sensor. With the drone and the controller connected, place the drone on a flat floor and press and hold the controller reset button to proceed with sensor reset.

Drone during the sensor reset led starts blinking, reset is complete, the brightly lit again.

Troubleshooting

	Problem	Cause	Solution method
1	I plugged in the drone's battery and it just blinks and becomes unresponsive	The drone and the controller are out of pairing	Refer to the manual and cycle power to both the drone and the controller and try new pairing
2	There is no response when connecting the drone's battery	The battery is running low	Please charge the battery of the drone
3	The motor won't stop when I lower the lever to land	I didn't know if the drone was on the floor	Please raise it up again and try to land Lower and hold the throttle lever for at least 2 seconds after the drone hits the floor
4	Only the propeller turns and the drone does not take off	1. the direction of the propeller is wrong 2. the battery is low	1. Fit the propeller in the correct orientation 2. Charge the battery
5	The drone rotates in place even after the trim is set	1. the direction of the propeller is wrong 2. The propeller is damaged 3. Sensor reset is required	1. Refit the propeller correctly 2. Replace the propeller 3. Refer to reset sensor in manual
6	The drone doesn't fly after the crash	I plugged in the drone's battery and it just blinks and becomes unresponsive	1. Refit the propeller 2. Replace the propeller

Initial Defect and Warranty

Supports the following initial defect and warranty exchange policies:

1. Within 7 days of receipt of the new product
2. If problem symptoms are found within 5 minutes of the cumulative flight time after opening the product:

If a problem occurs with a product that meets all of the above conditions, it will be judged to be an initial defect and you will be able to exchange the product.

Any other user negligence and damage other than initial defect will result in paid repair, so please note. Please contact your place of purchase for further product repair and support.

* Drone simulator, Rocket Brick for Cordonrobolinksw.com

* Check the website later for coding manual. (robolink.co.kr)

Robot Education Company

Copyright © 2019 Robolink Co., Ltd.
All Rights Reserved, Made in Korea

CE

RoHS

Autonomous safety

check report number

CB062R276-8001

=6=

=7=

=8=

=9=

codrone MINI

1 Precautions to Know Before Flying a Drone

2 Basic Component Guide
Name by Drone Part

Pilot Guidance
Insert Controller Battery
Connecting Drone
Pilot Main Function Guidance
How to operate a drone (Mode2)

Motor Start/Stop
Emergency stop
Headless Mode

3-5 Change Mode
Rotate 360 degrees (Mode)

Propeller Repacement
To Charge
Guides and caveats for first-time users
Initial Defect and Warranty
Troubleshooting

6-9 Quick Manual for Control

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.