




HIGH SPEED RC MOTORCYCLE
WITH LEANING FUNCTION

THE BLACK SERIES™

Toy RC Motorcycle

radio controlled racing motorcycle

lean machine

BATTERY INSTALLATION

Operation requires 5 "AA" 1.5V batteries (not included) for motorcycle, and one 9V battery (not included) for radio controller.

- After removing your motorcycle from the box, you must remove the paper tray. Uncover the fastener underneath the motorcycle to remove from the tray.
- Locate the battery compartment on the underside of the motorcycle, and the radio controller.
- Remove the battery compartment.
- Insert 5 "AA" 1.5V batteries according to the polarity diagram located on the battery tray (Fig. 1).
- Replace the battery compartment and battery cover.
- Slide open the battery compartment door of the controller (Fig. 2).
- Insert the one 9V battery following the correct polarity.
- Replace the screw/battery compartment door securely before operating.

Fig.1
FRONT
BACK

Fig.2
FRONT
BACK

REMOVING BATTERY DOOR TO INSERT BATTERIES

REQUIRES 5 "AA" 1.5V BATTERIES
1) Insert the first 4 at the bottom first.
2) attach the tray on top.
3) Insert the remaining 2 batteries.

BASIC OPERATION

- Switch the controller power switch to the "ON" position.
- Operate the motorcycle according to the controls diagram below.
- For best operation, use on a hard and flat surface.
- To start your motorcycle press the left joystick forward and slightly turn the motorcycle in the opposite direction in which it is resting.

OPERATING CONTROLS

LEFT JOYSTICK
FORWARD & REVERSE

RIGHT JOYSTICK
LEFT & RIGHT

PUSH FUNCTION

OFF/ON SWITCH

RADIO CONTROLLER (USES ONE 9V BATTERY (NOT INCLUDED))

Fig.2

ON/OFF SWITCH IS LOCATED ON FRONT OF CONTROLLER

BATTERY WARNING:

- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon zinc), or rechargeable (nickel-cadmium) batteries.
- Insert batteries using the correct polarity. Do not short-circuit the supply terminal.
- Remove batteries when not in use. Repair or dispose of exhausted batteries according to federal, state, and local laws. Do not dispose of batteries in a fire - they may burn or explode.
- Only use manufacturer specified material. Careful and correct disposal is available, specified by the manufacturer.
- Always use, replace, and recharge if applicable batteries under adult supervision.

SAFETY WARNINGS - PLEASE READ BEFORE USING PRODUCT

- Not recommended for children under 6 years of age. As with all electrical products, precautions should be observed during handling and use to reduce the risk of electrical shock.
- It is recommended that this toy and all accessories be periodically examined for potential hazards and that any potentially hazardous parts be repaired or replaced.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to take one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

WARNING: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

2905058 (35003)

6 942025141111

Made in China

©2015 Mattel/Hasbro, LLC. DMS. The Black Series, The Black Series by Shift, and all associated logos are trademarks of Mattel/Hasbro, LLC. All rights reserved. Operated by Mattel/Hasbro, LLC, Irvine, CA 92618. Operated by Shift, LLC, Irvine, CA 92618. For technical support, please visit www.mattelhasbro.com or call 1-800-374-2744. The artwork and design of this package are protected by copyright law and are the property of Mattel/Hasbro, LLC. All rights reserved. Reproduction, distribution, display, publication or use for any purpose without prior written permission is prohibited. It is not permitted to alter, remove or reproduce any trademarks or copyright notice from this package.

lean machine



STANDS UP ON ITS OWN!



by shift®

THE BLACK SERIES™

THE BLACK SERIES™

radio controlled racing motorcycle

lean machine

High speed RC motorcycle with leaning function



High performance rubber grip tires



multi-directional operation



Motorcycle weighs 1.8 lbs. (0.8 kg). 1.5V batteries not included. RC controller requires one 9V battery (not included). See bottom panel for additional information. Colors and styles may vary.

EXCITING

HIGH SPEED RC MOTORCYCLE
WITH LEANING FUNCTION

COMPETITIVE

AVAILABLE IN 2 FREQUENCIES
FOR TWO PERSON PLAY

WIRELESS

REMOTE CONTROL FOR FULLY
FUNCTIONAL RACING ACTION

45°

LEANING
ACTION



45°

LEANING
ACTION



THE BLACK SERIES™

radio controlled racing motorcycle

lean machine

by shift®



WARNING!

CHOKING HAZARD - Small parts. Not suitable for children under 3 years.

BATTERY OPERATED PLAY VEHICLE

AGES 6 AND UP



BOX CONTAINS THE FOLLOWING FREQUENCIES:

