

EXMITTER



EX2

ADVANCED FHSS RADIO CONTROL SYSTEM

EXMITTER -- Professional Remote Control Products Expert

NOTICE

All instructions, warranties and other collateral documents are subject to change at the sole discretion of VolantexRC Co., Ltd.. Visit www.volantexrc.com for up-to-date product literature.

WARNING

The following terms are used throughout the product literature to indicate various levels of potential harm when operating this product.

CAUTION: Procedures, which if not be properly followed, is able to create a possibility of physical property damage AND or possibility of injury.



Read the **ENTIRE** instruction manual to become familiar with the features of the product before operating. Fail to operate the product correctly can result in damage to the product, personal property and cause serious injury.



This is a sophisticated hobby product and **NOT a toy**. It must be operated with caution and common sense and requires some basic mechanical ability. Fail to operate this Product in a safe and responsible manner could result in injury or damage to the product or other property. This product is not intended for use by children without direct adult supervision. Do not attempt to disassemble , use with incompatible components or augment product in any way without the approval of VolantexRC Co., Ltd.. This manual contains instructions for safety, operation and maintenance. It is essential to read and follow all the instructions and warnings in the manual, prior to assembly, setup or use, in order to operate correctly and avoid damage or serious injury.


Age Recommendation:

Not for Children under 14 years. This is not a toy.


SAFETY PRECAUTIONS

- Always ensure all batteries have been properly charged prior to using the model.
- Always check all servos and their connections prior to each run.
- Never operate your model near spectators, parking areas or any other area that could result in injury to people or damage of property.
- Never operate your model during adverse weather conditions. Poor visibility can cause disorientation and loss of control of your model.
- Never point the transmitter antenna directly toward the model. The radiation pattern from the tip of the antenna is inherently low.
- If at any time during the operation of your model you observe any erratic or abnormal operation, immediately stop operation of your model until the cause of the problem has been ascertained and corrected.


TRANSMITTER DETAILS



ON / OFF Switch





BATTERY LED MONITOR



7:3 / 5:5 Switch Instruction


Adjust the proportion of throttle signal on either side of the center trigger position. You can pick which proportion of forward/reverse you prefer. We **recommend** using the 7:3 position for most applications.



SERVO REVERSING SWITCHES

If the direction of travel on the rudder is backwards, slide the steering reverse switch to the other position.


It is Same principle for the throttle reverse switch.



STEERING RATE KNOB


Rotating the knob clockwise will give you greater range in rudder movement.

Counter-clockwise will reduce the range of rudder movement. Adjust to suit your driving style and preferences.




Throttle TRIM

The throttle trim dial is used to adjust the throttle trim when the throttle stick is released (neutral position). This is typically used to adjust the brakes. Rotating the dial causes the throttle trim (the throttle position at rest) to be changed.





STEERING TRIM

The steering trim dial is used to adjust the steering trim when the wheel is centered. Rotating the dial changes the steering trim (the steering at rest position). Normally, the steering trim is adjusted until the vehicle tracks straight.



INSTALL YOUR RECEIVER




Install the Receiver in your vehicle using double-sided Velcro. Velcro will hold the receiver in place and help isolate it from vibrations. Mount the antenna up and away from the vehicle in an antenna tube. The higher up the antenna is, the better signal it will receive.




CAUTION: Do not cut the antenna.

RECEIVER CONNECTION



BINDING



Binding is the process of programming the receiver to recognize the GUID (Globally Unique Identifier) code of a single specific transmitter. When a receiver is bound to a transmitter, the receiver will only respond to that specific transmitter. If you need to rebind for any reason, please follow these steps:

1. With the transmitter switched OFF
2. Insert the bind cable to bind channel slot.
3. Power on the receiver, then turn on the transmitter with pressing on the bind button within 5 seconds after receiver is power on.
4. Loose the bind button and wait for about 5 seconds.
5. After the receiver stop blinking, it means the binding is finished
6. Unplug the bind cable and then you are ready to run.




CAUTION: DO NOT leave the bind cable in the bind channel plug after binding finished, otherwise the binding program will work automatically each time when you power on the receiver.

FAILSAFE Setting


The EX2 comes with the receiver failsafe set to NONE. In the event of loss of signal the motor will stop and the vehicle will drift. If the signal is regained normal function will return. If you wish to program the failsafe to a custom setting just follow these simple steps:

1. With both the transmitter and receiver powered ON, press the bind button on the receiver for about 3 seconds.
2. The receiver will enter the failsafe setting menu and the receiver LED will flash.
3. You have about 3 seconds to move the controls to the position that you wish to program into failsafe.
4. After the 3 seconds the receiver will save the settings and return to normal mode.
5. If you wish to reset to a different setting, simply repeat the above steps.


HOW TO OPERATE YOUR VEHICLE




Push the trigger slightly away from you to arm the motor



Pull the trigger towards you to make the vehicle go forward.




The proportional speed control means the farther you pull it the faster the vehicle will go. Release the trigger to stop.




When you upgrade to brushless speed control with the reverse function, pushing the throttle trigger forward will make the motor run in reverse and back the vehicle up.

Rotate the steering wheel clockwise while holding the trigger to turn right. If the steering is not tight enough, increase the travel volume by rotating the travel rate knob clockwise till you reach the desired amount.



Rotate the steering wheel counter-clockwise while holding the trigger to turn right. If the steering is not tight enough, increase the travel volume by rotating the travel rate knob clockwise till you reach the desired amount.



Caution: The user is cautioned that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CE0890

Company Name: VOLANTEXRC CO., LTD. Add: 2nd Building Fuxi Dongqiao Industrial Park,

Shanzhang Road Shantou, China

Product Name: RADIO CONTROL PRODUCT Item No: V792