



User Guide

Manual

SOUNDBAR WITH WIRELESS SUBWOOFER



Remote Control



- 1 POWER:** Switch the unit between on and standby mode.
- 2 SOURCE:** Select the play function.
- 3 VOL+ / VOL-:** Increase/decrease the volume level.
- 4 ⏮ / ⏭:** In *Bluetooth*® mode, skip to the previous/next audio file.
- 5 ▶⏮:** In *Bluetooth*® mode, start or pause playback.
- 6 PAIR:** In *Bluetooth*® mode, activate the pairing function and disconnect the existing paired *Bluetooth*® device.
- 7 MUTE:** Mute or resume the sound.
- 8 EQ:** Select a preset sound effect.


Remote Control (Cont.)

Remote Control Battery

The remote control comes with a CR2025 3V button cell battery pre-installed.



First Time Use

- To activate the battery and use the remote control, pull out the plastic tab that separates the battery from the contacts inside the compartment.



Battery Replacement

- If the remote control unit is no longer working even when it is operated near the soundbar, you will need to replace the battery with a new battery of the same type.
- Push in the tab and pull out the battery tray. Remove the old battery.
- Insert a fresh CR2025 battery with the (+) marking facing upwards. Then push the battery tray with the battery back into the slot.



DANGER if swallowed

WARNING!

Keep batteries out of reach of children. Swallowing may lead to serious injury or death in as little as 2 hours due to internal burns.

If swallowed, go straight to a hospital emergency room.

Dispose of used batteries immediately.

Remote Control (Cont.)


Using the Remote Control

- The remote control has a range of up to 6 metres from the soundbar. Point the remote control directly towards the sensor at the front of the soundbar.
- Make sure no obstacles are blocking its path. The remote control will not operate if its path is blocked.
- Handle the remote control with care. Do not drop, apply shock or step on the remote control. Do not spill water on the unit.
- Do not use the remote control while simultaneously operating a remote control unit of any another unit, which may result in interference.
- If the remote control is operated near other products which generate infra-red rays, or if other remote control devices using infra-red rays are used near the unit, it may operate incorrectly. Conversely, the other products may operate incorrectly.
- If you do not intend to use the remote control for an extended period of time (more than a month), remove the battery to prevent possible damage from battery leakage and corrosion.

Battery Precautions

- Do not use any other battery than the ones specified.
 - Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.
 - Do not carry or store batteries with other metallic objects. Doing so could cause batteries to short-circuit, leak or explode.
 - Do not expose the battery to excessive heat such as sunshine, fire or the like.
 - Do not attempt to short-circuit, disassemble or throw batteries into a fire.
 - Never recharge a battery unless it is confirmed to be a rechargeable type.
 - Dispose of batteries promptly and properly, observing any local hazardous waste regulations. Do not burn or bury them.
-


Product Overview



- 1 **NFC (Near Field Communication) Sensor**
- 2 **Speakers**
- 3 **Power Switch:** Press to switch the unit between on and standby mode.
- 4 **SOURCE:** Select the play function.
- 5 **LED Indicators**
 - Red Indicator: In STANDBY mode.
 - Green Indicator Lights Up: In AUX mode.
 - Green Indicator Flashes: In HDMI ARC mode.
 - Orange Indicator: In OPTICAL mode.
 - Blue Indicator:
 - (Bluetooth® indicator flashing slowly: in Bluetooth® mode.)
 - (Bluetooth® indicator flashing fast: in Bluetooth® pairing mode.)
 - Indicator Flashes: Adjust the volume / select a preset sound effect.
- 6 **VOL+/VOL-:** Increase/decrease the volume level.
- 7 **Remote Control Sensor**
- 8 **Stand**
- 9 **Power Socket**
- 10 **HDMI (ARC) Socket**
- 11 **OPTICAL Socket**
- 12 **AUX Socket:** Connect to an external audio device.
- 13 **USB Charging Port:** 5V $\overline{\text{---}}$ 1A

Controls and Connections

Back Panel Connections



AUX Socket

- A Use the supplied 3.5mm to 3.5mm audio cable to connect the headphone socket of the connected audio device, such as a media player, to the AUX socket on the unit.
- B Use the supplied RCA to 3.5mm audio cable to connect the TV's audio output sockets to the AUX socket on the unit.

Optical Socket

- C Remove the protective cap from the OPTICAL socket, then connect an OPTICAL cable to the TV's OPTICAL OUT socket and the OPTICAL socket on the unit.

TIP: If no sound is coming out of the soundbar and the indicator light flashes fast, make sure the audio setting of your source player (e.g. DVD player, game player, TV) is set to PCM with optical output.

HDMI (ARC) Socket

- D The ARC (Audio Return Channel) function allows you to send audio input from an ARC-compliant TV to an ARC-compliant audio device (e.g. soundbar) without the need for an additional audio cable connection.

To enjoy the ARC function, make sure the soundbar main unit's HDMI OUT socket is connected via HDMI cable to the HDMI (ARC) socket of your ARC-compliant TV. Then just use your TV remote control to adjust the volume output (VOL +/- and MUTE) of the connected audio device.


Controls and Connections (Cont.)

NOTE:

- Your TV must support the HDMI-CEC and ARC, and the HDMI-CEC and ARC must be set to On.
- The setting method of HDMI-CEC and ARC may differ depending on the TV. For details about ARC function, please refer to the TV's instruction manual.
- Make sure the HDMI cable you use can support the ARC function.
- HDMI-CEC will be called different names by different manufacturers. Please refer to your TV's instruction manual for details on setting up HDMI-CEC and ARC.

Power Connection

- Before connecting the power adapter, ensure you have completed all other connections.
- Risk of product damage! Ensure that the power supply voltage corresponds to the voltage printed on the back or the underside of the unit.
- Connect the mains plug to the main unit and a mains socket.

**USB Charging**

Connect a USB cable (not supplied) to the USB charging socket to charge your smartphone or tablet PC.

NOTE:

- The maximum output of the USB charging port is 5V DC 1A. Please refer to your mobile device's manual regarding the charging power.
- This product is suitable for charging mobile devices only.


Controls and Connections (Cont.)

Wireless Subwoofer

PAIR Indicator: Lights up solidly when the pairing is successful.

Pair Button: Connect to the main unit.

Power Socket: Connect to power.



Pairing the Wireless Subwoofer With the Main Unit

Automatic pairing

The subwoofer and soundbar will automatically pair when both units are plugged into the mains sockets and turned on. No cable is needed for connecting the two units.

- When the subwoofer is pairing with the main unit, the Pair Indicator will flash fast.
- When the subwoofer is paired with the main unit, the Pair Indicator will light up.

NOTE:

- Do not press the Pair button on the rear of the subwoofer, except for manual pairing.
- If the automatic pairing fails, pair the subwoofer with the main unit manually.

Manual Pairing


1. Ensure that all the cables are well connected and the main unit is in Standby mode.
2. Press the (power icon) button on the main unit or on the remote control to switch the main unit on and go to AUX mode.
3. Press and hold the Pair button on the rear of the subwoofer for a few seconds. The subwoofer will enter the pairing mode and the Pair Indicator will blink quickly. At the same time, press and hold the pair button on the remote control.
4. After the wireless connection succeeded, the Pair Indicator will light up.
5. If the Pair indicator blinks, the wireless connection has failed. Unplug the cable of the subwoofer and then reconnect the main cable after 3 minutes. Repeat step 1 ~ 4.

NOTE:


- If the wireless connection fails again, check if there is conflict or strong interference (for example, interference from an electronic device) around your location. Remove these conflicts or strong interferences and repeat the above procedures.
 - The subwoofer should be within 6m of the soundbar in an open area.
 - If a TV or an external device is connected, the main unit and the subwoofer will switch on automatically when the TV or the external device is switched on.
 - If the main unit is not connected with the subwoofer and it is in On mode, the POWER Indicator will flash. Follow step 1 ~ 4 above to pair the subwoofer to the main unit.
-

Installation


This soundbar unit can be used either as a single soundbar or as 2-piece tube speakers. Installation options include:



Option A:
Two tube speakers
installed on stands




Option B:
Single soundbar mounted
horizontally with rubber feet



Option C:
Single soundbar
wall-mounted

Stand Mounting (if using option A)


Attach one stand each to the two separate pieces and twist to secure, as illustrated below.



Installation (Cont.)

Horizontal Mounting


Align the two separate pieces and twist to secure, as illustrated below.



Rubber Feet Installation (if using option B)

You can extend the height of the unit, if required. To do so, attach the supplied rubber feet as follows.


- Ensure the surface of the soundbar is clean prior to attaching the rubber feet.
- Turn the unit upside down.
- Remove the backing paper from the rubber feet.
- Stick the rubber feet to the bottom of the unit, as illustrated below.



Installation (Cont.)

Wall Mounting (if using option C)

- **Wall-mounted installation must be carried out by qualified personnel only. Incorrect assembly can result in severe personal injury and property damage!** (If you intend to install this product yourself, you must check for installations such as electrical wiring and plumbing, which may be hidden inside or behind the wall.)
- **It is the installer's responsibility to verify and confirm that the wall will safely support the total load of the unit and wall brackets.**
- Additional tools (not included) are required for the installation.
- Do not overtighten screws.
- Use an electronic stud finder to check the wall type before drilling and mounting.



Instructions

General Operation

Standby/ON

- When you first connect the main unit to the mains socket, the main unit will be in Standby mode.
- Press the **POWER**  button on the unit or on the remote control to switch the unit ON.
- Press the **POWER**  button again to switch the unit back to Standby mode. The power indicator will light up red.
- Disconnect the mains plug from the mains socket if you want to switch the unit OFF completely.
- When there is no input signal (or weak input signal) in HDMI, AUX, Optical and *Bluetooth*® mode (Stop or Pause) for more than 15 minutes, the unit will automatically switch to Standby mode.

Mode Selection

Press the **SOURCE** button repeatedly on the unit or the button on the remote control to switch between HDMI (ARC), AUX, Optical and *Bluetooth*® modes.

- In AUX mode: the status indicator lights up green.
- In HDMI (ARC) mode: the green status indicator flashes.
- In Optical mode: the status indicator lights up orange.
- In *Bluetooth*® mode: the status indicator lights up blue.

Volume Adjustment

- Press the **VOL+ / VOL-** buttons on the unit or on the remote control to adjust the volume.
- If you wish to turn the sound off, press the **MUTE** button on the remote control. Press this button again or press the **VOL+ / VOL-** buttons to resume normal listening.
- While adjusting the volume, the status indicator flashes quickly.
- When the volume level reaches its maximum level, if you press the **VOL+** button again, the status indicator flashes once. When the volume level reaches its minimum level, if you press the **VOL-** button again, the status indicator flashes once.

Preset Sound Effect Selection

- Press the **EQ** button on the remote control to select between preset equalisers: Movie (recommended for viewing movies), Music (recommended for listening to music).
 - Music EQ: the status indicator will flash twice.
 - Movie EQ: the status indicator will flash four times.
-

Instructions (Cont.)

HDMI (ARC) / AUX / Optical Operation

- Ensure that the unit is connected to a TV or audio device.
- While in ON mode, press the **SOURCE** button repeatedly on the unit or on the remote control to select HDMI (ARC), AUX or Optical mode.
- Operate your audio device directly for playback features.
- Press the **VOL +/-** button to adjust the volume to your desired level.

Playing *Bluetooth*® Enabled Devices

You can listen to tracks from a media device if connected to the unit via *Bluetooth*® Wireless Technology.

Pairing *Bluetooth*® Enabled Devices

The first time you connect your *Bluetooth*® device to this player, you need to pair your device to this player.

1. During ON mode, press the **SOURCE** button repeatedly on the unit or the remote control to select *Bluetooth*® mode. The blue indicator will flash slowly, indicating that the system has entered pairing mode.
2. Alternatively, press the **PAIR** button on the remote control to be searchable. The blue indicator will flash fast.
3. Activate your *Bluetooth*® enabled device and select the search mode. "BAUHN SB-1" will appear on your *Bluetooth*® device list.
4. Select "BAUHN SB-1" in the pairing list. The blue indicator will light up solidly if pairing succeeds.
5. To disconnect the *Bluetooth*® function, switch to another function on the unit or disable the function from your *Bluetooth*® enabled device. The blue indicator will flash slowly.

Important Notes

- The operational range between this player and a *Bluetooth*® device is approximately 8m (without any object between the *Bluetooth*® enabled device and the unit). Any obstacle between the devices can reduce the operational range.
 - Before you connect a *Bluetooth*® enabled device to this unit, ensure you know the device's capabilities. Compatibility with all *Bluetooth*® devices is not guaranteed.
 - If the signal strength is weak, your *Bluetooth*® receiver may disconnect, but it will re-enter pairing mode automatically.
-

Instructions (Cont.)

TIPS

- If you are prompted for a password, enter "0000".
- If there is an existing connection, press the **PAIR** button on the remote control to re-activate the pairing mode, the connection will be interrupted. The blue indicator will flash slowly.
- If no other *Bluetooth*® device pairs with this player within two minutes, the player will recover its previous connection.
- The player will also be disconnected when your device is moved beyond the operational range.
- If you want to reconnect your device to this player, place it within the operational range.
- If the device is moved beyond the operational range, when it is brought back, please check if the device is still connected to the player.
- If the connection is lost, follow the instructions above to pair your device to the player again.

Music Playback From *Bluetooth*® Enabled Devices


1. Pair and connect your *Bluetooth*® enabled device with the soundbar.
2. Play audio on your *Bluetooth*® enabled device.
3. Use the remote control to control playback.

Instructions (Cont.)

NFC (Near Field Communication) Operation

Pair your NFC enabled mobile device directly with this unit with just a single tap.

1. Activate NFC on your mobile device.
2. Tap the mobile device's NFC antenna area on the  icon of the unit.
3. Confirm the *Bluetooth*® connection.
4. To disconnect, tap the mobile device on the  icon of the unit to disconnect or disable NFC from your mobile device.



NOTE: This NFC function only works with mobile devices that support NFC technology.

TIPS:

Some NFC enabled mobile devices cannot pair directly with the unit via NFC. In such a case, please try either one of the solutions below:

- Please download the App "Tap-and- Pair" from Google Play Store (<https://play.google.com>) and install.
 - Pair with the unit manually first, then touch again on the NFC sensing area.
-

Other Useful Information

Troubleshooting

To keep the warranty valid, never try to repair the system yourself. If you encounter problems when using this unit, check the following points before requesting service.

Problem	Solution
No power	Ensure that the power cord of the apparatus is properly connected.
	Ensure that there is power at the outlet.
	Press the POWER ⏻ button to turn the unit on.
Remote control does not work	Reduce the distance between the remote control and the unit.
	Insert the battery with its polarities (+/-) aligned as indicated. Please check the battery is installed correctly (refer to page 7).
	Replace the battery.
	Aim the remote control directly at the sensor on the front of the unit.
No response from the unit	Disconnect and reconnect the power adapter, then turn the unit on again.
Unable to find the soundbar in the <i>Bluetooth</i> ® device list when pairing	Ensure you have paired the unit with your <i>Bluetooth</i> ® enabled device.
	Ensure the <i>Bluetooth</i> ® function is activated on your <i>Bluetooth</i> ® enabled device.
No connection between the main unit and the Subwoofer	Ensure the main cables of the main unit and the subwoofer are both connected securely to the mains power socket.
	pair the main unit with the subwoofer manually. Please refer to "Pairing the Wireless Subwoofer with the Main Unit" above.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

- NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

- However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
-