



USER GUIDE

YUNEEK®

INDEX

01		INDEX
02		INTRODUCTION
03		OVERVIEW
08		CHARGE SETUP
09		SYNCING CONTROLLER AND BOARD
10		FEATURES
11		SPECIFICATIONS
12		SAFETY WARNINGS AND TIPS
16		TROUBLESHOOTING
19		SPARE PARTS
20		GARAGE
22		INSTALLATION GUIDE
24		CERTIFICATION INFORMATION

INTRODUCTION


Congratulations, you have purchased an E-GO 2 . You are now the owner of a portable, eco-friendly mode of transport that is incredibly fun to use. Integrating state of the art motor technology developed by YUNEEC for use in the aviation industry, E-GO 2 brings to the streets an experience and convenience that was never available in the past.

Setting aside dated conventions, E-GO 2 focuses on what is essential to the design of a sustainable transport unit that functions in todays urban areas. Combining high performance with low consumption, the E-GO 2 CRUISER allows you to travel up to 30Km / 18Mi on one full charge. Its lightweight design and compact dimensions make the E-GO 2 the perfect wingman wherever you go: simply pick up your board and step into a taxi, bus, train, or indoor location.

Boarding is often linked to extreme sports activities like surfing, skating, or snowboarding and there are definitely similarities in the amount of freedom experienced when moving through space. However, E-GO 2 is foremost a city transport unit and distinguishes itself as such through features such as its advanced braking system, giving the rider more control over his / her vehicle which is required to ensure the safety of other people as well as his / her own.

Keeping the latter in mind, we would like to suggest you read through this users manual, to ensure you understand fully how to properly set-up and use your E-GO 2 and what general common sense to apply when riding in a public area. The general rule to follow: Ride with consideration and style. We hope you enjoy your E-GO 2 experience!

OVERVIEW




THE DECK

The E-GO 2 features a 12 mm, eight layered composite wood deck, making it flexible, durable and strong: all the qualities a rider looks for in a board. The deck surface is finished with griptape to avoid slipping.

THE BATTERY

E-GO 2 's sleek, low profile multi-cell battery pack is located under the deck, and utilises Yuneec's latest, patented battery technology. Its' flexible battery casing allows the deck to bend while riding.

- 1. charge port
- 2. power switch
- 3. power status indicator
- 4. USB port
- 5. 2.4GHz / bluetooth switch
- 6. Electronic Control Unit (ECU)





THE MOTOR

By integrating technology developed by Yuneec for use in the aviation industry, the brushless 400 watt motor provides reliable and efficient power for your E-GO 2 .

THE WHEELS

The E-GO 2 's 90mm wheels provide traction and stability on an array of surfaces, turning the E-GO 2 into a reliable urban transport system.



THE TRUCKS

Connecting the wheels to the deck are two alloy trucks made of the highest grade materials available. The trucks can be adjusted using the truck tool.

(For more on the truck tool see page 7)

THE CONTROLLER

The EB24C is the smart controller of E-GO2, a key feature of the E-GO 2 is without doubt its sleek, pocket-sized, wireless controller which allows you to intuitively control its movements by simply sliding the throttle / brake (7) up and down.




The battery status indicator's light (9) indicates the wireless controller's and board's battery status:

Green light indicates the board's battery status. Blue light indicates the controller's battery status. Each light blinks 1,2,3 or 4 times in series. Each blink indicates 25% of the total battery capacity.

When the board or controllers battery goes under 25% of its maximum capacity, the controller vibrates, its light will turn red and blink 1 time. When charging - with the controller connected to the board - a red light indicates that the controller's battery charge is less 100%.

Example: (when activated but not charging) the board's battery is completely empty and the controller's battery has less than 75% of its full charge capacity left 1 red blink will be followed by 2 blue blinks.


(For more information on the yellow and purple warning lights, reference troubleshoot page 19)




THE TRUCK TOOL

To keep your E-GO 2 's performance up to maximum you will need to do regular maintenance checks (for more info on maintenance please check page 17), making sure the board is not obstructed by dirt and all nuts and bolts are properly tightened. To tighten and loosen these nuts and bolts, your E-GO 2 comes with a specific tool - the truck tool - that allows you to do that. In general you should make sure all parts are screwed on there nice and tight, with the exception of the kingpin nut which can be adjusted according to your personal riding style.

- 6. START button
- 7. throttle / brake
- 8. flash light
- 9. battery status indicator*
- 10. riding mode switch
- 11. speed mode switch
- 12. torch light switch
- 13. mini USB port



Tightening the kingpin will give a more stable, rigid ride. Loosening the kingpin nut will make the board more maneuverable and decreases the diameter of your turn radius, allowing sharper turns.




THE USB

Use the USB to connect the wireless controller to the board's USB port, to any computer or any other USB port for recharging purposes.

THE CHARGER

The E-GO 2 charger allows you to fully recharge the E-GO 2 and the controller's battery in 3 to 5 hours (depending on charge left and ambient temperature) giving you a maximum riding range of 30 km / 18 miles (depending on weight, road conditions, riding style, etc...).



charge status indicator*

Charge lead depending on sales area




THE PIN TOOL

Also included with the E-GO 2 is a small pin-shaped object, which allows you to access the speed mode switch on the controller and the bluetooth switch on the board.

*red = charging / green = charged

CHARGE SETUP




The board needs to be powered on in order to charge the wireless controller through the usb port.


Charge lead depending on sales area

To ensure a healthy battery life, recharge the battery for 6 hours straight before first use. This will condition the battery and give better long term performance.


SYNCING CONTROLLER AND BOARD




Use the pin tool (page 8) to slide the speed switch (positioned on the left side of the controller) fully down.




Slide down the riding mode switch (positioned on the left side of the wireless controller) to 'ECO' mode.



Make sure the 'BLUETOOTH' switch (ill. 4) is switched to the side closest to the motor, then turn on the board by switching the power switch on. The board should now beep two times and its battery status indicator should be flashing fast.



Begin with the 'BLUETOOTH' switch flipped toward the right (closest to the motor). Immediately after powering the board ON, move the 'BLUETOOTH' switch to the left (furthest away from the motor) and back to the right (closest to the motor). Then the battery status indicator should go from flashing fast to flashing more slowly.



Slide down the wireless controller's throttle / brake to the lowest possible position, and hold it there. At the same time, press and release the start button while the throttle/brake is still held down. After 7 seconds, the controller will show 8 green flashes, followed by blue flashes. At this point release the throttle / brake. The board should now beep again, indicating a successful synchronization.

FEATURES



THE E-GO 2 FEATURES 2 SPEED MODES: A SLOW MODE OR BEGINNER MODE - WITH A LIMITED SPEED OF 13 KM/H OR 8 MPH), AND A FAST MODE - WITH A MAXIMUM SPEED OF 20 KM/H OR 12.5 MPH.



THE E-GO 2 ALSO FEATURES 2 RIDING MODES: THE ECO MODE - WITH A LOWER ACCELERATION CURVE - AND THE SPORT MODE - WITH A HIGHER ACCELERATION CURVE. RIDING IN ECO MODE WILL DEMAND LESS POWER FROM THE BATTERY THUS MAXIMIZING THE EGO'S RANGE.



THE E-GO 2 WILL TAKE YOU UP INCLINES OF UP TO 10% FOR A LIMITED DISTANCE. VARIABLES LIKE WEIGHT OF RIDER, INCLINE, AMBIENT TEMPERATURE AND ROAD SURFACE MAY CAUSE THE ECU TO OVERHEAT AND PERFORM A TEMPORARY CONTROLLED SHUTDOWN.



TO FULLY CHARGE THE E-GO 2 'S BATTERY, A CHARGE TIME OF 3 TO 5 HOURS FROM A STANDARD A/C POWER SOURCE IS NEEDED. TO FULLY CHARGE THE WIRELESS CONTROLLER A CHARGE TIME OF ABOUT 50 MINUTES FROM ANY USB PORT IS NEEDED.



THE E-GO 2 FEATURES A REGENERATIVE BRAKING SYSTEM (RBS) THAT RECYCLES POWER USED WHEN BRAKING TO RECHARGE THE BATTERY. BE AWARE THAT RBS STOPPING PERFORMANCE VARIES DEPENDING ON RIDER WEIGHT AND CONDITIONS.



AT JUST 6.3 KG / 13.9 LBS, THE E-GO 2 IS LIGHTWEIGHT AND PORTABLE WHICH WORKS IN COMBINATION WITH AN ARRAY OF PUBLIC TRANSPORTATION.

PERFORMANCE

Max. User Weight: 100kg / 220bs
Max. Range: 18mi / 30km
High Speed Mode Max.: 12.5mph / 20km/h
Low Speed Mode Max.: 8mph / 13km/h

CHARGER

Input: AC 100-240V / 50-60HZ / 1.5A Max.
Output: 29.5V / 2A
Charge Indicator: Red when charging /
Green when charged


CONTROLLER

Material: ABS Plastic
Dimensions: 125*41*33mm
Weight: 60g
Battery Type: Lithium
Battery Capacity: 240mAH
Battery Charging Time: 50 minutes
Wireless Connection: 2.4GHz
Vibration: Yes

BOARD

Deck Material: Canadian Maple Wood
Deck Dimensions: 910*240mm
Wheel Material: Polyurethane
Wheel Size: 90mm diameter / 52mm width
Battery Type: Li-ion
Battery Capacity: 7.8 AH
Battery Cell Quantity: 21 pcs
Battery Charging Time: 3-5 hours (depending on ambient temperature)
Motor Type: Brushless Direct Current
Motor Power: Max. 400W / Ave Power 150W
Transmission Model: Synchronous Belt Drive
Board Weight: 13.9lbs / 6.3kg

SPECIFICATIONS



SAFETY WARNINGS AND TIPS

ABOUT THE SAFETY GUIDELINES

BEFORE RIDING THE E-GO 2 , IT IS STRONGLY ADVISED TO READ THROUGH AND FOLLOW ALL TIPS, INSTRUCTIONS AND WARNINGS LISTED UNDERNEATH. THIS CAN REDUCE THE RISKS THAT COMES WITH USING A PERSONAL ELECTRONIC TRANSPORTER (PET) // IT SHOULD BE CLEAR THAT READING THIS MANUAL WILL ONLY REDUCE AND NOT ELIMINATE THE RISK INHERENT TO USING A PERSONAL ELECTRIC TRANSPORT (PET) // IF YOU EXCEED THE ABILITY OF YOURSELF OR YOUR E-GO 2 BY RIDING OVER OBSTACLES OR ANY OTHER UNSUITABLE SURFACES, THIS MIGHT POTENTIALLY LEAD TO COLLISIONS OR FALLS IN TURN LEADING TO SERIOUS OR FATAL INJURY, OR THE DAMAGING OF YOUR E-GO 2

NEW RIDERS

FIRST TIME USING AN E-GO 2 ? START BY RIDING IN THE LOW SPEED MODE // INEXPERIENCED RIDERS ARE BEST TO FIRST PRACTICE IN A SPACIOUS, NON TRAFFIC ZONE // INEXPERIENCED RIDERS SHOULD BE ASSISTED BY A MORE EXPERIENCED RIDER // DO NOT LET NEW RIDERS OPERATE THE E-GO 2 OUTSIDE OF YOUR SUPERVISION UNLESS THEY HAVE READ THIS GUIDE // YOU SHOULD NOT ALLOW ANYONE TO STEP ONTO YOUR E-GO 2 FOR THE FIRST TIME UNLESS YOU ARE THERE TO SUPPORT THEM // ASSIST NEW RIDERS UNTIL THEY ARE COMFORTABLE WITH THE BASIC OPERATION OF THE E-GO 2

RIDER PROFILE

THE E-GO 2 IS DESIGNED FOR HUMAN RIDERS // THE E-GO 2 IS DESIGNED FOR RIDERS 14 YEARS AND OLDER // THE E-GO 2 IS DESIGNED FOR RIDERS WITH A BODY WEIGHT UNDER 100 KG / 220 LBS // THE E-GO 2 IS NOT DESIGNED FOR CARGO TRANSPORTATIONS // THE E-GO 2 IS DESIGNED FOR RIDERS IN GOOD PHYSICAL HEALTH // DO NOT RIDE THE E-GO 2 WHEN SICK // AS WITH ANY OTHER PERSONAL ELECTRIC TRANSPORTATION DEVICE, YOU MUST BE MENTALLY ALERT TO SAFELY RIDE AN E-GO 2 // THE E-GO 2 IS NOT DESIGNED FOR TANDEM USE, DO NOT TAKE ANY PASSENGERS WITH YOU ON THE E-GO 2 // DO NOT TAKE A CHILD IN YOUR ARMS OR IN A CHILD CARRIER WHILE RIDING // DO NOT RIDE UNDER THE INFLUENCE OF DRUGS OR ALCOHOL // DO NOT ATTEMPT TO RIDE IF YOU CAN NOT COMPLY FULLY WITH THE INSTRUCTIONS AND WARNING IN THIS GUIDE

RIDER TIPS

WHILE RIDING KEEP YOUR BACK STRAIGHT AND USE YOUR ARMS TO MAINTAIN BALANCE // BENDING YOUR KNEES LOWERS YOUR BODY'S CENTER OF GRAVITY WHICH INCREASES STABILITY // SHIFT YOUR BODY WEIGHT TO THE FRONT WHEN ACCELERATING // SHIFT YOUR BODY WEIGHT TO THE BACK WHEN BRAKING // TO TURN / CARVE, DISPLACE YOUR BODY WEIGHT AND EXERT PRESSURE ON THE HEEL AND TOE SIDES OF THE BOARD // YOUR TURNING RADIUS DEPENDS ON THE AMOUNT OF PRESSURE YOU EXERT ON THE SIDE OF THE BOARD: MORE PRESSURE MEANS SHARPER TURNING // CARVING WILL SLOW DOWN YOUR SPEED AND MAKES FOR AN ENERGY EFFICIENT WAY OF BRAKING // BE MINDFUL WHEN TURNING / CARVING AT HIGH SPEED // YOU CAN ADJUST MANEUVERABILITY BY TIGHTENING OR LOOSENING THE KINGPIN NUTS // ADJUST YOUR RIDING STYLE WHEN RIDING AT NIGHT OR IN CONDITIONS WITH LOW VISIBILITY // ADAPT YOUR SPEED TO YOUR RIDING SKILL AND ENVIRONMENT // DO NOT RIDE WHEN INTOXICATED // BEWARE THAT WET, FROZEN, OILY OR UNPAVED SURFACES ARE UNSUITED FOR RIDING ON // BEWARE THAT BRAKING DISTANCES VARY ACCORDING TO SURFACE TEXTURE, HUMIDITY, TEMPERATURE, ETC... // AVOID RIDING OVER GUTTERS, THIS MIGHT DAMAGE THE BOARD // DO NOT EXPOSE E-GO 2 TO WATER: DO NOT RIDE WHEN RAINING, DO NOT RIDE THROUGH PUDDLES // ALWAYS WEAR PROTECTIVE GEAR WHEN RIDING // ALWAYS WEAR A HELMET WHEN RIDING // USE AN APPROVED SKATEBOARD, BICYCLE OR FULL FACE MOTORCYCLE HELMET THAT PROPERLY FITS WITH THE CHIN STRAP SECURELY FASTENED // USE DIRECT HAND CONTACT WHEN OPERATING THE HANDHELD REMOTE, WEARING GLOVES OR AN UNUSUAL GRIP MIGHT INTERFERE WITH YOUR ABILITY TO ACCURATELY USE THE CONTROLS // DO NOT WEAR LOOSE CLOTHING THAT CAN GET STUCK IN THE WHEELS OR DRIVE BELT // BE AWARE THAT A STRONG ELECTROMAGNETIC FIELD IN YOUR AREA MIGHT INTERFERE WITH THE FUNCTION OF THE REMOTE CONTROLLER // BRAKE WHEN GOING DOWNHILL TO MODERATE YOUR SPEED // TAKING ON INCLINES OVER 10% MIGHT OVERHEAT THE ECU AND CAUSE INTERMITTENT POWER LOSS OR EVEN SHUT DOWN THE ECU // DO NOT RIDE E-GO 2 DOWNHILL MORE THAN 2% TO AVOID ECU OVERHEATING // REGULAR SHORT BURST OF FULL POWER AND BRAKING HEAVILY WILL DRAIN THE BATTERY FASTER THAN RIDING AT A MODERATE CONSISTENT SPEED // BEWARE OF WHEEL STOPS THAT CAN OCCUR WHEN THE E-GO 2 'S WHEELS ENCOUNTER AN OBSTACLE OR TERRAIN CHANGE THAT PREVENT THEM FROM MOVING, THIS WILL BRING THE E-GO 2 TO AN ABRUPT STOP AND ARE LIKELY TO CAUSE A FALL // NEVER RIDE ON STAIRS, ELEVATORS OR THROUGH REVOLVING DOORS // DO NOT ATTEMPT JUMPS OR OTHER STUNTS, THIS MIGHT LEAD TO INJURY OR DEATH AND MIGHT DAMAGE YOUR E-GO 2 // ALWAYS BE ALERT AND AWARE OF YOUR SURROUNDINGS WHEN RIDING

RIDING OUTSIDE OF YOUR PRIVATE PROPERTY

ABIDE BY THE LAWS AND REGULATIONS IN YOUR STATE OR COUNTRY // RESPECT OTHER DRIVERS AND PEDESTRIANS ON THE ROAD // AVOID RIDING ON BUSY ROADS AND CROWDED AREAS // ADJUST YOUR SPEED WHEN RIDING ON THE SIDEWALK // DO NOT PARK YOUR E-GO 2 IN A WAY THAT BLOCKS PEOPLE OR TRAFFIC AS IT CREATES A SAFETY HAZARD // CROSS ROADS AT DESIGNATED CROSSWALKS OR SIGNALLED INTERSECTIONS // DO NOT JAYWALK / RIDE // WHEN RIDING WITH OTHER E-GO 2 RIDERS YOU SHOULD KEEP A SAFE DISTANCE FROM EACH OTHER AND OTHER TRANSPORT DEVICES // WHEN RIDING WITH OTHER E-GO 2 RIDERS YOU SHOULD NOT RIDE SIDE-BY-SIDE UNLESS THERE IS PLENTY OF ROOM LEFT FOR PEDESTRIANS AND OTHER POTENTIAL TRAFFIC // IDENTIFY AND KEEP A SAFE DISTANCE FROM HAZARDS AND OBSTACLES ON THE ROAD // DO NOT RIDE YOUR E-GO 2 ON PRIVATE PROPERTY (INSIDE OR OUTSIDE) UNLESS YOU HAVE OBTAINED PERMISSION TO DO SO // MAINTAIN CONTROL OF YOUR EQUIPMENT

STORAGE AND MAINTENANCE

DO FREQUENT MAINTENANCE CHECKS: BEFORE RIDING MAKE SURE ALL SCREWS ARE TIGHT AND YOUR E-GO 2 IS IN PERFECT WORKING ORDER // CLEAN THE BOARD'S BEARINGS REGULARLY // TO CLEAN THE WHEELS IT IS ADVISED TO REMOVE THEM FROM THE AXLE // TURN OFF E-GO 2 AND WIRELESS CONTROLLER WHEN NOT IN USE // CHOOSE A COOL ENVIRONMENT FOR STORING THE E-GO 2 AND ITS CHARGER // KEEP YOUR BATTERY FULLY CHARGED WHEN NOT IN USE // RECHARGE THE BATTERY IN A WELL VENTILATED AREA // DO NOT RECHARGE THE BATTERY IN AN AREA THAT MIGHT ALLOW E-GO 2 OR ITS CHARGING UNIT TO BECOME WET // DO NOT LEAVE E-GO 2 CHARGING UNATTENDED // KEEP CHILDREN AWAY FROM E-GO 2 WHEN CHARGING // DO NOT KEEP THE BATTERY ON CHARGE ONCE IT IS FULLY CHARGED // STOP USE OF THE PRODUCT OR CHARGING UNIT IF ANY WIRES ARE WORN OR DAMAGED // DO NOT MODIFY THE ELECTRICAL CONTROLS OR WIRING // ONLY USE A MOTOR, BATTERY OR CHARGING UNIT SUPPLIED OR APPROVED BY E-GO 2 // DO NOT USE THE E-GO 2'S BATTERY TO POWER ANY OTHER EQUIPMENT

BATTERY SAFETY

LITHIUM-ION BATTERIES CAN EXPLODE OR CAUSE A FIRE IF THEY ARE USED INCORRECTLY OR IF THEY ARE DEFECTIVE. THEREFORE, YOU ARE RECOMMENDED TO READ THE FOLLOWING INSTRUCTIONS VERY CAREFULLY:

- EACH TIME BEFORE USING THE BATTERY, CAREFULLY CHECK THE BATTERY PACK AND IN PARTICULAR THE PROTECTIVE SEAL/ CASING TO MAKE SURE THAT IT IS UNDAMAGED AND INTACT. IF IN DOUBT, TAKE THE BATTERY TO A CHEMICAL WASTE DISPOSAL FACILITY AND/OR CONTACT YUNEEC CUSTOMER SUPPORT IMMEDIATELY.
- ALWAYS HANDLE THE BATTERY WITH CARE. NEVER DROP THE BATTERY.
- STORE THE BATTERY IN A SAFE AND DRY PLACE AND KEEP THE BATTERY AWAY FROM ALL METAL OBJECTS.
- NEVER EXPOSE THE BATTERY TO TEMPERATURES ABOVE 100 DEGREES CELSIUS.
- ONLY USE OFFICIAL YUNEEC E-GO 2 2 CHARGERS THAT HAVE BEEN SPECIALLY BEEN DESIGNED FOR USE WITH LITHIUM-ION BATTERIES.
- WHEN CHARGING BATTERIES, KEEP THE CHARGER AWAY FROM HIGHLY FLAMMABLE MATERIALS OR PRODUCTS AND NEVER LEAVE THE CHARGER UNATTENDED WHEN IN USE.
- WHEN CHARGING THE CHARGER CAN GET HOT. DO NOT PLACE THE CHARGER ON DAMAGABLE SURFACES.
- IF YOU ARE NOT PLANNING ON USING THE BATTERY FOR ABOUT 6 MONTHS OR LONGER, FIRST CHARGE IT FULLY AND THEN RECHARGE IT ONCE A YEAR. THIS IS BECAUSE A LITHIUM-ION BATTERY THAT HAS BEEN LEFT EMPTY FOR TOO LONG CAN NO LONGER BE CHARGED.



TROUBLESHOOTING

MY BOARD DOESN'T START	1.1	Check if the board is activated on. When turning on the board you should hear two beeps and its status indicator light should come on.
	1.2	Check if the controller is powered ON. When turning ON the controller, its blue light should start flashing.
	1.3	If both the board and controller are powered ON, and the wireless controller's green light is not flashing, it means the board and controller are not synchronized (see page 10).
	1.4	If both board and controller are powered ON, and both the controller's blue and green light are flashing but you don't hear a beep and the board does not start, turn off the board and turn it on again.
	1.5	If the board and controller are synchronized and the controller's blue light is followed by a red flashing light and vibration, it means the board's battery is low and needs to be recharged.
	1.6	If board and controller are synchronized and the controller's green light is followed by a red flashing light and vibration, it means the controller's battery is low and needs to be recharged.
MY BOARD IS MOVING AT LOW SPEED...	2.1	Check if the board is in slow speed mode. If so, move the controller's speed mode switch to fast speed mode.
	2.2	If during your ride the controller's blue light is flashing, followed by a red flashing light and accompanied by vibration, it means the board's battery is low and needs to be recharged.

	3.7	If during your ride you hear a beep, the board stops and only the controller's blue light is flashing, it means the control signal is lost. Turn the controller off and then on again to reconnect.
	3.8	Control signal loss will occur when the distance between your board and controller becomes too great. To reconnect close the distance between the two.
MY BOARD DOESN'T CHARGE	4.1	Check if the charge cable is connected to the board and if the charger is connected to a standard A/C power source. If the connection is good and the board is charging, the charger's battery status indicator will turn red. When fully charged it should turn green. In any other situation please contact the E-GO 2 customer service.
MY CONTROLLER DOESN'T CHARGE	5.1	Check if the USB cable is well connected to the controller and the charge port and if the board is powered on. If the connection is good and the controller is charging, the controller's red light will turn on. When fully charged the red light will turn off. In any other situation please contact the E-GO 2 customer service.


YOU CAN CONTACT THE E-GO CUSTOMER SERVICE AT

YUNEEC.COM

SPARE PARTS


EGOCR001AU	E-GO 2 CRUISER WITH AU CHARGER
EGOCR001EU	E-GO 2 CRUISER WITH EU CHARGER
EGOCR001UK	E-GO 2 CRUISER WITH UK CHARGER
EGOCR001US	E-GO 2 CRUISER WITH US CHARGER
EGOCR002	GRIP TAPE: E-GO 2 CRUISER
EGOCR003	MOTOR COVER: E-GO 2 CRUISER
EGOCR004	DRIVE BELT: E-GO 2 CRUISER
EGOCR005	BUSHING SET: E-GO 2 CRUISER
EGOCR006	WHEEL SET WITH PRE-INSTALLED BEARINGS: E-GO 2 CRUISER
EGOCR007	BEARING SET: E-GO 2 CRUISER
EGOCR008	COMPLETE HARDWARE SET: E-GO 2 CRUISER
EGOCR009	REMOTE CONTROL WITH USB CABLE: E-GO 2 CRUISER
EGOCR010AU	AU CHARGER: E-GO 2 CRUISER
EGOCR010EU	EU CHARGER: E-GO 2 CRUISER
EGOCR010UK	UK CHARGER: E-GO 2 CRUISER
EGOCR010US	US CHARGER: E-GO 2 CRUISER
EGOCR011	FRONT TRUCK SET: E-GO 2 CRUISER
EGOCR012	REAR TRUCK SET WITH MOTOR: E-GO 2 CRUISER
EGOCR013	ELECTRONIC CONTROL UNIT (ECU): E-GO 2 CRUISER
EGOCR014	BATTERY PACK: E-GO 2 CRUISER
EGOCR015AU	CHARGE LEAD WITH AU PLUG: E-GO 2 CRUISER
EGOCR015EU	CHARGE LEAD WITH EU PLUG: E-GO 2 CRUISER
EGOCR015UK	CHARGE LEAD WITH UK PLUG: E-GO 2 CRUISER
EGOCR015US	CHARGE LEAD WITH US PLUG: E-GO 2 CRUISER
EGOCR016	DECK WITH GRIP TAPE: E-GO 2 CRUISER
EGOCR017	T-TOOL WITH PIN TOOL: E-GO 2 CRUISER

DECK SCREWS



1. front truck screws
2. battery pack screws
3. ECU screws
4. rear truck screws

5. motor cover
6. drive belt cover
7. drive belt cover screw
8. drive belt
9. drive wheel
10. washer
11. drive wheel nut




DEFORMING THE DRIVE
BELT MIGHT DAMAGE IT.

GARAGE

MAKE SURE THE E-GO 2 IS POWERED
OFF WHEN DOING MAINTENANCE
OR REPLACING COMPONENTS.

DRIVE WHEEL AND BELT




TO REPLACE THE GRIP TAPE IT IS ADVISED TO CONSULT YOUR LOCAL SKATE SHOP.

- 23. wheel nut
- 24. washer
- 25. bearing
- 26. spacer
- 27. truck axle
- 28. wheel

TRUCKS AND BUSHINGS



- 12. king pin nut
- 13. top cup washer
- 14. top bushing
- 15. truck
- 16. bottom bushing
- 17. bottom cup washer
- 18. king pin
- 19. baseplate nut
- 20. baseplate
- 21. baseplate rubber
- 22. truck screw



WHEELS AND BEARINGS

APPLY EQUAL PRESSURE ON THE OUTER RINGS OF THE BEARINGS TO PUSH THEM OUT OF AND INTO THE WHEEL TO AVOID DAMAGING THEM.

BATTERY PACK AND ECU



31. JST RCY connector
32. EC3 connector

INSTALLATION GUIDE

FRONT CRACK SEC EGOCR011

1 Unscrew the front wheel bolts.
2 Dismount the front wheels from the truck's axle. **3** Unscrew the top screws connecting the front baseplate to the deck. **4** Replace the complete assembly with the replacement part and reinstall. **5** Mount the wheels back on the truck's axle and tighten the screws.

REAR CRACK SEC WITH MOTOR EGOCR012

1 Unscrew the rear wheel nuts.
2 Dismount the rear wheels from the truck's axle. **3** Unscrew the top screws connecting the rear baseplate to the deck. **4** Replace the complete assembly with the replacement part and reinstall. **5** Mount the wheels back on the truck's axle and tighten the screws.

ELECTRONIC CONTROL UNIT EGOCR013

1 Unscrew the screws connecting the ECU to the deck. **2** Slide the ECU from the battery pack. **3** Disconnect the wires connecting the ECU to the battery pack. **4** Reconnect the battery packs wires to the replacement part. **5** Slide the replacement part in it's slot with the battery pack. **6** Screw in the deck screws connecting the ECU to the deck.

INSTALLATION GUIDE

MOTOR COVER EGOCR003

1 Unscrew the five screws securing the motor cover. **2** Remove the motor cover and replace it with the replacement part. **3** Screw on the motor cover screws and tighten.

DRIVE BELT EGOCR004

1 Unscrew the drive wheel bolt. **2** Dismount the rear wheels from the truck's axle. **3** Unscrew the drive belt cover screws. **4** Replace the belt with the replacement part. **5** Screw on and tighten the drive belt cover screws. **6** Mount the drive wheel back onto the truck's axle. **7** Screw on the drive wheel nut and tighten.

BUSHING SET EGOCR005

1 Unscrew the kingpin nut from the kingpin. **2** Replace the bushing. **3** Remount the truck and bushing on the baseplate axle. **4** Screw on and tighten the king pin nut.

BEARING SET 8 PCS EGOCR007

1 Unscrew the wheel bolt. **2** Dismount the wheel from the truck's axle. **3** Replace the bearing in the wheel with the spare part by applying equal pressure on the outer rings of the bearings. **4** Mount the wheel back onto the truck axle. **5** Screw on the wheel nut and tighten.

WHEEL SET WITH PRE INSTALLED BEARINGS EGOCR006

1 Unscrew the wheel bolt. **2** Dismount the wheel from the truck's axle and replace it with the replacement part. **3** Screw on and tighten the wheel bolts.

BATTERY PACK EGOCR014

1 Unscrew the screws connecting the battery pack to the deck. **2** Tilt the battery pack out of its slot with the ECU. **3** Disconnect the wires connecting the battery pack to the ECU and reconnect the ECU's wires to the replacement part. **4** Slide the replacement part in its slot with the ECU. **5** Screw in the deck screws connecting the battery pack to the deck.

E-GO 2 CRUISER



CAUTION: DO NOT SHORT-CIRCUIT, DISASSEMBLE OR EXPOSE THE BATTERY TO FIRE OR WATER

MADE IN CHINA

YUNEEC
AVIATION TECHNOLOGY

THIS MANUAL IS SUBJECT TO CHANGE
WITH FUTURE REVISIONS.

> PLEASE VISIT WWW.YUNEEC.COM

CERTIFICATION INFORMATION

FCC STATEMENT:

This equipment has been tested and found to comply with the limits for Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

RF EXPOSURE WARNING

This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provided with antenna installation instructions and transmitter operating conditions for satisfying RF exposure compliance.