


MOBILE LABEL PRINTER RPP30



Please read this Manual carefully before using the printer and keep it for future reference

Contents

Preface.....	1	4.4 Auto sleep/wake	12
About This Manual	1	4.5 Icons Description.....	13
Icons and Practices	1	4.6 Enter setting Screen.....	14
Related Manual Information	1	V. Communication	15
Safety Instruction	2	5.1 USB Communication	15
I. Standard Configuration.....	5	5.2 WiFi Communication	16
II. Appearance and Components	6	5.3 Bluetooth Communication	16
III. Preparation Before Use	8	VI. Repair and Maintenance.....	17
3.1 Battery Installation.....	8	6.1 Daily Maintenance of Printer	17
3.2 Battery Charge.....	9	6.2 Use and Storage of Printing Paper.....	17
3.3 Printing paper roll installation	10	VII. Troubleshooting	18
3.4 Belt buckle installation.....	11	VIII. Appendix	19
IV. Basic Functions.....	12	8.1 Printer Parameters	19
4.1 Power On.....	12	8.2 Battery Recycling	20
4.2 Power Off.....	12	IX. FCC WARNING.....	21
4.3 FEED.....	12		

Preface

About This Manual

Thank you for purchasing the RPP30 mobile printer produced by Rongta.

This Manual can help you easily learn to use this product. Please read this Manual carefully before using the printer and keep it properly so that everyone who uses this product can read it.

Icons and Practices

For your convenience, this Manual uses the following symbols (icons) and practices:

-  **WARNING** warns that improper use may result in property damage, serious injury or death.
-  **ATTENTION** indicates that improper use may result in personal injury or property damage.
-  **NOTE** indicates that the information listed allows you to use the product better or extend the service life of the product.

Related Manual Information

Various manuals provide detailed instructions for various technical problems.



The illustrations and text used in this Manual may differ from the actual product.

Safety Instruction

Please follow the following precautions when using the printer:



ATTENTION

Do not disassemble the printer by yourself. Please read this Manual carefully before use.



WARNING

Please turn off the power immediately in case of failure. When you notice smoke or odor coming from the printer or power adapter, please unplug the power adapter and remove the battery immediately. Please be careful not to get burnt.



WARNING

Please do not use the printer near gas stations, fuel warehouses and other flammable materials.



WARNING

During charging, the printer and power adapter must be placed in a ventilated place with the ambient temperature of 0°C - 45°C, and be sure to use the power adapter provided by the Company. The use of unapproved power adapters may be hazardous and also violates our warranty policy.



ATTENTION

When the printer is printing, please do not open the cover of the paper bin; otherwise, unpredictable conditions may occur and the printer may even be damaged.



ATTENTION

After printing, the print head is still at a high temperature. Do not touch it to avoid burns.



ATTENTION

Please do not use dissolved matter (such as benzene thinner) to wipe the printer shell, and please keep the printer away from corrosive chemicals. You can only gently wipe the printer with a clean soft cloth.



ATTENTION

Please use our original or approved printing paper; otherwise, it may lead to poor printing quality or even damage to the printer mechanism.



WARNING

The print head is a hot part. Do not touch the print head and its surrounding parts during or just after printing.

-  **ATTENTION** If the printer is to be stored for a long time, be sure to remove the battery from the printer and store it separately; otherwise, the battery may fail or even have leakage, which may damage the printer.
-  **ATTENTION** Make sure the printer is turned off before replacing the battery. If a power adapter is used, make sure the power is cut off before replacing the battery.
-  **ATTENTION** The printer can work stably at an ambient temperature of 0°C - 40°C. Too high or too low ambient temperature will lead to low printing quality.
-  **ATTENTION** The time that the printed text can be kept on the thermal printing paper is related to the paper quality. To print documents that need to be kept for a long time, please use long-lasting thermal printing paper.
-  **ATTENTION** The tear blade has a sharp edge, please be careful not to touch to prevent cuts.

Please follow the following precautions when using the battery:

-  **ATTENTION** Please carefully read this Manual and symbols on the battery surface before use.
-  **WARNING** Please charge the battery in a cool and ventilated room. The high ambient temperature during charging will cause the battery to heat up, emit smoke, burn, deform, or even explode.
-  **WARNING** There are special protective circuits and devices inside the battery. Please do not disassemble the battery by yourself, or it will cause a short circuit or electrolyte leakage.
-  **WARNING** There is a risk of blindness if the electrolyte gets into the eye. In case of eye contact, rinse immediately with water and seek doctor's advice immediately.


-  **WARNING** Do not squeeze, mechanically vibrate or shake the battery, and short circuit of the battery is strictly forbidden.
-  **WARNING** Please do not put the battery into water; otherwise, it may result in internal short circuit, which may cause the battery to heat up, emit smoke, deform, damage or even explode.
-  **ATTENTION** Do not expose the battery to direct sunlight or put it in a place with excessive smoke and dust. Do not use the battery in a high humidity environment, such as a bathroom.
-  **ATTENTION** Please replace the battery if it cannot meet the performance requirements.
-  **ATTENTION** Keep the battery out of reach of children to prevent danger.
-  **ATTENTION** If you notice any discoloration or deformation of the battery, stop using it immediately.

Please carefully read this Manual and symbols on the surface of power adapter before use.

-  **ATTENTION** Do not disassemble or modify the power adapter. Do not use the power adapter if the power line is damaged; otherwise, it may cause electric shock, fire and damage to the power adapter.
-  **WARNING** Do not touch the power adapter with wet hands. If the power adapter comes into contact with water or other liquids, cut off the power supply immediately.
-  **WARNING** Please avoid short circuit, vibration or shaking of the power adapter.
-  **WARNING** Do not use the power adapter in a high humidity environment, such as a bathroom. The equipment is not waterproof and must not be exposed to rain or moisture.
-  **WARNING** Hold the power adapter body when unplugging. Simply pulling the power line will damage the wires.
-  **ATTENTION** Keep the power adapter out of reach of children to prevent danger.

I. Standard Configuration



Printer	USB cable	Power adapter	Quick installation guide
			
Roll(Optional)	Belt buckle (Optional)	Battery	
			




The pictures are for reference only, please subject to practicality


II. Appearance and Components




□ Front View



❑ Inside View




❑ Rear View



III. Preparation Before Use




This chapter describes the steps to prepare the printer, including battery installation, battery charging, and printing paper loading.



3.1 Battery Installation

The battery is installed in the printer before the product leaves factory.

1. Remove the protective film of battery contacts.
2. Install the battery as shown in the figure above.
3. Fasten the battery.



3.2 Battery charge

1. Standby charging

Insert the power adapter plug into the power socket, and the USB interface into the printer charging port(AC:100V~240V(50/60Hz)).

Charging: Battery indication icon  scroll display of battery indication slot.

End of charging Battery indication icon shows  full battery,

The buzzer will alert with a "beep" sound.



WARNING

If you use a power adapter not provided or approved by us, the printer may be damaged.



NOTE


It can be printed while charging.

The device supports the fast charge function, which can continue to print after a short charge.




ATTENTION

Do not remove the battery while charging.



3.3 Printing paper roll installation

1. Remove the seal of the paper roll;
2. Press the open button to open the paper compartment, turn the baffle wrench to unlock, and adjust the paper width baffle to the paper width;
3. Put the paper roll into the paper bin, fine-tune the paper width baffle to lean against the paper roll, turn the paper width baffle wrench to fix it;
4. Pull out a part of the paper along the exit and close the paper bin cover.





NOTE

1. printers use paper specifications: paper width: 20~80mm (adjustable on one side), paper roll diameter: 50mm.
2. Pay attention to the direction of paper roll. If it is placed in the wrong direction, it will lead to blank printing.

3.4 Belt buckle installation

1. Remove the belt buckle
2. Tighten the belt buckle screws as shown in the following figure



IV. Basic Functions



Function description of buttons

4.1 Power On

Press and hold the POWER button for 3 seconds to turn on the printer.

4.2 Power Off

When the printer is on, press and hold the POWER button to turn it off.

4.3 FEED

Press the FEED button (under continuous feeding mode, press FEED button to feed paper of about 5mm; under label/black label mode, press FEED button to feed paper to seam label or black label.)

4.4 Auto sleep/wake

Auto sleep

When the printer is turned on and has no button operation or data transmission within 10 seconds, it will automatically enter sleep mode. The screen display is shown in the figure.



Auto wake

When the printer is in sleep mode, it can be woke up by pressing the POWER button or when receiving data.

4.5 Icons Description

Printing status		This icon is displayed when the printer is printing or feeding paper.
Paper shortage state	 Please fill printing papers	When paper shortage occurs or the paper roll is not properly loaded
Cover opening state	Please close paper tank cover 	When the r paper bin cover is not closed or not properly closed
Battery indication		When charging, the icon will scroll to indicate the charging status
Bluetooth indicator		The printer has Bluetooth function
WiFi indicator(Optional)		The printer has WiFi function (√ :indicates successful WiFi connection)

4.6 Enter setting Screen

During power-on state (non-sleep mode), press and hold SET/FEED button to enter the option screen.

Press SET/FEED button: Go to the next option

Press POWER button: Change option parameters

Press and hold SET/FEED button: Confirm settings and exit


 Do: Print Info	Print self-test page	Press and hold SET/FEED button to start printing self-test page
 Print Quality: 4	0-4	Set wide range definition (coarse tuning)
 Darkness: 4	0-4	Set small range definition (fine tuning)
 Speed: 0	0-5	Set print speed
 Language: English	EngLish	Set language
 Buzzer Set: Open	on	Set whether to turn on the buzzer
 Paper Type: Gap	Continuous paper	Set according to the paper type used
 Power Feed: Open	Close	Set whether to enable startup and paper feeding
 Cover Feed: Open	Close	Set whether to enable cover closing and paper feeding
 ScreenSaver: 10	Screensaver Time	Set screensaver time (four levels)
 Auto Shutdown:-	1-5H	Set auto shutdown
 Cmd Mode: ESC	CPCL/ESC	Instruction mode setting
 Paper Size: 80	58/80	Paper width setting 58/80

V. Communication



5.1 USB Communication

The printer provides USB port, which is used to connect the printer to a PC as shown in the figure to charge the printer, set parameters, and transmit data, etc.



5.2 WiFi Communication (Alternative)

The mobile label printer can provide WiFi communication, and support STA mode and TPK/AES encryption. Its effective communication distance is no more than 20m.



 WiFi information can be changed through the setting tool. For details, please refer to the "Instruction Manual for Setting Tool".

5.3 Bluetooth Communication

The mobile label printer can provide dual-mode Bluetooth 5.2 (SPP + BLE), which can communicate with Android system and IOS system terminals. Its effective communication distance is no more than 10m.



 The default pairing password of Bluetooth is 1234 and the parameters can be set through the setting tool. For details, please refer to the "Instruction Manual for Setting Tool".

VI. Repair and Maintenance




6.1 Daily Maintenance of Printer

1. Cleaning of outside and paper bin: Wipe the surface of the printer and the inside of the paper bin gently with a wrung-out wet cloth. Make sure that the wet cloth is completely wrung out.
2. Cleaning of printer mechanism: The printer mechanism must be cleaned regularly, especially when the print quality declines. The cleaning method is as follows: Use absorbent cotton moistened with anhydrous alcohol to gently wipe the stains or the residue glue of label paper on the surface of the printer mechanism until it is clean.
3. If water is found inside the printer, Turn it off immediately, remove the battery, and dry the printer by airing.
4. If the printer will not be used for a long time, remove the battery and store it separately.

6.2 Use and Storage of Printing Paper

1. Please keep newly purchased printing paper in intact package and prevent it from direct sunlight and high temperature.
2. Please keep printed documents in a dark place at room temperature (about 20°C), so as to effectively extend the storage life of the documents.
3. If the documents need to be kept for a long time, please use long-lasting thermal printing paper.



VII. Troubleshooting



Fault Phenomenon	Cause	Solution
Paper is fed but no data is printed.	Printing paper is loaded in the wrong direction.	Please load the printing paper in the other direction.
Blurry printing	The printer is not cleaned for a long time and the printer mechanism is contaminated by dirt.	Clean the printer mechanism.
	Poor color rendering of printing paper	Please set higher blackness or use paper with better color rendering
Printed documents are blurred in months or even weeks	Poor quality of printing paper	Please use long-lasting thermal printing paper
	Documents are kept at high ambient temperature	Please keep the documents at room temperature (about 20°C)

VIII. Appendix



8.1 Printer Parameters

Printing Parameters	
Printing method	Thermal line printing
Print width	22~80mm
Paper roll diameter	≤ 50mm
Print speed	100mm/s MAX
Resolution	203dpi
Built-in font	GB18030 Simplified Chinese (standard)
Thermal head lifespan	≥ 50km (label paper)
Command set	TSC/CPCL/ESC/POS compatible
Support paper types	Thermal continuous paper, label paper, black label paper
Print content	One-dimensional code: Code 39, 39C, I25, Code 93, ITF25, EAN128, Code 128, Codabar, EAN-8, EAN8+2, EAN8+5, EAN-13, EAN13+2, EAN13+5, UPC-A, UPCA+2, UPCA+5, UPC-E, UPCE+2, UPCE+5 MSIC, ITF14, EAN14, CODE11, POST QR code: QR CODE, PDF417 (optional)

Printing Parameters

Extended character list	CP437, CP850, CP852, CP860, CP863, CP865, CP866, WPC1250, WPC1251, WPC1252, WPC1253, WPC1254
Input power supply	Input AC 100-240V, output DC 5V  2A
Battery specification	7.4V 2000mAh lithium-ion battery
Charging time	3 hours
Wireless communication	Bluetooth 5.2- Dual mode (compatible with Android and iOS)
Wire communication	Type-C USB
Working environment	Temperature: -10°C~50°C Humidity: 5%~95%(No condensation)
Storage environment	Temperature: -20°C~60°C Humidity: 5%~90%(No condensation)

 **Note:** This product information parameters are subject to change without prior notice, subject to the actual!

8.2 Battery Recycling

This product uses a rechargeable lithium battery. To protect the environment, please do not dispose of used batteries at will. The supplier will provide you with battery recycling service.



IX. FCC WARNING



This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

WARNING

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.



Rongta Technology (Xiamen) Group Co., Ltd.

ADD: No.88, Tonghui South Road, Tongan, Xiamen, China.

WEB: www.rongtatech.com

TEL: 0086-592-5666129

FAX: 0086-592-5659169