

RFID MODULE

Mifare Reader / Writer

SL025B
User Manual

Version 3.0

Jan 2018

StrongLink

CONTENT


1. MAIN FEATURES	3
2. PINNING INFORMATION.....	4
3. BAUD RATE SETTING.....	5
4. COMMUNICATION PROTOCOL.....	5
4-1. COMMUNICATION SETTING	5
4-2. COMMUNICATION FORMAT	5
4-3. COMMAND OVERVIEW	6
4-4. COMMAND LIST	7
4-4-1. Select Mifare card	7
4-4-2. Login to a sector	7
4-4-3. Download Key into SL025	7
4-4-4. Login sector via stored key	8
4-4-5. Read a data block	8
4-4-6. Write a data block.....	8
4-4-7. Read a value block	8
4-4-8. Initialize a value block.....	9
4-4-9. Write master key (key A)	9
4-4-10. Increment value	9
4-4-11. Decrement value.....	10
4-4-12. Copy value	10
4-4-13. Read a data page (UltraLight).....	10
4-4-14. Write a data Page (UltraLight).....	11
4-4-15. Manage Red Led	11
4-4-16. Get firmware version	11

1. MAIN FEATURES



- Tags supported: Mifare 1k, Mifare 4k, Mifare UltraLight and NFC NTAG203
- Auto-detecting tag, Built-in antenna
- RS232 interface, baud rate 9,600 ~ 115,200 bps
- 4.4 ~ 12.0VDC power supply
- Work current less than 80mA
- Operating distance: Up to 70mm, depending on tag
- Storage temperature: -40 °C ~ +85 °C
- Operating temperature: -25 °C ~ +70 °C
- Dimension: 86 × 55 mm
- Two LEDs, green led is auto light when tag in detection range, red led is controlled by host
- The OUT pin at low level indicates tag in detective range, and high level indicating tag out
- Support IAP firmware update

2. PINNING INFORMATION



Connector: Würth Elektronik [653 105 131 822](https://www.wuerth-elektronik.com/653105131822)

PIN	SYMBOL	TYPE	DESCRIPTION
1	TagSta	Output	Tag detect signal, RS232 level Logic 0 indicating tag in detection range Logic 1 indicating tag out
2	TXD	Output	Serial output port
3	RXD	Input	Serial input port
4	VCC	PWR	Power Supply
5	GND	PWR	Ground

3. BAUD RATE SETTING

Two 820 ohm resistances R6 & R7 are used for setting baud rate as follows sheet

	R6	R7	Baud rate bps
Assembled	no	no	9,600
	yes	no	19,200
	no	yes	57,600
	yes	yes	115,200 (default)

4. COMMUNICATION PROTOCOL

4-1. Communication Setting

The communication protocol is byte oriented. Both sending and receiving bytes are in hexadecimal format. The communication parameters are as follows

Baud rate: 9,600 ~ 115,200 bps

Data: 8 bits

Stop: 1 bit

Parity: None

Flow control: None

4-2. Communication Format

Host to SL025:

Preamble	Len	Command	Data	Checksum
----------	-----	---------	------	----------

Preamble: 1 byte equal to 0xBA

Len: 1 byte indicating the number of bytes from Command to Checksum

Command: 1 byte Command code, see Table 3

Data: Variable length depends on the command type

Checksum: 1 byte XOR of all the bytes from Preamble to Data

SL025 to Host:

Preamble	Len	Command	Status	Data	Checksum
----------	-----	---------	--------	------	----------

Preamble: 1 byte equal to 0xBD

Len: 1 byte indicating the number of bytes from Command to Checksum

Command: 1 byte Command code, see Table 3

Status: 1 byte Command status, see Table 4

Data: Variable length depends on the command type.

Checksum: 1 byte XOR of all the bytes from Preamble to Data

4-3. Command Overview

Table 3

Command	Description
0x01	Select Mifare card
0x02	Login to a sector
0x03	Read a data block
0x04	Write a data block
0x05	Read a value block
0x06	Initialize a value block
0x07	Write master key (key A)
0x08	Increment value
0x09	Decrement value
0x0A	Copy value
0x10	Read a data page (UltraLight & NTAG203)
0x11	Write a data page (UltraLight & NTAG203)
0x12	Download Key
0x13	Login sector via stored Key
0x40	Manage Red Led
0xF0	Get firmware version

Status Overview

Table 4

Status	Description
0x00	Operation succeed
0x01	No tag
0x02	Login succeed
0x03	Login fail
0x04	Read fail
0x05	Write fail
0x06	Unable to read after write
0x08	Address overflow
0x09	Download Key fail
0x0D	Not authenticate
0x0E	Not a value block
0xF0	Checksum error
0xF1	Command code error

4-4. Command List

4-4-1. Select Mifare card

0xBA	Len	0x01	Checksum
------	-----	------	----------

Response:

0xBD	Len	0x01	Status	UID	Type	Checksum
------	-----	------	--------	-----	------	----------

Status: 0x00: Operation succeed

0x01: No tag

0xF0: Checksum error

UID: The uniquely serial number of Mifare card,

Type: 0x01: Mifare 1k, 4 byte UID

0x02: Mifare 1k, 7 byte UID ^[1]

0x03: Mifare UltraLight or NATG203^[2], 7 byte UID

0x04: Mifare 4k, 4 byte UID

0x05: Mifare 4k, 7 byte UID ^[1]

0x06: Mifare DesFire, 7 byte UID

0x0A: Other

4-4-2. Login to a sector

0xBA	Len	0x02	Sector	Type	Key	Checksum
------	-----	------	--------	------	-----	----------

Sector: Sector need to login, 0x00 – 0x27

Type: Key type (0xAA: authenticate with KeyA, 0xBB: authenticate with KeyB)

Key: Authenticate key, 6 bytes

Response:

0xBD	Len	0x02	Status	Checksum
------	-----	------	--------	----------

Status: 0x02: Login succeed

0x01: No tag

0x03: Login fail

0x08: Address overflow

0xF0: Checksum error

4-4-3. Download Key into SL025

0xBA	Len	0x12	Sector	Type	Key	Checksum
------	-----	------	--------	------	-----	----------

Sector: 0x00 – 0x27

Type: Key type (0xAA: KeyA, 0xBB: KeyB)

Key: 6 bytes, stored into SL025

Response:

0xBD	Len	0x12	Status	Checksum
------	-----	------	--------	----------

Status: 0x00: Operation succeed

0x08: Address overflow

0x09: Download fail

0xF0: Checksum error

4-4-4. Login sector via stored key

0xBA	Len	0x13	Sector	Type	Checksum
------	-----	------	--------	------	----------

Sector: Sector need to login, 0x00 – 0x27

Type: Key type (0xAA: KeyA, 0xBB: KeyB)

Response:

0xBD	Len	0x13	Status	Checksum
------	-----	------	--------	----------

Status: 0x02: Login succeed

0x03: Login fail

0x08: Address overflow

0xF0: Checksum error

4-4-5. Read a data block

0xBA	Len	0x03	Block	Checksum
------	-----	------	-------	----------

Block: The absolute address of block to be read, 1 byte

Response:

0xBD	Len	0x03	Status	Data	Checksum
------	-----	------	--------	------	----------

Status: 0x00: Operation succeed

0x01: No tag

0x04: Read fail

0x0D: Not authenticate

0xF0: Checksum error

Data: Block data returned if operation succeeds, 16 bytes.

4-4-6. Write a data block

0xBA	Len	0x04	Block	Data	Checksum
------	-----	------	-------	------	----------

Block: The absolute address of block to be written, 1 byte.

Data: The data to write, 16 bytes.

Response:

0xBD	Len	0x04	Status	Data	Checksum
------	-----	------	--------	------	----------

Status: 0x00: Operation succeed

0x01: No tag

0x05: Write fail

0x06: Unable to read after write

0x0D: Not authenticate

0xF0: Checksum error

Data: Block data written if operation succeeds, 16 bytes.

4-4-7. Read a value block

0xBA	Len	0x05	Block	Checksum
------	-----	------	-------	----------

Block: The absolute address of block to be read, 1 byte.

Response:

0xBD	Len	0x05	Status	Value	Checksum
------	-----	------	--------	-------	----------

Status: 0x00: Operation succeed

0x01: No tag
 0x04: Read fail
 0x0D: Not authenticate
 0x0E: Not a value block
 0xF0: Checksum error

Value: Value returned if the operation succeeds, 4 bytes.

4-4-8. Initialize a value block

0xBA	Len	0x06	Block	Value	Checksum
------	-----	------	-------	-------	----------

Block: The absolute address of block to be initialized, 1 byte.

Value: The value to be written, 4 bytes.

Response:

0xBD	Len	0x06	Status	Value	Checksum
------	-----	------	--------	-------	----------

Status: 0x00: Operation succeed
 0x01: No tag
 0x05: Write fail
 0x06: Unable to read after write
 0x0D: Not authenticate
 0xF0: Checksum error

Value: Value written if the operation succeeds, 4 bytes.

4-4-9. Write master key (key A)

0xBA	Len	0x07	Sector	Key	Checksum
------	-----	------	--------	-----	----------

Sector: The sector number to be written, 0x00 – 0x27

Key: Authentication key, 6 bytes

Response:

0xBD	Len	0x07	Status	Key	Checksum
------	-----	------	--------	-----	----------

Status: 0x00: Operation succeed
 0x01: No tag
 0x05: Write fail
 0x08: Address overflow
 0x0D: Not authenticate
 0xF0: Checksum error

Key: Authentication key written if the operation succeeds, 6 bytes.

Attention: Be sure KeyB is readable, otherwise KeyB will be change to 000000000000 after this command.

4-4-10. Increment value

0xBA	Len	0x08	Block	Value	Checksum
------	-----	------	-------	-------	----------

Block: The absolute address of block to be increased, 1 byte.

Value: The value to be increased by, 4 bytes.

Response:

0xBD	Len	0x08	Status	Value	Checksum
------	-----	------	--------	-------	----------

Status: 0x00: Operation succeed
 0x01: No tag
 0x05: Write fail
 0x06: Unable to read after write
 0x0D: Not authenticate
 0x0E: Not a value block
 0xF0: Checksum error
 Value: The value after increment if the operation succeeds, 4 bytes

4-4-11. Decrement value

0xBA	Len	0x09	Block	Value	Checksum
------	-----	------	-------	-------	----------

Block: The absolute address of block to be decreased, 1 byte
 Value: The value to be decreased by, 4 bytes

Response:

0xBD	Len	0x09	Status	Value	Checksum
------	-----	------	--------	-------	----------

Status: 0x00: Operation succeed
 0x01: No tag
 0x05: Write fail
 0x06: Unable to read after write
 0x0D: Not authenticate
 0x0E: Not a value block
 0xF0: Checksum error
 Value: The value after decrement if the operation succeeds, 4 bytes

4-4-12. Copy value

0xBA	Len	0x0A	Source	Destination	Checksum
------	-----	------	--------	-------------	----------

Source: The source block copy from, 1 byte
 Destination: The destination copy to, 1 byte
 Attention: The source and destination must in the same sector

Response:

0xBD	Len	0x0A	Status	Value	Checksum
------	-----	------	--------	-------	----------

Status: 0x00: Operation succeed
 0x01: No tag
 0x05: Write fail
 0x06: Unable to read after write
 0x0D: Not authenticate
 0x0E: Not a value block (Source)
 0xF0: Checksum error
 Value: The value after copy if the operation succeeds, 4 bytes

4-4-13. Read a data page (UltraLight & NTAG203)

0xBA	Len	0x10	Page	Checksum
------	-----	------	------	----------

Page: The page number to be read, 0x00 – 0x0F

Response:

0xBD	Len	0x10	Status	Data	Checksum
------	-----	------	--------	------	----------

Status: 0x00: Operation succeed

0x01: No tag

0x04: Read fail

0x08: Address overflow

0xF0: Checksum error

Data: Block data returned if operation succeeds, 4 bytes.

4-4-14. Write a data Page (UltraLight & NTAG203)

0xBA	Len	0x11	Page	Data	Checksum
------	-----	------	------	------	----------

Page: The page number to be written, 0x00 – 0x0F

Data: The data to write, 4 bytes.

Response:

0xBD	Len	0x11	Status	Data	Checksum
------	-----	------	--------	------	----------

Status: 0x00: Operation succeed

0x01: No tag

0x05: Write fail

0x06: Unable to read after write

0x08: Address overflow

0xF0: Checksum error

Data: Page data written if operation succeeds, 4 bytes.

4-4-15. Manage Red Led

0xBA	Len	0x40	Code	Checksum
------	-----	------	------	----------

Code: 0 command red led turn off , other red led turn on, 1 byte

Return:

0xBD	Len	0x40	Status	Checksum
------	-----	------	--------	----------

Status: 0x00: Operation succeed

0xF0: Checksum error

4-4-16. Get firmware version

0xBA	Len	0xF0	Checksum
------	-----	------	----------

Response: ^[3]

0xBD	Len	0xF0	Status	Data	Checksum
------	-----	------	--------	------	----------

Status: 0x00: Operation success

0xF0: Checksum error

Data: firmware version.

Remark

^[1] In order to support 7 byte UID Mifare class, the firmware of SL025 has been updated to Ver1.2 in Mar 2011.

And older firmware version (such as Ver1.0, 1.1) only supports 4 byte UID.

Please refer to NXP [Customer Letter UID](#) for detailed information of 4 byte & 7 byte UID of Mifare products.

^[2] To support NATG203, the firmware of SL025 has been updated to Ver1.6 in May 2012. The older firmware version only supports reading/writing data page address less than 16.

^[3] One sample of SL025 response

	Preamble	Len	Command	Status	Data (Firmware version)	Checksum
HEX	BD	15	F0	00	53 4C 30 32 35 2D 33 2E 30 2D 32 30 31 36 31 31 31 34	69
ASCII					"SL025-3.0-20161114 "	

Product Information

Product Name:	MIFARE MODULE
Model No.:	SL025B_V3.0
RFID:	13.56MHz
Antenna Type:	Integrated Antenna

Host Information

Product Name:	Host device
Model No.:	T025B
Manufacturer:	BEIJING STRONGLINK TECHNOLOGY CO., LTD.

Federal Communications Commission (FCC) Interference Statement

The limited modular transmitter is **only** FCC authorized for the specific rule part (FCC Part15.225) listed on the grant, and that the host product manufacturer is responsible for compliance to any other FCC rules that apply to the host not covered by the modular transmitter grant of certification.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

For additional hosts other than the specific host originally granted with a limited module, a Class II permissive change is required on the module grant to register the additional host as a specific host also approved with the module.

OEM/Host integrator is responsible for complying with the instructions and requirements for each transmitter they choose to integrate into a host product.

RF exposure warning

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This product may not be collocated or operated in conjunction with any other antenna or transmitter. This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance from all persons and must not be collocated or operating in conjunction with any other antenna or transmitter. Additional text needed for the host product manufacturer to provide to end users in their end-product manuals.

OEM Integration Instructions :

This device is intended only for OEM integrators under the following conditions:

The module can be used to installation in other host. The antenna must be installed such that 20 cm is maintained between the antenna and users, and the transmitter module may not be co-located with any other transmit or antenna. The module shall be only used with the integral antenna(s) that has been originally tested and certified with this module. As long as 3 conditions above are met, further transmitter test will not be required. However, the OEM integrator is still responsible for testing their end-product for any additional compliance requirement with this module installed (for example, digital device emission, PC peripheral requirements, etc.)

IMPORTANT NOTE :

In the event that these conditions cannot be met (for example certain laptop configuration or co-location with another transmitter), then the FCC authorization for this module in combination with the host equipment is no longer considered valid and the FCC ID of the module cannot be used on the final product. In these and circumstance, the OEM integrator will be responsible for re-evaluating. The end product (including the transmitter) and obtaining a separate FCC authorization. The final end product must be labeled in a visible area with the following:

“Contains Transmitter Module FCC ID: 2ADI8-SL025B or Contains FCC ID: 2ADI8-SL025B”.