

Operating Instructions

Microphone and Earphone Connection

- Connect the microphone / headset to the 3.5mm socket on the transmitter and the earphones to the 3.5mm socket on the receiver. Make sure the connectors are properly inserted in place.

Power On and Off

- Press and hold the power button  /  for 2 seconds to turn on the system. The LCD display will illuminate and retrieve the channel number used last time to indicate Power on successfully.
- Press and hold the power button  /  for 2 seconds. The LCD display will disappear to indicate Power off completely.

Note :

- Energy saving- Receiver will automatically power off if no signal is received after about **20min**.

How to select a channel

- The channel is preset to **CH 001**. If you wish to select a different channel, press  and  buttons simultaneously for 2 seconds. The **CH** sign starts flashing. Press  or  button to select your desired channel. Press  /  button briefly to confirm the selected channel or wait for approximately 5 seconds to automatically store the selected channel.

Note :

- Make sure that the transmitter and receiver(s) operate on the same channel. The receiver display will keep flashing when no transmission signal is being received.
- System will retrieve the channel number used previously.
- Channel SYNC – Receiver(s) which operates on same channel of the transmitter will be synced wirelessly when the channel on the transmitter has been changed as synchronization feature.

Receiver:

- Receiver volume is preset at level 4 
- Press  or  button to decrease or increase the volume level. There are 8 adjustable levels from  to 
- The LCD display  indicates no volume and in mute mode.

Battery Autonomy and Charging

- When battery icon is displayed at fully autonomy , the battery contains sufficient power.
- When the battery icon is displayed as empty and flashing , this indicates low battery and only 10% battery remaining. Recharge the battery immediately via USB certified traveling charger (optional accessories) or appropriated Linkx charger station. It will take approx. **6** hours to reach full charge and provide approx. **17** hours of continuous operation.
- While charging, the battery icon displays on LCD  back and forth.

Note :

- The transmitter or receiver will shut down automatically when charging is taking place. If you want to use the system while it's charging, simply press the power button again to turn the system back on.

Working Frequency : 902~928MHz

Output Power: 10 ± 1 dBm