

User Manual



SPORTS
HD DV



Features

Shutter/Select Button WiFi ON/OFF

MicroSD Slot

Microphone



Power/Mode Button

Micro USB
Port

Status Indicator
Light

Lens

Status
Indicator Light

Up Button



Screen

Speaker

Charging Status
Light


Down Button
Menu

Battery Door Latch



Battery Door

Waterproof Housing



Accessories



Waterproof
Housing



Handle Bar/Pole
Mount



Mount 1



Mount 2



Mount 3



Mount 4



Mount 5



Mount 6



Mount 7



Clip 1



Clip 2



Helmet
Mounts



Bandages



Battery



Adhesives



Tethers



Metal Tether



Protective
Backdoor



USB Cable




Charger





Lens Cloth

Mounting Your Camera

Attach your camera to helmets, gear and equipment.






1. Video - logo camera - or Photo - logo P



Record Video

2. Playback (Event, Video or JPEG)



3. Settings (Video Settings, Photo Settings, and System Settings)

To access to Video Settings, go to the Video mode and press the down button. To access the Photo Settings, go to the Photo mode and press the down button.

You can then choose different settings such as

Movie Size: 1080p 30fps or 720p 60fps

MicroSD Card	1080p 30fps	720p 60fps
32 GB	240 mins	320 mins
16 GB	120 mins	160 mins
8 GB	60 mins	80 mins
4 GB	30 mins	40 mins

You can also choose Video Quality, Seamless mode, White Balance mode, Resolution usefull in driver mode so you can save battery and memory space, and Date Stamp display.

You can select different resolutions up to 12 Mp, White Balance modes, Driver/Timer modes, Burst mode, Date Stamp Display.

Storage/MicroSD Cards

This camera is compatible with 4GB, 16GB, and 32GB capacity microSD, microSDHC, and microSDXC memory cards. You must use a microSD card with a Class 10 speed rating. We recommend using brand name memory cards for maximum reliability in high-vibration activities.

Charging the Battery

If recording is occurring when battery reaches 0%, the camera will save the file and power OFF.

To charge the battery:

1. Connect the camera to a computer or USB power supply.
2. The Charging Status Light remains ON while the battery is charging.
3. The Charging Status Light will turn OFF when the battery is fully charged.

Connecting to the iSmart DV App

The iSmart DV App lets you control your camera remotely using a smartphone or tablet. Features include full camera control, live preview, photo playback and sharing of select content and more.

1. Download the iSmart DV App to your smartphone or tablet at the Apple App Store or Google Play.
2. Press the Power/Mode Button to power camera ON.
3. Press the OK/Shutter button for 3 seconds until you see “waiting for WiFi connection”
4. In your smartphone or tablet’s Wi-Fi settings, connect to the network called “ Action Cam ” followed by a series of numbers.
5. Enter the password “1234567890”.
6. Open the iSmart DV App on your smartphone or tablet.

Compatibility

The iSmart DV App is compatible with some smartphones and tablets listed below.



iOS App Download
For Wi-Fi Edition



Android App Download
For Wi-Fi Edition

Remote control instructions (Set selectable)

1. Sport DV after startup, the red power button on the remote control is a direct shutdown.
2. MODE key on the remote control panel, click on the remote control sport DV photographs, video switch.
3. REC key on the remote remote control panel, click on the remote control sports DV photograph, video.

COMPATIBILITY

* Compatibility varies by device. Content playback, sharing and access to the camera's memory card might be not available on some devices.

THANK YOU !

Congratulations on your new camera! This user manual will help you learn the basics of capturing life's most incredible moments!

Getting Started

Turn camera ON and repeatedly press the Button to cycle through camera modes.

Products in sales, the masses of users to provide a lot of valuable Suggestions, we will continue to update software and hardware for provide a perfect products, subject to our available products, if there are any discrepancies, please understanding!

Warning Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.