

MiTraveler

by Michley Tivax



10.1" Windows Tablet User Manual

Model: MiTraveler 1081W

Table of Contents

1. What's in the Box.....	1
2. Tablet Parts.....	1
3. Getting Started.....	2
4. The Start Screen.....	3
5. Getting Around.....	4
6. Apps.....	5
7. Charm Menu.....	6
8. Using Two Apps at Once.....	7
9. Factory Reset.....	7
10. Safety Information.....	8
11. Specifications.....	9

1. What's in the Box

Please check your box for the following items:

- Tablet
- User manual
- Warranty card
- Power adapter
- USB cable
- OTG cable

2. Tablet Parts



- | | |
|----------------------|---------------------|
| ① Power button | ② Earphone jack |
| ③ HDMI port | ④ Micro SD port |
| ⑤ Micro USB port | ⑥ DC jack |
| ⑦ Volume down button | ⑧ Volume up button |
| ⑨ Camera | ⑩ Start menu button |

3. Getting Started

Charging the Battery

The tablet has a built-in rechargeable Li-polymer battery.

1. To charge, plug the AC power adapter into the charging port and plug the other end into a power source.
2. The tablet can still be used while the battery is charging.

Power ON/OFF

1. Press and hold the power button until the tablet turns on.
2. To power off, press and hold the power button for several seconds. Slide your finger downward on the screen to turn off the tablet.

Screen Lock/Unlock

This feature locks and turns off the screen while the tablet is still turned on.

Screen locks when:

1. Tablet is left idle for a period of time
2. Manually activated by pressing the power button once

To unlock the screen, press the power button once and slide your finger upward on the screen.


Connecting to Internet

1. Swipe your finger in from the right edge of the screen to open the charm menu.
2. Choose Settings, and press the network icon (five vertical bars).
3. Choose the network of your choice from the list, and press Connect. You may need to enter your network password or key.

4. The Start Screen

1. Touch the white Start menu icon next to the screen to visit the Start screen. You can also swipe in from the right edge of the screen and choose Start.

2. Press any tile on the Start screen to start an app. Some apps require you to create or log into a Microsoft account before they will work.



3. Slide your finger left or right to see more apps.



4. To customize your Start screen, swipe down from the top edge of the screen and choose Customize. You can then drag and drop tiles where you want them.



5. Getting Around

To return to your previous app, swipe in from the left edge of the screen. To see a list of all open apps, swipe in from the left edge, keep your finger on the screen, and slide your finger back toward the left edge.



In some apps, you can reduce or enlarge the picture by placing two fingers on the screen and sliding them apart or together.

Zoom out



Zoom in




To see the commands for the app you are using, swipe down from the top edge of the screen.



6. Apps

To see all your apps, go to the Start screen and slide your finger up.




To place one of these apps on the Start screen, press and hold the icon for about one second. Choose Pin to Start.

To remove an app icon from the Start screen, press and hold it for about one second. Choose Unpin from Start.

7. Charm Menu

Swipe in from the right edge of the screen to see the five charm icons: Search, Share, Start, Devices, and Settings.



Search the web and the tablet.



Share something via email or a social network.



Return to the Start screen. If you are already on the Start screen, this icon returns you to the last app you used.




Manage devices such as printers and projectors.



Change tablet settings.

8. Using Two Apps at Once

1. To open two apps on the screen at the same time, first open one app. Then swipe in from the left edge, keep your finger on the screen, and slide your finger back toward the left edge to see a list of all open apps.
2. Drag the app you want from the list, and drop it to the left or right side of the current app.
3. Drag the divider to resize the apps or move one of them off the screen.



9. Factory Reset

To erase all personal data and downloaded apps from your tablet, you can do a factory data reset.

1. Go to the PC Settings app.
2. Choose Update and recovery > Recovery.
3. Press "Get started" under "Remove everything and reinstall Windows."
4. Follow the prompts to reset your tablet to default settings.

Warning: If you perform a factory reset, all your personal data and files on the tablet will be lost. Please back up any necessary files.

10. Safety Information

1. Never use your device while driving or operating a vehicle.
2. In some circumstances your device may cause interference with other devices.
3. Switch off your device in an airplane, in an area with a potentially explosive atmosphere, or in any other area where its use is prohibited or it may cause interference or danger. Please follow posted regulations.
4. Pacemaker manufacturers recommend keeping a minimum distance of 8 inches between a wireless device and a pacemaker to avoid potential interference with the pacemaker. Consult a physician or the manufacturer of the medical device if you have any questions.
5. Switch off your device in health care facilities when posted regulations instruct you to do so.
6. When connecting to another device, read and follow the safety instructions in that device's user manual. Do not connect incompatible products.
7. Do not place your device in the air bag deployment area of a vehicle.
8. Use only manufacturer-approved accessories. Using generic accessories may shorten the life of the device or cause it to malfunction.
9. Keep your device dry. Humidity or liquids may damage the device.
10. Do not use or store the device in dusty or dirty areas, in extremely hot or cold environments, near magnetic fields, or with hard objects that could damage the device.
11. Do not drop your device or impact it with hard objects.

11. Specifications

Display: 10.1-inch IPS 10-point touch screen, resolution 1280*800

CPU: BayTrail-CR, quad-core, Z3735F

Internal Storage: 32GB

RAM: 2GB

Ports: Micro SD card and micro USB

Wi-Fi: 802.11 B/G/N

Power Adapter: 5V-2.1A

Operating System: Windows 8.1

Battery: 7000 mAh Li-Polymer

Cameras: 2M front and rear

FCC Warning Statement

FCC Statement This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation .

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If

this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



530 Showers Dr., Suite #7-204
Mountain View, CA 94040
Tel. 1-888-33-Tivax (1-888-338-4829)
(9am-5pm PST, Mon-Fri)
Fax: 1-650-963-3585
Website: www.tivax.com
Email: support@tivax.com