


Installing and Connecting the AKL08RF Zigbee Zone Wiring Centre


Use the AKL08RF zone wiring centre to simply and safely connect thermostats and corresponding thermal actuators or motorised valves. The AKL08RF connects to the wireless network through the AC10RF coordinator or the Universal Gateway SG888ZBWH. **One coordinator can support up to nine wiring centres, which means that if you buy more than one wiring centre, you will only need one of the included coordinators. Keep the other coordinators in a safe place as spares. If you are using the Universal Gateway SG888ZBWH please remove the AC10RF coordinator from your system.** Install the AKL08RF only in dry and closed interior rooms. Relative air humidity in the room may not exceed 95%. Clean the AKL08RF only with a dry and soft cloth. Do not use solvents or aggressive cleaning agents.



- 1** A. Remove the plastic cover by turning the screw 90° to the Unlock position.
B. Remove the High voltage cover.
C. Detach the 24V supply connection.
D. Remove the white terminal for access to the power cord connections.
E. Insert wires for the Power, Pump and Boiler and fasten securely.
F. Use the proper wire connectors (purchased separately) for a 120VAC power supply system. After placing the wires through the wire connectors, secure them by tightening the screws.





- 2** Attach the back of the AKL08RF to the wall or in a suitable location.




- 3** **Connect your wiring center to a 120VAC supply**



Connect the wires to the correct terminals.



- 4** Clip in the terminals for boiler and pump connection. Press the terminal button, insert the cable and release the button.




Ensure the Pump and Boiler wires are placed in their respective grooves in the back plate.



- 5** Push in the Dew Point wires in the AKL08RF for a dry contact humidity sensing.




- 6** Push in the CO wires for dry contact heating/cooling changeover switching. An open switch is for heating (red LED). A closed switch is for cooling (blue LED).



● Heating mode
● Cooling mode


- 7** • Bend and place the wires into their correct positions.
• Reattach the 24V supply connection.
• Bend and place the wires into the round holes at the button of the AKL08RF for actuators/motorised valves. You can add up to 4 actuators or motorised valves for each zone.
• Reattach the white cover to the wiring center and secure it with two screws.



- 8** Set the boiler delay, wireless, and thermal actuator jumpers.

Jumper Settings/Positions for Pump/Boiler On/Off Delay

The pump/boiler on delay and the pump off delay are fixed 3 minutes in the software and at 0 in the terminal. The default setting for the boiler off delay is also 0 minutes, but can be changed to 15 minutes. To do this, carefully remove the jumper and re-insert it in the other position as shown below:




Wireless
The default setting for the wireless connection is internal (INT). If the external antennae A8RFA is used change this setting (EXT). Carefully remove the jumper and re-insert it in the other position as shown below:




Type of Actuator

The default setting for the type of actuator is normally closed (NC). To change this setting to normally open (NO), carefully remove the jumper and re-insert it in the other position as shown below. **Note** that the actuator setting and thermostat setting must be the same.



- 9** Make sure there is the correct fuse (4 Amp).




- 10** Re-attach the High voltage cover and secure it with two screws.



- 11** If you are not using the SG888ZBWH Gateway then plug in the AC10RF coordinator.



- 12** Re-attach the plastic cover. Turn the screw in the lock position. Switch on main power supply to the unit. The red LED comes on.



- 13** If you need to install the specified external antenna and have set the wireless jumpers to EXT:

- a. Disconnect power.
b. Remove the protective cap from the antenna connection on the bottom of the AKL08RF/SAA6MI1.
c. Screw the antenna into the AKL08RF/SAA6MI1.
d. Change the INT/EXT jumper position to EXT position.
e. Reconnect power. The AKL08RF/SAA6MI1 will now use the external antenna and not the internal antenna.



The antenna (type A8RFA, gain 2.15dBi, made by Salus) for AKL08RF/SAA6MI1 is sold separately.

LED indications

Name	Colour	Meaning
Power	●	AKL08RF is supplied with 120V power
G1	●	Wireless network activity on group 1 thermostats
G2	●	Wireless network activity on group 2 thermostats
Network Status	●	AKL08RF is waiting to pair
	●	AKL08RF is connected to the wireless network
Zone 1 actuators	●	Demand from group 1, zone 1 thermostat: actuator open
Zone 2 actuators	●	Demand from group 1, zone 2 thermostat: actuator open
Zone 3 actuators	●	Demand from group 1, zone 3 thermostat: actuator open
Zone 4 actuators	●	Demand from group 1, zone 4 thermostat: actuator open
Zone 5 actuators	●	Demand from group 2, zone 1 thermostat: actuator open
Zone 6 actuators	●	Demand from group 2, zone 2 thermostat: actuator open
Zone 7 actuators	●	Demand from group 2, zone 3 thermostat: actuator open
Zone 8 actuators	●	Demand from group 2, zone 4 thermostat: actuator open
Pump	●	Pump on
Boiler	●	Boiler on
CO	●	Heating Mode
	●	Cooling Mode

Coordinator

Connecting the AKL08RF (s) to the ZigBee Wireless Network

- On powering up the AKL08RF, all actuator LEDs light up green then go off, then the Network Status LED flashes green.
- Press and hold the button on the coordinator for five seconds. The button flashes red to indicate the coordinator is ready to pair. The Network Status LED on the AKL08RF goes steady green when connected.
- Repeat the process for every AKL08RF in the system. Note that one coordinator can support up to nine AKL08RFs.
- To identify your AKL08RF (WC) number press Pair for one second. The LED on the zone number lights green: Zone 1 = WC-1, Zone 2 = WC-2, and so on. The Network Status LED is used to identify WC-9.
- To pair your Salus thermostats, see your thermostat manual.
- Press the coordinator button for five seconds until the LED flashes steady red.

Note: To restore the AKL08RF back to factory default settings at any time, using a suitable tool, press the Reset button to the left of the pair button.

Checking the System Configuration and Communication

- Press and hold the coordinator button for one second. All devices connected to the system flash. To stop checking, press and hold the coordinator button again for one second.
- Press and hold the Pair button on the WC for five seconds. All devices connected to the AKL08RF will flash. To stop checking, press and hold the Pair button again for five seconds.

Deleting all Devices from the Wireless Network

- To delete all devices connected to the network, press and hold the coordinator button for 15 seconds. The colour of the button changes from red to amber.
- To delete all devices connected to the AKL08RF, press and hold the pair button on the AKL08RF for 15 seconds. The G1 and G2 LEDs turn from flashing red to solid red then go off.

Note: After all devices have been deleted from the wireless network, they will need to be reinstalled. Refer to the instruction manuals.

Universal Gateway

Connecting the AKL08RF (s) to the ZigBee Wireless Network

- On powering up the AKL08RF, all actuator LEDs light up green then go off, then the Network Status LED flashes green.
- Remove the coordinator, access the Wise.ly App and add your AKL08RF. When in Pairing Mode, the Universal Gateway will start flashing red. The Network Status LED on the AKL08RF goes steady green when connected.
- Repeat the process for every AKL08RF in the system. Note that one Universal Gateway can support up to 100 devices (thermostats, ARV's, etc.).
- To identify your AKL08RF (WC) number press Pair for one second. The LED on the zone number lights green: Zone 1 = WC-1, Zone 2 = WC-2, and so on. The Network Status LED is used to identify WC-9.
- To pair your Salus thermostats, see your thermostat manual.
- The Universal Gateway will turn solid blue automatically, once the pairing process is complete.

Note: To restore the AKL08RF back to factory default settings at any time, using a suitable tool, press the Reset button to the left of the pair button.

Checking the System Configuration and Communication

- Go to the Wise.ly App and press the Identify button. The device will start flashing. Stop the identify process by pressing the button from the App again.
- Press and hold the Pair button on the WC for five seconds. All devices connected to the AKL08RF will flash. To stop checking, press and hold the Pair button again for five seconds.

Deleting all Devices from the Wireless Network

- You can remove your devices from the Wise.ly App. Equipment, All equipment menu.
- To delete all devices connected to the AKL08RF, press and hold the pair button on the AKL08RF for 15 seconds. The G1 and G2 LEDs turn from flashing red to solid red then go off.

Note: After all devices have been deleted from the wireless network, they will need to be reinstalled. Refer to the instruction manuals.