

About This Manual



WWW.AKUVOX.COM



INDOOR MONITOR

Administrator Guide

S562W

Thank you for choosing the Akuvox S562Wseries indoor monitor. This manual is intended for the administrators who need to properly configure the indoor monitor. This manual is written based on firmware 562.30.0.114, and it provides all the configurations for the functions and features of the S562W series indoor monitor. Please visit the Akuvox website or consult technical support for any new information or the latest firmware.

Product Overview

Product Overview

It can be connected with the Akuvox door phone for audio/video communication, unlocking, and monitoring. Residents can communicate with visitors via audio/video call, and it supports unlocking the door remotely. It is more convenient and safer for residents to check the visitor's identity through its video preview function. S562W series are often applied to scenarios such as villas, apartments, and buildings.



Model Specification

Model	S562W
Touch Screen	✓
Resolution	1024x600
Wi-Fi	IEEE 802.11 b/g/n
Bluetooth	×
NFC	×
RS485	1
Alarm In	8

Introduction to Configuration Menu

Introduction to Configuration Menu

Status: This section gives you basic information such as product information, Network Information, and account information, etc.

Account: This section concerns SIP account, SIP server, proxy server, transport protocol type, audio&video codec, DTMF, session timer, etc.

Network: This section mainly deals with DHCP&Static IP setting, RTP port setting, and device deployment, etc.

Device: This section includes time&language, call feature, screen display, multicast, audio intercom feature, monitor, relay, lift import&export, door log, and web relay.

Contacts: This section allows the user to configure the local contact list stored in the device.

Upgrade: This section covers firmware upgrade, device reset&reboot, configuration file auto-provisioning, and PCAP.

Arming: This section covers the configuration including arming zone setting, arming mode, disarm code, and alarm action.

Security: This section is for password modification, account status & session time out configuration, as well as service location switching.

Settings: This section includes the RTSP, power output.

Akuvox
Open A Smart World

S562W



Homepage



Status



Account



Network



Device



Contacts



Upgrade



Security



Settings



Arming



Status » [Info](#)

Product Information

Network Information



FCC Caution:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment .

This transmitter must not be co - located or operating in conjunction with any other antenna or transmitter.

This equipment should be installed and operated with minimum distance 20cm between the radiator&you body.