


User Manual



Description on Functions



Description on Functions



Description on Functions



Content

Introduction	1
Safety Instruction	2
Technical Specification	4
About the POS	5
Quick Start	6
Charging the Battery	6
Startup	6
Open the Screen	6
Close the Screen (Standby)	7
Shutdown	7
Home Page	7
Creat Folder Icon in Desktop	8
Remove the Icones in Desktop	8
Change he Wallpaper of Desktop	9
Wi-Fi Settings	9
Connect Wi-Fi	9
3G	10
Connect 3G	10
Camera	13
1D Barcode	13
Browser	14
Photo Gallery	15
View Pictures	15
File Manager	16
Save Storage	16
Insert Micro SD Card	16
Uninstall and Removed Micro SD Card	17
Connect kiosk to Computer	18
Safety Setting	19
Backup and Reset	22
Swipe Card and Printer	23
Troubles Shooting	27

Introduction

Dear User,

Thank you for purchasing our product. Please read the instruction manual carefully. Do not use the product, if you don't understand instructions included in this manual.

We have done our best to make a complete and accurate manual; however, we cannot ensure that there are no errors or omissions. We do not assume responsibility for product damage or loss of data due to your improper handling. We will update this manual if any improvement without notice. The trademarks and trade names mentioned in this manual belong to their respective companies or organizations.

Safety Instruction

Before operation of the POS, please read this chapter and teach your kids about this information. For further details, please refer to the safety instructions and announcement.

- **Warning:** Please don't disassemble the POS and accessories. Only authorized agent has access to service the POS.
- **Warning:** Never use the POS in rain or other humid environment to avoid fire or electric shock.
- Do not use headphones at high volume; otherwise it will damage your hearing.
- This POS is not waterproof. Do not place the equipment in water (dripping environment) or other objects filled with liquids, such as vases.
- Do not place the product in a hot environment, heating equipment or direct sunlight.
- Do not place this product on an unstable stand or table, lest it fall, causing unnecessary damage and personal injury.
- Do not place heavy or sharp objects on the LCD screen or on the machine.
- Please use the standard power adapter. We do not responsible for damage to your machine caused by using of the other power adapter
- When connecting the power cord, make sure that nothing rests on the power cord, and the location where the power cord will not be stepped on or cause to stumble.
- Please unplug the power cord if not using the POS for a long time.
- There may be explosion if battery incorrectly replaced.
- Please replace only with the same type or equivalent type of battery.
- The battery must not be exposed under sunshine, fire or overheated environment.

Cleaning

- Before cleaning the machine, make sure that the machine is turned off.
- Do not directly spray cleaning fluids or spilled on the LCD screen or plastic case.
- Please use a clean, soft, lint-free cloth to clean the LCD screen. If it is difficult to remove stains, use a clean, soft, lint-free; please wipe the screen with alcohol-free ammonia-based cleaner.
- Please use a soft, dry cloth to clean the plastic case. If the stain is difficult to remove, please use a clean, soft, lint-free cloth, stained with a little ammonia-free non-alcoholic ingredients, and non-abrasive cleaner to wipe the surface of the shell.
- Use a soft, dry cloth to clean the POS.

Disclaimer: All authorized dealers do not recommend that you use any cleaners containing ammonia or alcohol to clean the LCD screen or plastic casing. Cleaners containing these ingredients to cause some damage on LCD screen, which dealers will not responsible for it.

Technical Specification

- Operation System : ANDROID 4.2.2
- Processor: ARM Cortex A7 All-winner A20 Dual Core
- Memory : 1GB DDR3
- Storage: 8GB; External Storage: Micro-SD Card
(Max. support 32GB)
- LCD: 7.0 inch TFT 1024X600 resolution
- Touch Panel: Capacitive touch screen
- Internet Connection: Wi-Fi 802.11b/g/n
- Battery: 7.4V /4000 mAH
- Battery working time: 5~6H
- Head of printer: Three-track magnetic head
- Connected IC Card: ISO7816Smart CPU Card
- Unconnected IC Card: ISO14443 TYPE A Smart CPU Card
- Printer: 58mm Printer
- 3G Function: available
- BT: available
- Camera: Front 2.0 MP
- NFC: available
- Barcode: 1D barcode (optional)

About the POS

You can connect by below steps:

- Browsing internet through Wi-Fi or 3G;
- Access to online services, such as music and video, social networking services, news, clocks and other services;
- Visit thousands of applications from Android market;
- View photos;
- Take pictures;
- Connected by inserting a Micro SD card (sold separately) extended memory;
- Connect to Financial Card (magnetic stripe card, IC card, and NFC-enabled card);
- Printing.

Quick Start

Charging the Battery

Please put POS to power outlet by standard DC-in power adapter.

Note: Playing time may vary from actual due to special use and settings.

Startup

Long press power key , for three seconds, you can enter into startup picture. The system enters into screen lock status, please unlock it.

Open the screen

Screen will be closed on its own when no operation happens.

If the screen is closed, short press POWER to open the screen.

The screen will be locked.

To open it, left slide to unlock and enter into camera, right slide the unlock icon to unlock the screen (showing as below picture).



Picture 1

Close the Screen (Standby)

When screen is open, press POWER key  the screen will be closed immediately (standby to save battery power).

Shutdown

1. Long press POWER key , it will popup shutdown window.
2. Shutdown window contains mute mode, airplane mode, reboot mode and shutdown four options.
3. Click Shutdown is the last step.

Home Page

In main interface, long press the blank and it will popup windows to set wallpaper, folder, widgets, and shortcut.

The home page can be extended beyond the wideness of screen to provide more space, which you can put new added shortcuts and widgets.

Click the blank space in home page, then slide right or left to extend to the right or left of the screen. In the home page, there are two extended pictures.

Create Folder Icon in Desktop

1. Drag the icons need to be put together on one icon (can also overlay several Icons) as Picture 2.
2. Then click the overlaid icons, the applications can be folded, as Picture 3.

Click the unnamed folder in the black box, it will popup the hidden keyboard, the folder name can be renamed (this is similar with Apple IOS system); the icons position can be changed through long press.



Picture 2

Picture 3

Remove the Icons in Desktop

1. Long press the icons need to be removed, then on the right above of the screen, it will appear  icons.
2. Drag the icon to the above of the remove icon, till the icon become red, and then move your finger to delete the icon.

Change the Wallpaper of Desktop

1. In home page, long press any blank space in main screen, it will pop up a window to change the wallpaper.
2. Click the gallery or wallpaper gallery to select the wallpaper.


Wi-Fi Settings

Connect Wi-Fi

1. In the main menu or interface, choose setting application procedure.
2. Click WLAN, open Wi-Fi, POS will automatically search the available Wi-Fi wireless internet as Picture 4.
3. Choose the Wi-Fi internet you want to connect, if it has password, it will popup the password window, enter password, click connect as Picture 5 to use internet.



Picture 4



Picture 5

4. When POS connect to network, the Wi-Fi icon as Picture 6 will showing on Status Bar, and below the selected internet will show "connected".



Picture 6

Please turn off Wi-Fi when do not need network in order to prolong battery life.

3G

Connect 3G

Insert SIM card into card slot,enter the system main interface.

Camera

In the main interface or desktop, click camera application procedure



enter into camera.

Operation of camera, Switch camera: choose Menu key, click switch front/back camera, as Picture 9.



Camera mode

Picture 9

Barcode

Open the 1D barcode APK, take the POS machine scan the bar code, then the POS will show all of this product information.

Browser

In case of Wi-Fi or mobile internet is connected well (Please refer to wireless and internet setting), click IE browser  in the main menu or desktop to enter the IE interface, as Picture 10.



Picture 10

Click address bar to input the website, click start, enter into related webpage, then you can browse the website information, as Picture 11 and you can click the menu you can refresh, save to bookmarks, share page, bookmarks, history and setting the webpage.



Picture 11

Photo Gallery

Photo gallery  application can auto search photos and video files in SD card, and photo gallery will classify these photos and videos in folder. You can apply photo gallery to view and edit photos, set the photos as wallpaper and watch the video.

View Pictures

1. Click gallery application in main interface.
2. Enter into gallery, click the folder you want to view.
3. Click the picture you want to view; the system will play it in full screen mode automatically.
4. The pictures can be zoom in and zoom out, put two fingers on the screen, the separate the fingers (gather up the fingers, the picture will be zoom in) or double click the screen.

Note: when you browse the pictures, slide left or right to view more pictures.

File Manager

File manager will copy, cut, delete, rename the documents or the folder in the TF card, it also will share the files, install apk etc

In the main menu or desktop, click the document manager icon to enter into documents manager.

Save Storage

Strongly recommend that you purchase and install a Micro SD card, then operate POS and download multimedia files.

Tip: transmission and storage of multimedia files such as music, pictures and video to the Micro SD card, and avoid these types of files stored on the memory inside - this will save memory to allow you to download more applications.

Insert Micro SD Card

Kiosk support Micro SD card, Max. 32GB

1. Insert Micro SD card carefully from front side until locked with a click sound.
2. The Icon of Micro SD card as below Picture 12 will showing on status bar.



Picture 12

3. You can visit Micro SD card by choosing the "File Manager"  from application interface.


Uninstall and Remove Micro SD Card

You can check storage space, micro SD card available space, uninstall micro SD card and remove micro SD card as Picture 13.

Safely remove micro SD card

- 1.Click setting application.
- 2.Click memory.
- 3.Click uninstall micro SD card.
- 4.Now you can carefully press the SD card and remove it safely.

Note: Removing micro SD card safely can protect micro SD card and increase its lifetime.



Picture 13

- Micro SD card can only be inserted from front side, do not insert with strong strength.
- Please assure uninstall micro SD card before remove it.

Connect kiosk to Computer




Picture 14

Kiosk storage configuration

Before transmitting documents, you have to conduct storage configuration for your kiosk:

1. Connect the kiosk and computer by USB cable, the reminder column will show the remind information.
2. Open the reminder board; please view the kiosk status and reminder to learn how to open the board.
3. In the reminder board, click the "USB Connected", it will as below Picture 15, then click "open USB storage configuration".
4. Now the USB is connected successfully.



Picture 15

Copy the document into memory card

1. Connect the kiosk to computer with USB cable.
2. As kiosk storage configuration, it is connected with computer successfully.
3. Open the "My computer" in your computer, check the items in "removable disc".
4. Copy the documents you need into "removable disc".
5. After copying finishes, click "shutdown the USB storage configuration" to uninstall.

Notice: When the kiosk is connected with USB cable, and you open the USB storage configuration, you can't view the memory card through the kiosk. Only after you detach the USB cable, you can view the memory card in the kiosk.

Safety Setting

Set locked screen


Locks the touch screen by unlock icon or password to protect your Kiosk.

Note: After setting screen locked, you should enter the pass code each time when you startup or screen is locked

Set unlocked picture

1. Click setting application in main interface.
2. Click safe.
3. Click locked the screen.
4. Choose picture in text setting area.

5. Click next following the remind message.
6. The unlocked pattern board pop up, there are nine touch spots, connect 4 points from vertical, horizontal or diagonal direction as Picture 16, move your finger from the screen when finish. The system will record your new unlock pattern.
7. Click continue.
8. When you see the reminder, enter the unlock pattern, then click confirm.



Picture 16

Set unlock PIN code

1. Click setting application in main interface.
2. Click safe.
3. Click screen locked.
4. Choose PIN in text setting area.
5. Enter new PIN code (numbers) and click continue.
6. Enter new PIN code again and click confirm.

Set unlock password

1. Click setting application in main interface.
2. Click safe.
3. Click screen locked.
4. Set password in text setting area.
5. Set new password (letters and numbers) and then click continue.
6. Enter the password again and then click confirm.

Unknown source

1. In main interface, click setting.
2. Click safety.
3. Click unknown source, as Picture 17



Picture 17

Nota: Manual installing APK files needs to turn on unknown source.

Backup and Reset

If your kiosk cannot work properly or screen stopped, it can backup by turn-off and then turn on.

If this still not working, then you may need to recovery factory reset, please click reset, as Picture 18, if you need to formulate NAND, please click reset POS.



Picture 18

Note: Factory data reset will erase the data stored on the device, so please make sure make the data backup before this operation.

Swipe Card and Printer

1. Swipe magnetic stripe cards

Hold magnetic stripe cards, and swipe from left to right quickly and slightly. Please make sure you face the front side of the magnetic stripe cards, and magnetic stripe in bottom side. Showing as below picture 19.



Picture 19

2. Read card with NFC function

Please make sure you face the front side of bank card with NFC function, and simply put the card to the place with NFC chip, as below picture 20.

The distance for NFC to read data is 0~3cm.

Remarks: this NFC only support OS14443 Type A card.



Picture 20

3. Insert IC card

Insert IC card as below picture 21. Please make sure you face the back side of the IC card.



Picture 21

4. Thermal Printer:

Close printer cartridge

Put the printing paper outward as below picture 22, and leave some blank paper outside printer cartridge, then close the cartridge.



Picture 22

Open printer cartridge

Put into your fingers into the hollow of cartridge cover as below picture 23.



Picture 23

Then the thumb press one point and upward force your fingers as below picture 24 and 25.



Picture 24



Picture 25

5. Charging Indicator

Charging indicator as below picture 26 is in red color when charging, and in green color when fully charged.



Picture 26

Troubles Shooting

1. Device cannot startup

Make sure that the batteries do not run out.

Make sure the power adapter is securely connected.

Make sure you are using the standard power adapter.

Make sure that the machine was already open.

2. The system is abnormal and can't work.

When you install some third party application procedure, it may cause abnormal work, you can press Reset key (next to power port) to reset the system.

3. Device does not recognize the memory card

Make sure you insert a certified memory card.

Make sure you insert a memory card in correct way.

Please try to restart device without remove the memory card.

4. The device has a low battery warning

Please charge the device before continues to use while it's in low power.

5. Device can't connect to Wi-Fi

Make sure the wireless router of internet service can work in normal.

Make sure the Wi-Fi is turn-on, and ensure the device and wireless router in certain distance, and no wall or other barrier between them.

Ensure the user name and password both correct.

6. Device is hot

When many application procedures are used in meanwhile or the brightness of screen open to the lightest or under charging, device may feel fever. It is normal.

7. Media Player no sound

Unplug the headphones, reconnect. Make sure the headphone jack has been deep into the headphone jack.

Volume may be set too low or muted volume is set.

Check the volume settings for software.

8. Actual storage capacity less than the specifications described

Because the device needs to set aside some space to accommodate system applications and data files, so the actual storage capacity will be less than the standard description on.

9. The printer does not print

Temperature of printer core is too high.

Paper loading terminal is not 35mm thermal paper.

Printer out of paper or printing is not installed or installed backwards.

10. Printer is overheating

Immediately stop the printing operation, shutdown, and restart the terminal device later.

This device complies with part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC RF Radiation Exposure and SAR Statements SAR Statement The Archos 7 home tablet has been tested for body-worn Specific Absorption Rate (SAR) compliance. The FCC has established detailed SAR requirements and has established that these requirements. RF Exposure Information The radio module has been evaluated under FCC Bulletin OET 65C (01-01) and found to be compliant to the requirements as set forth in CFR 47 Sections, 2.1093, and 15.247 (b) (4) addressing RF Exposure from radio frequency devices. This model meets the applicable government requirements for exposure to radio frequency waves. The highest SAR level measured for this device was 0.555W/kg.

