

SCREEN ADJUSTMENT

ADJUSTING BRIGHTNESS

The brightness of the screen can be adjusted. (→P.62)

CHANGING BETWEEN DAY AND NIGHT MODE

Depending on the ambient brightness and/or position of the headlight switch, the screen changes to day or night mode.


NOTE

● 8-inch with Navi system only: Regardless of the position of the headlight switch, the screen mode of MAP screen can be changed. (→P.178)

STATUS DISPLAY

The status of the Bluetooth connection, etc. is displayed on the screen.



No.	Name	Conditions
1	Screen hierarchy	Displays the screen context.
2	CD indicator	This icon is displayed when a disc has been inserted.
3 *	The level of Wi-Fi® reception	 When Wi-Fi® function is off, no item is displayed.

No.	Name	Conditions
4	The Bluetooth connection indicator	This icon is displayed when the Bluetooth connection is established.
5	Remaining battery charge	 Low  Full The amount displayed does not always correspond with the amount displayed on the Bluetooth device.
6	Reception level	 Poor  Excellent The level of reception does not always correspond with the level displayed on the cellular phone. The level of reception may not be displayed depending on the phone you have.
7	Active audio source	Select to display the active audio source information, radio frequency, and name of the artist and track currently playing, etc.


*: 8-inch with Navi system/8-inch system only

HOME SCREEN OPERATION

ADDING SHORTCUT ICONS TO THE HOME SCREEN

Shortcut icons for various functions can be added to the home screen when the home screen shortcut function is turned on. (→P.62)

1. Press .
2. Select **Add Shortcut** (Add Shortcut).



3. Select the desired function.

