



OPERATING MANUAL

MODEL:MPD1029B



Carefully read User Guide to operate this unit properly.
Keep for future reference.

Connecting to BT

- Press "MODE" until you hear tow beeps. BT Mode is on pair.
- Turn on your smartphone's BT and search for the device. Then you will read "MPD1029B" on smartphone.
- Connect with "MPD1029B" click the OK on smartphone.
- "Connected" message will appear. Connecton is successful.

(play and select music with smartphone when connected through BT).

MMC Function

- Press "MODE" on remote or "Mode" on back panel to switch to MMC Mode or just insert a MMC card. MMC mode will start automatcally.
- Press "PLAY/PAUSE" to continue play/pause music.
- Press "NEXT" button to go to next song.
- Press "PREVIOUS" to go back to previous song.
- Press "REPEAT" to replay same song.

USB Function

- Press "MODE" on remote or "Mode" on back panel to switch to USB Mode or just insert a USB flash drive. USB mode will start automatcally.
- Press "PLAY/PAUSE" to continue play/pause music.
- Press "NEXT" button to go to next song.
- Press "PREVIOUS" to go back to previous song.
- Press "REPEAT" to replay same song.

FM Radio Function

- Press "MODE" on remote or "Mode" on back panel to switch to FM Mode. Radio will start automatcally.
- Press "PLAY/PAUSE" to enter into automatic FM channel searching.
- Press "NEXT" button to go to next frequency.
- Press "PREVIOUS" to go back to previous frequency.

FCC Statement

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:

- 1) This device may not cause harmful interference
- 2) This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.