

Bluetooth Speaker 5B349BT User manual



Instruction Manual

Please read carefully before use and keep for future reference.

Thank You

We know you have many choices when it comes to technology; thank you for choosing us here at Naxa Electronics. Established in 2001 in Los Angeles, California, we are dedicated to delivering products that entertain and delight.


We trust that you will be happy with your purchase. Please read this manual carefully and save it for reference. You may also find the latest FAQ, documentation, and other product material at our website. Come visit us on the web at www.naxa.com and see all that we have to offer!

In the Box


Please take a moment to make sure that you have everything in the list below. Although we make every effort to ensure that each Naxa device is securely packed and sealed, we know a lot can happen in between us and you. If anything is missing, check back with your local retailer to get immediate assistance. If they cannot help you, please contact our Naxa Support team at www.naxa.com/naxa_support.

- 5B349BT
- AUX cable
- Charging cable
- Carrying strap

At a Glance



- | | | |
|---|---------------------|--|
| 1 | POWER | Set the switch to the "ON" position to turn the speaker on.
Set the switch to the "OFF" position to turn the speaker off. |
| 2 | Status LED | Lights up to indicate which mode the speaker is in. |
| 3 | AUX connector | AUX mode. 3.5mm stereo connection for devices with 3.5mm line-out or headphone output. |
| 4 | DC 5V charge port | Connect to a USB power source with the included cable. |
| 5 | microSD card reader | CARD mode. Load memory cards here. |
| 6 | USB port | USB mode. Load USB memory sticks here. |



- | | | |
|---|---|--|
| 7 | ⏮ | Press to skip to the previous track during playback.
Press and hold to decrease the volume. |
| 8 | ⏸ | Press to pause or resume playback.
Press and hold to change the active mode (Bluetooth®, SD, USB, FM, and AUX). |
| 9 | ⏭ | Press to skip to the next track during playback.
Press and hold to increase the volume. |

Connecting Power

Your speaker has an integrated rechargeable battery. Upon initial use, the battery should be charged fully to ensure optimal performance and battery life.

Use the included USB charging cable to connect the speaker to a USB power source to charge the battery.

- Connect the small end of the cable to the USB charge port [4] of the unit.
- Connect the large end of the cable to a high-power USB port of a computer. The computer should be powered on.

! The battery used in this device may present a fire or chemical burn if mistreated. Do not disassemble, incinerate, or heat the battery. Do not leave the battery in a place subject to direct sunlight, or in a car with its windows closed.
Do not connect the unit to a power source other than that which is indicated here or on the label as this may result in the risk of fire or electric shock.

Using Bluetooth® Mode

Pairing a Device with Bluetooth®

A device must be paired with the speaker before using them together for the first time.

Make sure Bluetooth is enabled on your device before attempting to pair it.

When you turn on the speaker, it will automatically search for a paired device. If it finds a paired device, it will connect to it automatically, and you're ready to play music from that device.

If it does not detect a paired device, it will switch to Pairing mode (the Status LED will [2] flash blue quickly). When the speaker is in Pairing Mode, it will announce itself to nearby Bluetooth devices and accept pairing requests from them.

1. The speaker will announce itself as "NAXA NAS-3071." Use your device to search for nearby Bluetooth devices. (This function is usually in the Bluetooth settings menu; refer to your device's instruction manual to learn more.)

2. Select "NAXA NAS-3083" from the list of found devices.
3. If your device asks for a passcode, use "0000" to complete the pairing process.

When the speaker is paired and connected to a device, the Status LED [2] will blink blue slowly.

i To enter pairing mode when the speaker is already on, turn it off and then back on again.

The speaker can be paired with one device at a time.

Bluetooth® Speaker Controls

When the speaker is connected to a Bluetooth® device:

To do this...	...do this
Start, pause, or resume audio playback	Press ⏸
Skip to the previous track	Press ⏮
Skip to the next track	Press ⏭
Adjust the volume level	Press and hold ⏮ or ⏭

i You may also use your device to control playback. Some devices may not support remote Bluetooth® controls.

Use the speaker to adjust the volume to a comfortable level. Set the volume level of the connected Bluetooth device to maximum.

Using USB & Card Mode

Install a USB drive or microSD memory card and then press and hold **⏸** [8] to set the active mode to USB or CARD.

Install a compatible USB drive or memory card with music files on it.

- The speaker will automatically detect the drive or card and the Status LED [2] will light blue.
- The speaker will automatically switch modes, and attempt to play music from the USB drive or card.

i Please refer to the Specifications section to learn more about compatibility.

To do this...	...do this
Start, pause, or resume playback.	Press ⏸
Skip to the next track.	Press ⏭
Skip to the previous track.	Press ⏮
Change the active mode (Bluetooth®, SD, USB, FM, and AUX).	Press and hold ⏸

Using FM Radio Mode

Press and hold **⏸** [8] to set the active mode to FM.

i You must connect the included AUX cable to the AUX connector [3] in order to use the FM radio. The AUX connector is also used for FM radio reception.

To optimize reception, extend the connected AUX cable and adjust its position.

Automatic Station Scan

Use the station scan feature to find stations within broadcast reception range and save them to preset memory.

1. Press **⏸** [8] once. The speaker will search for and store stations automatically.

i Scan for new stations any time you move the speaker. Scanning for new stations will replace the old stations.

FM Radio Controls

To do this...	...do this
Tune to the next station	Press ⏭
Tune to the previous station.	Press ⏮
Scan for stations and auto save them to preset memory	Press ⏸


Using the AUX Input Connector

Connect devices without Bluetooth® by using the AUX connection. A 3.5mm stereo patch cable is required to make this connection.

1. Press and hold **⏸** [8] to switch the speaker to AUX mode.
2. Use the included AUX cable to connect the device's headphone or line-out jack to the AUX connector [3] found on the side of the speaker.
3. Turn on the device and the speaker. Lower the volume on both.
4. Set the device volume to 80% of its maximum and then start playback.
5. Press and hold **⏭** [9] to increase the volume gradually to a comfortable level.

i Use the connected AUX device to control all functions in AUX mode. The speaker can only be used to adjust the volume.

Warnings and Precautions



The lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of significant magnitude to constitute risk of electric shock.

The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operation and servicing instructions in the literature accompanying the appliance.

CAUTION

- Do not block the ventilation openings or holes.
- Do not place any naked flames (such as lighted candles) on the apparatus.
- When discarding batteries, follow all local rules and laws governing the disposal of batteries. Consider the environmental impact of your actions!
- To prevent fire or shock hazard, do not expose this appliance to rain or moisture.



9. Ventilation: Slots and openings in the cabinet are provided for ventilation to ensure reliable operation of the product and to protect it from overheating. These openings should never be blocked by placing the product on a bed, sofa, rug, or other similar surface. This product should not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer instructions have been adhered to.
10. Power Sources: This product should be operated only from the type of power source indicated on the rating label. If you are not sure of the type of power supply to your home, consult your product dealer or local power company. For products intended to operate from battery power or other sources, refer to the operating instructions.
11. Grounding or Polarization: This product may be equipped with a polarized alternating-current line plug that has one blade wider than the other. This plug will only fit into the power outlet in one direction. This is a safety feature. If you are unable to insert the plug fully into the outlet, try reversing the direction of the plug. If the plug should still fail to fit, contact an electrician to replace the obsolete outlet. Do not defeat the safety purpose of the polarized plug.
12. Power-Cord Protection: Power supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords at plugs, convenience receptacles, and at the point which they exit from the product.
13. Protective Attachment Plug: The product may be equipped with an attachment plug with overload protection. This is a safety feature. See the operating instructions for replacement or directions to reset the protective device. If replacement of the plug is required, be sure the service technician has used a replacement plug that has the same overload protection as the original plug as specified by the manufacturer.
14. Lightning: For added protection for this product, unplug it from the wall outlet during a lightning storm or when it is left unattended and

unused for long periods of time. This will prevent damage to the product due to lightning or power-line surges.

15. Overloading: Do not overload wall outlets, extension cords, or integral convenience receptacles as this can result in a risk of fire or electric shock.
16. Object and Liquid Entry: Never push objects of any kind into this product through openings as they may touch dangerous voltage points or short-out parts that could result in a fire or electric shock. Never spill liquid of any kind on the product.
17. Servicing: Do not attempt to service this product yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.
18. Damage Requiring Service: Unplug this product from the wall outlet and refer servicing to qualified service personnel under the following conditions: a) when the power-supply or plug is damaged; b) if liquid has been spilled or if objects have fallen into the product; c) if the product has been exposed to rain or water; d) if the product does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operating instructions as improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the product to its normal operation; e) if the product has been dropped or damaged in any way; f) when the product exhibits a distinct change in performance—this indicates a need for service.
19. Replacement Parts: When replacement parts are required, be sure that your service technician has used replacement parts specified by the manufacturer or have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock, or other hazards.

20. Safety Check: Upon completion of any service or repairs to this product, ask the service technician to perform safety checks to ensure that the product is in proper operating condition.
21. Wall or Ceiling Mounting: The product should be mounted to a wall or ceiling only as recommended by the manufacturer.
22. Heat: The product should be situated away from heat sources such as radiators, heat registers, stoves, or other products (including amplifiers) that produce heat.

WARNING:

This product contains lead, a chemical known to the State of California to cause cancer and birth defects or other reproductive harm. **Wash hands after handling.**

FCC NOTICE

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION ON MODIFICATIONS

Any changes or modifications not expressly approved by the grantee of this device may void the authority granted by the FCC to operate the equipment.

This device complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Troubleshooting Guide

This guide lists common problems and their solutions. Please refer to this guide before requesting service. If you need further assistance, please contact Naxa Technical Support (www.naxa.com/naxa_support/).

Symptom	Possible Cause	Possible Solution
There is no power.	The battery is exhausted.	Connect the unit to a USB power source to charge it.
	The Power switch is set to OFF.	Make sure that the Power switch is set to the ON position.
The device is unable to connect to the speaker.	The speaker is not in pairing mode.	Reset the speaker (turn it off and then on again.) Wait for the status LED to flash quickly blue.
	Bluetooth may be disabled on your device.	Make sure Bluetooth is enabled on your device. Turn it on if it isn't.

Specifications

Speakers	3W + 8W
Frequency Response	100–20,000 Hz
Removable Memory Support	USB, microSD, microSDHC (max 32 GB)
Playable Media Formats	MP3
Radio Tuner	FM
Input	Bluetooth® 2.1 + EDR
	3.5 mm AUX audio
Power	Rechargeable lithium battery
	USB charge
Battery Life*	Up to 15–2 hours

* Estimate based on playback with Bluetooth at 100% volume. Battery life will vary depending on usage.

Note: Product are improved continuously. We reserve the right to modify the product and specifications without prior notice.

Support

If you have problems with your device, please consult the instructions in this manual. Please also visit us on the web at www.naxa.com to get up to the minute news, alerts, and documentation for your device. For additional assistance, please contact Naxa Technical Support.

NAXA Technical Support
2320 East 49th St.
Vernon, CA 90058

http://www.naxa.com/naxa_support/