

More Access to Resources

1 Statement

Thank you for purchasing. If you have any questions,, please feel free to contact Us. This manual applies to our Standard and to the high-definition network camera products Wineglass IR waterproof camera as an example, the remaining models, please refertothe manual operation.

This manual operation only for a brief description of the product, more product information please phone to scan the CD- ROM.

We will update the contents of this manual based on product enhancements, and will update the products or procedures described in this manual regularly. Updated content will be added in the new version, without notice.

Outlook & interface

Am

RJ45 interface CDC12V input GNetwork cable port waterproof cap @Audio Input

3 Bootup&IPconfigure

3. 1 Boot up

Please use the formal 12V DC power adapter; otherwise the camera will work abnormal or even damage.

Please Use the positive power of about 50 Seconds of network cameras start complete, the network camera through a cable connected to the LAN. 3.21P config Speed dome default IP config: 【IP address】 :default is 192.168.1.10; 【Subnet Mask】 :default is 255.255.255.0; 【Default Gateway】 :default is 192.168.1.1.

Open the CD, double-click Setup.exe, goto 【English】 > 【Software】 > 【upgrade management】 to install upgrade management tools, then click 【 1P search】 〕 】,all online IP address of the

monitoring devices within the LAN will be searched and displayed.

CD: Choose one IPaddress ChooseIPaddress to config.IPaddress and port are displayed on the right, you can modify the IP parameters and click “Modify” to Save. Note: IP address of the speed dome must share the same network segment with the router and conform to the routers IP, and make sure the IP is not conflicted in the network of LAN. Go to to automatically match subnet mask and default gateway with local computer

4 LAN Access

4.1 1IEAccess

Open web browser, enter IP address, take 192.168.1.10 as an example, input <http://192.168.1.10> to connect.

Enter username and password.(default user name is admin, no password). Change the administrator password timely after login.

After successful login, go to to connect main stream or Sub- stream.

[| CE NO

Function NO. | Function 1 main menu stream selection 3 PTZ control menu | 4
Shortcut menu

Note: Plug-ins need to be installed if you login via IE browser. IE is default to intercept plug-in. Please set IE_ security level, Go to ----< Customized level>--, enable them all. Or go to our official website to download and install plug-ins (<http://www.xmeye.net>); Or get it from the CD and install IE plug-in _V1.1.0.78.exe.

4.2 Client access

1. Open the CD, double-click Setup.exe, go to **【English】** > **【Software】** > **【CMS】** to install centralized network video management software.CMS shortcut icon will be displayed when installed successfully. 2.Double-click CMS shortcut icon , input user name and password(user name: Super, no password) to login.

NO. | Function NO. | Function

1 Channeldisplayarea | 2 Preview area

3 Screen-split menu 4 volume adjustment 5 main menu 6 PTZ control menu 7 Log display area

3.Go to **【 Main Menu】** > **【 System】** > **【Device Manager】** to add speed dome to client, you can add camera via 1IP address, domain name, cloud or ARSP. Added cameras will be displayed in channel display area.

Adding visa IP supports both search adding and manual adding, adding by others methods support manual adding only. CDSearch add: click **【1IP search】** , all online IP address will be displayed, select one, click OK to finish.

Note: Search function only support adding Via IP address.

@ Manual add:, Input the device name, IP address, domain name or serial number of the speed dome, click “ok” to finish the adding.

Note: Domain name, clouds and ARSP are under public network to add the device and that need Speed dome connected to Public network.

4 Double-click speed dome name in , Right-click the channel name to choose main stream or Sub- stream.

5. Control the rotation, zoom, focus, preset points, points cruise and other movements via PTZ control area.

4.3 Mobile Access

Network environment: WIFI, 3G

Mobile system: Android, Apple

Software Name: VmEyeSuper

Software Download: Google Market, App store

Note: if the speed dome can be visited on public network, it also can be achieved via VmEyeSuper on public network.

Note: When left device name shows with red cross, it means speed dome is not connected with cloud service website. 5.2 Mobile Access Network environment: WIFI, 3G Mobile system: Android, Apple Software Name: VmEyeCloud Software Download: Google Market, app store

6.2 Open Audio Click on the icon in the lower right

corner of the Screen [5], the icon changes to

Cloud operations

Cloud technology achieves one step to go on the Internet; it brings great convenience to _ customers in public_ network monitoring. For first time users, please click "Enter Guide", or just skip.

5.1 PC access 1. Visit <http://xmeye.net> to login. Mrim, represent audio open

Login And Preview

3029 / Video Playback

Raeinaer。 umn need to Penemvd

Our standard series network camera

2. Install it step by step according to the

| comes standard with _ motion detection, No. Function No. | Function guides prompt message. video blind, video loss, intelligent analysis, 1 | Playback progress bar | 2 Play RE intelligent alarm function, the user can 3 Pause playback 4 stop

configure the [Device Cfg]> [Alarm] in the 5 Slow play
6 Fast play

smart alarm function set. 7 Previous frame 8 | Nextframe

3.Click "Login" to _ enter cloud service interface, double-click left camera with alias name to connect to the preview, as

C Product warranty card

Note:Audio features require access to the

follows : 。 Product , camera's audio input interface active Se Model 4.After Successful configuration, wherever pickups, NVR or computer access the Name and whenever you are, as long as you can , , rf the Internet, you can get a to the 1 urncane Distributor SU ern8 ,yu 5an 9g8 3008SS -9 6.1Audio Settings Date gdSV 88 , InIeinterface [Device Cfg]> Purchase PC monitoring: Login , - - , , [System]> [Encode] in the audio coding Place <http://www.xmeye.net>;Login with User 。 enable the setting. name and password that you registered Customer Occupation (user name: guest, password: 123 as an — Name example), click Login. ER Post Code 5. After | SCeSs 1 vs 2 Company to server will display on the left device list, In the intelligence analysis function the Address

click the device and get into the preview directly. User can set the warning level and warning

ectional cross area of unidirectional or bidir

the cordon and entered the alert zone alarm

tracking moving objects.

Warranty notice: Warranty period: One year. The Warranty

Card only applies forthe products purchased

Tick here to

from our company,

enable audio

Please take care of it to get more efficient and better service.

| Tel

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Responsible for compliance could void the user's authority to operate this equipment. (Example- use only shielded interface cables when connecting to computer or peripheral devices).

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement:

The equipment complies with FCC Radiation exposure limits set forth for uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.