


Rechargeable and waterproof

©Controller



©Features

1. 100 levels of vibration.
2. 100 levels of static(optional).
3. The levels can be altered by use of up & down button.
4. A tone button activates a tone on the receiver collar.
5. The system can be used for 1 or 2 receivers collar.

POWER SAVING

6. The Receiver Collar will TURN OFF if is unused for 4 minutes.
7. Any movement will activate the Receiver Collar into STANDBY MODE.
8. The Controller will go into STANDBY MODE if there is no operation after 20 seconds and turn off after 2 minutes.

©How to match

1. Charge the Controller

Connect the charger connector to the charging jack. After plug the charger into a standard outlet, The red LED light inside the Transmitter will be lighted. Charge the Controller at least 6 hours for the first charge. After fully charged ,the red LED light will be turned off automatically.



2. Charge the Receiver Collar

After Plug the charger into a standard outlet., the red LED light inside the Collar Receiver will be lighted.

Charge the Collar Receiver at least 6 hours for the first charge. After fully charged ,the red LED light will be turned off automatically.



Controller	Enters sleep mode after 2-3m of no operation	Press Mode for 1s wake to up
Receiver Collar	Lights up once per 5s when working	
	Enters sleep mode after 20s no movement	Apply any movement to wake it up

Low battery indicator: the symbol  will show up on the right down side of LCD screen.

©Install the receiver's contact column

According to the size of the dog and dog hair length, choose the right column for your dog between the tall one and short one.



©How to Use the controller.



●After install the batteries of receiver collar, you will hear a sound “beep”, now press Y button of Controller within 5 seconds, you can hear a “beep” again that means paired successfully. If not, please release the batteries of receiver collar and install them once again, and try the above steps.



●Press the up and down buttons right hand side to set level.



●Choose the different channels for 1 or 2 on Receivers collar.

Note: If you fail to press the Y button after hearing the second beep from the Receiver collar, you need re-sync and start with pressing the Reset button of the receiver collar.



- Press Y button, test bulb will flash, that means Shock function works, you can press the UP/DOWN button to adjust the intensity level.

©How to Test Static Shock Function (after encoding is completed)

1. Take out the test bulb from the package and put it on the Receiver collar's contact points.



2. Press Mode button of Remote transmitter, switch to Shock Mode, confirm LCD display not to be 0, you can press UP/DOWN button on the right side to adjust.



3. Test the Training System

The following methods will help you ascertain whether this training system functions properly. Please make sure that the remote and the receiver collar have been synced successfully.



4. Test the static shock function

- Take out the test bulb from the package and wind its metal wire on the Receiver collar's contact points.
- Pressing the Mode button switch to Shock mode, confirm LCD display not to be 0 , and then press the UP/DOWN button to adjust the intensity level.
- Press the Y button and the test bulb will flash, that means Shock function works.



5. Test the vibration function

- Press Mode button of controller, switch to Vibrate Mode, confirm LCD display not to be 0, and then press the UP/DOWN button to adjust the intensity level.
- Press Y button, Receiver collar will vibrate, that means Vibration function works.



6. Test the beep function

- Press Mode button of Controller, switch to Beep Mode.
- Press the Y button and receive collar will beep, that mean Beep Function works.



7. Test the LED Light function

- Press Mode button of Controller, switch to Beep Mode.
- Press the Y button and then the receiver collar will flash, signifying that the LED Light function works.

©After indicating that the Controller has been synced successfully with the receiver collar. To sync the remote with another receiver collar, simply repeat the previous steps.

Thread the collar strap through the slots on the receiver.



©Package includes

- 1 x Remote
- 1 x Receiver Collar(1 for 1)/ 2 x Receiver Collar(1 for 2)
- 1 x Controller
- 1 x Belt (1 for 1) / 2 x Belt (1 for 2)
- 1 x Test Bulb

Notes for use:

1.The lifetime of the batteries vary according as how often you use the product. Therefore you should often check the batteries by hearing the beep from the Receiver Collar and watching the indicator sign on the LCD screen of the Transmitter.

2.The valid distance of Controller means the straight-line distance between the Controller and the Receiver Collar without obstacles in between. If there are interference signals or signal screening around, the actual remote Controller distance may vary.

3.This product is for pet training. Only by training, the pet can understand the intention of its owner. Good effect can only be achieved after a period of training.

4.Training sessions should be kept positive and short, about 10-15 minutes long each time.

5.Presently, this product is the most effective and safest tool for training pet. Following the correct operational instructions, you can effectively train the pet and bring it no harm.

Frequency: 433.92MHz
Controller: 3.7V 500ma LiP
Receiver: 3.7V 200ma LiP



MADE IN CHINA

§ 15.19 Labelling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

§ 15.21 Information to user.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.