

Quick Start Guide

SABRE IoT Sensor USB



Specifications

Form Factor/Mounting	Desktop with a mounting bracket option and desktop stand
Input	Proximity (125kHz), Smartcards (13.56MHz), Bluetooth Low Energy, NFC (Apple Access) 2.45GHz
Output	Wi-Fi, BLE Mesh Network, keyboard emulation via USB
Current Consumption (@5.3V)	110 mA Average 250mA Peak
Power Supply	5.3V USB at 250mA max
Product Weight	94 g / 3.31 oz +/- 5%
Dimensions	3.9 x 7.4 x 2.3 cm (1.57 x 3.05 x .94 in) `
Color	Black
Operating Temperature	-35...+65°C / -31...+149°F
Storage Temperature	-35...+85°C / -31...+185°F
Operating Humidity	5% to 95% relative humidity (non-condensing)
Connection	USB
Status Indicator	LED and Buzzer
Configuration & Firmware Updates	Wi-Fi (remote via secure cloud portal); BLE (onsite, using administrator's mobile device)
Cable Length	3" and 6"



Quick Start Guide

SABRE IoT Sensor USB




1

Remove the IoT Sensor USB from the box and place it next to your computer.




2

Plug the reader's USB cable into a spare USB port on your computer. Wait while the computer configures the new device.





3

Open the Safetrust Wallet APP and select Admin Installer tab. Make sure your system admin has set you up with this role).



4

With the Admin Installer tab open from the App, bring the phone in range of the IoT Sensor and once visible from the App, highlight and select "Configure".



5

Select the corresponding IDENTITY SYSTEM from the drop down box. Assign a short "Name" and "Description" using alphanumeric characters. Enable the slider for "Self Enrollment" if you intend to allow your users to enroll mobile credential using their existing legacy cards from this reader. Click 'Save' to successfully complete reader configuration.



6

When the IoT Sensor information is successfully saved to the Credential Manager, and assigned to the Identity System, the new description will appear in the Admin Installer with a unique serial number assigned.



SAFETRUST MODEL SL 600
FCC ID: 2ANI5SL600
IC ID: 23133-SL600
SN: 1000000
MADE IN USA

FCC Part 15.19

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC 15.105 Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC 15.21 Change or Modifications that are not expressly approved by the manufacturer could void the user's authority to operate the equipment.

Canada Radio Certification

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.
Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

NCC warning statement
非經核准，公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。低功率射頻器材之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。前述合法通信，指依電信管理法規定作業之無線電通信。低功率射頻器材須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。