

ObserVIEW Help

USER MANUAL



© 2017 Vibration Research Corporation

1. Document Revision	4
2. Getting Started	6
2.1 Connecting and Disconnecting to Remote Devices	7
2.2 Inputs	7
2.3 Opening and Closing VFW Files	8
2.4 Exporting a File	9
2.5 File Properties	9
2.6 User Settings	10
3. Viewing a File	12
3.1 Main Graph	13
3.2 Summary Graph	14
3.3 Cursors	15
3.4 Traces	16
3.5 Adding and Removing Graphs	17
3.6 Editing Traces and Axes	18
3.7 FFT Graph Analysis	18
3.8 Graph Manipulation	19
3.9 Replay Graph	22
4. Editing a File	23
4.1 Sections	24
4.2 Selection Points	25
4.3 Editing the VFW	26
4.4 Edit Point Options	28
4.5 End Point Options	30
5. Notifications	31
5.1 Error Notifications	32
5.1.1 Copy Error Notification	32
5.1.2 Delete File Failure Notification	32
5.1.3 Export Error Notification	32
5.1.4 File Access Error Notification	32
5.1.5 File Append Failure Notification	32
5.1.6 Graph Load Failure Notification	32
5.1.7 Invalid File Notification	32

5.1.8	Invalid VFW Data Notification	33
5.1.9	Malformed File Notification	33
5.1.10	Missing VFW Data Notification	33
5.1.11	Overwrite File Error Notification	33
5.1.12	Paste Failure Notification	33
5.1.13	Primary Source Add Failure Notification	33
5.1.14	Temporary File Not Found Notification	33
5.1.15	VFW Read Error Notification	33
5.1.16	Create Edit Session Error Notification	33
5.1.17	Help File Error	33
5.2	Information Notifications	33
5.2.1	Cut All Not Allowed Notification	33
5.2.2	File Missing Notification	34
5.2.3	Incompatible File Notification	34
5.2.4	Successful Export Notification	34
5.2.5	Successful Registration Notification	34
6.	Hardware Description	35
6.1	Installing the ObserVR1000	40
6.2	Hardware Safety Documentation	42
6.3	Cables, Port Connections, and Pinout Information	43
6.4	RJ45 Connections	46
6.5	Physical Dimensions	47
6.6	Using The Battery	47
7.	Appendix	49
7.1	About ObserVIEW	50
7.2	Microsoft Public License (Ms-PL)	52


Hardware Description

6 Hardware Description



The Vibration Research OBSERVER1000 uses a 100/1000BASE-T port on the rear panel for connecting to a network.

The Gigabit Ethernet port can operate at 100 or 1000 Mbps. The port supports auto-negotiation, full duplex, and flow control. The port also supports Auto-MDX operation to eliminate any requirements for crossover network cables.



The audio input/output connector accepts a headset for audio prompting and voice notes.

The Front Panel has four BNC input connectors which support various analog input devices. Each port includes support for 1 Volt Peak, 10 Volt Peak, and 20Volt Peak input ranges. Each port supports IEPE transducers and smart transducers (TEDS). Channel 1 connector is a BNC.

Channels 2-16 connectors are triaxial. Each connector supports 1 triaxial transducers, or 3 single axis transducer. Microphones, and external conditioners are some of the supported signals and transducers than would use these 6 connectors.

The Tachometer connector includes a configurable 2 channel tachometer. The tachometer channels can be combined for quadrature mode or used as independent tachometers. The tachometer signals can be configured for low-impedance hall effect magnetics of up to +/- 30Volts peak. Included with the tachometer connector is a single TTL discrete input and a single TTL discrete output. The connector is capable of supplying 100mA at 5VDC to condition the input signals.


The three indicators provide operator status.

The Power Indicator is green when the main CPU is running and the external battery is not connected and the internal battery is at greater than 10% capacity. Power Indicator is red when the main CPU is running and the external battery is not connected and the internal battery is at or below 10% capacity. Power Indicator is off when the main CPU is off or held in reset.

The Power Indicator will blink ten (10) times with a period of 200msec, 50% duty cycle, when the OBSERVER1000 shuts down, or is prevented from turning on, due to extreme temperatures. Power Indicator blinks with a period of 800ms and a duty cycle of 50%, for a minimum of three (3) flashes, when the OBSERVER1000 is powering down. Power Indicator is green when the main CPU is running and the external battery is connected and is not detected as having a low voltage. Power Indicator is yellow when the main CPU is running and the external battery is connected and is detected as having a low voltage. Power Indicator is red when the main CPU is running and the external battery is connected and is detected as near shutdown voltage.

The Status indicator is green when all input channels which are configured to record are connected properly. The Status indicator is red if any input channel configured to record is disconnected or faulted.

The System Fault indicator is red when system fault is detected.



The Power Indicator to the left of the on/off power switch shows the same states as the power indicator on the front panel. It is green when the main CPU is running and the external battery is not connected and the internal battery is at greater than 10% capacity. Power Indicator is red when the main CPU is running and the external battery is not connected and the internal battery is at or below 10% capacity. Power Indicator is off when the main CPU is off or held in reset.

The Power Indicator will blink ten (10) times with a period of 200msec, 50% duty cycle, when the OBSERVER1000 shuts down, or is prevented from turning on, due to extreme temperatures. Power Indicator blinks with a period of 800ms and a duty cycle of 50%, for a minimum of three (3) flashes, when the OBSERVER1000 is powering down. Power Indicator is green when the main CPU is running and the external battery is connected and is not detected as having a low voltage. Power Indicator is yellow when the main CPU is running and the external battery is connected and is detected as having a low voltage. Power Indicator is red when the main CPU is running and the external battery is connected and is detected as near shutdown voltage.

Activating the Power Switch for 1 second or more while the OBSERVER1000 is off will turn it on. Activating the Power Switch for 2 seconds or more while the OBSERVER1000 is on will turn

it off within 30 seconds. Momentarily activating the Power Switch will cause the Internal Battery Status Indicator to display on the top of the OBSERVER1000.


The OUT connector can be used to drive external equipment. The connector is capable of +/-10V signal and is typically used to synchronize or drive external complementary equipment.

The SD Card provides storage for recorded data. The insertion and removal of the SD Card is a manual operation. To insert the card press the card until it clicks. Remove the card physically by pressing on the inserted card until it pops out. The lighted pushbutton to the left of the SD card slot is used to allow safe removal of the SD Card. Although physically the SD card may be removed at any time, you will need to allow the OBSERVER1000 to complete any data written to the SD card prior to removal. The SD Eject button blinks RED while write is active. The SD Eject button GREEN when not active/safe to remove. Press the SD Eject button to prepare card for safe ejection, then wait for it to turn GREEN prior to physically removing the SD Card.

The USB port connects to optional Vibration Research supplied data acquisition interfaces and external hard drives. The USB port is capable of supplying 0.9Amps.

The GPS port connects to an optional Vibration Research supplied GPS. The GPS is powered by the OBSERVER1000 and includes position updates at about 1Hz as well as GPS time base synchronization.

The Ethernet port is a 10/100/1000BT capable AutoMDIX port to connect to an external computer. This connection provides the ability to use the OBSERVER1000 tethered as a dedicated data acquisition device. This is in addition to the stand alone operation.



The Start button will start recording to the SD card using the most recently loaded configuration. Stop will stop the recording. The Start button will flash Green during the recording.

6.1 Installing the ObserVR1000

 A NOTE indicates important information that helps you make better use of your controller.

 A CAUTION indicates a potential for property damage, personal injury, or death.

Installation Precautions

 **CAUTION:** Before performing any of the following procedures, read and follow the safety instructions.

 **CAUTION:** If the equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.

 **CAUTION:** Observe the following points before performing the procedures in this section:

- Ensure that the power source circuits are properly grounded.
- Observe and follow the service markings. Do not service any device except as explained in the system documentation. Opening or removing covers marked with a

triangular symbol with a lightning bolt may cause electrical shock. These components are to be serviced by trained service technicians only.

- Ensure that the power cable, extension cable, and/or plug is not damaged.
- Ensure that the device is not exposed to water.
- Ensure that the device is not exposed to radiators and/or heat sources.
- Do not push foreign objects into the device, as it may cause a fire or electric shock.
- Use the device only with approved equipment.
- Ensure that the device does not overload the power circuits, wiring, and over-current protection. To determine the possibility of overloading the supply circuits, add together the ampere ratings of all switches installed on the same circuit as the device. Compare this total with the rating limit for the circuit.
- Do not install the device in an environment where the operating ambient temperature might exceed 55°C (131°F).
- Ensure that the airflow around the front, sides, and back of the device is not restricted.

Site Requirements

Before installing the device, verify that the site selected for the device meets the following site requirements:

- Power — When charging the device or using AC power, install within 1.5 m (5 feet) of a grounded, easily accessible outlet 100-240VAC Nominal VAC, 47-63 Hz.
- General — When charging the device or using AC power, ensure that the power supply is correctly installed.
- Cabling — Cabling is routed to avoid sources of electrical noise such as radio transmitters, broadcast amplifiers, power lines, and fluorescent lighting fixtures.
- Ambient Requirements — The ambient device operating temperature range is -20 to 55 °C (-4 to 131 °F) at a relative humidity of up to 95%RH , non-condensing. Verify that water or moisture cannot enter the device case.
- Ambient Requirements — The ambient AC Adapter operating temperature range is 0 to 60 °C (32 to 140 °F).
- Do not operate this product near volatile or flammable materials.

Unpacking

While unpacking the device, ensure that the following items are included:

- The device
- IEC C13 AC power cable
- Software CD

6.2 Hardware Safety Documentation

Intended Use

The OBSERVER1000 is a high sensitivity, low noise, low voltage data recorder intended to be used to record signals such as those generated by accelerometers and other sensors that generate signals in the $\pm 10\text{V}$ range.

Things to Note

- The mains supply cord is part of the separately certified power supply. Vibration Research is responsible for supplying the correct power supply for the country in which it is sold.
- The external power supply should not be supplied by other than Vibration Research. The external power supply shall be double insulated and LPS rated.
- Ensure any external circuits that provide a source of power connected to the unit, are double or reinforced insulated from mains or separated from mains by basic insulation plus a grounded shield and meet requirements for SELV (Separated or Safety Extra-Low Voltage) levels (under 33Vrms/46.7Vpk or 70Vdc in normal conditions and 55Vrms/78Vpk or 140Vdc single fault).

General Safety for the OBSERVER1000

- To prevent the spread of fire, keep candles or other open flames away from this product at all times.
- Do not place your equipment in a closed-in wall unit or on a bed, sofa, or rug.
- Keep your device away from radiators and heat sources.
- Keep your equipment away from extremely hot or cold temperatures to ensure that it is used within the specified operating range.
- Do not push any objects into the air vents or openings of your equipment. Doing so can cause fire or electric shock by shorting out interior components.
- Avoid placing loose papers underneath your device.
- Do not use your equipment in a wet environment, for example, near a bath tub, sink, or swimming pool or in a wet basement.
- Do not use AC powered equipment during an electrical storm. Battery powered devices may be used if all cables have been disconnected.
- Do not spill food or liquids on your equipment.
- Before you clean your equipment, disconnect it from the electrical outlet. Clean your device with a soft cloth dampened with water. Do not use liquids or aerosol cleaners, which may contain flammable substances.
- Do not operate your equipment with any cover(s) removed.
- Do not use for any purpose other than those for which the unit is intended.

FCC Notices

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

This portable transmitter with its antenna has shown compliance with FCC's SAR limits for general population / uncontrolled exposure. The maximum listed SAR level is 1.07 W/kg (body). The antenna used for this device must not be co-located or operating in conjunction with any other antenna or transmitter.

Manufacturer



Vibration Research
1294 Chicago Drive,
Jenison, MI 49428 USA


6.3 Cables, Port Connections, and Pinout Information

This section explains the switch physical interfaces, and provides information about cables and port connections.


BNC Input and Outputs

BNC connectors are manufactured with 50 and 75 ohm impedance capability. 50 Ohm cables are typically used in this application. BNC Inputs are typically used with accelerometer. Nominal ranging allows for maximum 20 Volts peak input devices. BNC output ranging allows driving maximum 10V peak devices or maximum 1V peak devices.

Connecting and disconnecting Triaxial Input and Tachometer Connectors




The self-latching system allows the connector to be mated by simply by aligning the red dot on the connector with the red dot on the pushing the plug axially into the socket.




The connector is disengaged by a single axial pull on the outer release sleeve. This first disengages the latches and then withdraws the plug from the socket.

Triaxial Input Connector



The lowest number channel is labeled X, second channel is labeled Y, highest numbered channel is labeled Z. Nominal ranging allows for maximum 20 Volts peak input devices. BNC output ranging allows driving maximum 10V peak devices or maximum 1V peak devices.

Tachometer Connector



A triaxial BNC breakout cable may be used on the tachometer connector. If used this way the X connector is the digital output. The Y connector is the first tachometer. The Z connector is the second tachometer. Tachometer channels support Low-Impedance Hall Effect Magentics. Adaptive Threshold Input Voltage Level is +/- 30V, and the tachometers will tolerate +/- 40V. The Digital Input and Output are 3.3V TTL logic levels, and will tolerate 5V TTL logic levels.

Audio Input/Output



The audio Input/Output connector supports a headset typically used with an iPhone(R) 6.

External AC Power Connector

The OBSERVER1000 is powered by using 18V 2.7A DC power adapter included in the package. An optional DC power adapter is available from Vibration Research.



The included power adapter must be powered from 100-240VAC Nominal power outlet at 50/60Hz. The adapter draws less than 1A AC.

External Battery Connector

The OBSERVER1000 supports an optional external battery available from Vibration Research Corporation.


CAUTION: Don't use a battery not supplied by Vibration Research or an authorized service provider.

GPS Connector

The GPS connector supports an optional GPS module available from Vibration Research Corporation.

6.4 RJ45 Connections

The 10/100/1000 BASE-T ports are copper Twisted-Pair ports.



RJ45 Pin Number Allocation for Ethernet Port

Pin No	Function
1	TxRx 1+
2	TxRx 1-
3	TxRx 2+
4	TxRx 2-

5	TxRx 3+
6	TxRx 3-
7	TxRx 4+
8	TxRx 4-

 **CAUTION** Terminals provided on the unit shall be connected only to passive load transducers or source transducers that apply no more than 10V to the circuit that originates from the OBSERVER1000 (or other value that equates to not more than 33Vac rms /46.7V peak or 70Vdc total on the circuit)

 **CAUTION** Other than the IEC inlet for input power to the unit, terminals provided on the rear of the unit shall be connected only to SELV / double insulated circuits of other equipment.

6.5 Physical Dimensions

OBSERVER1000 dimensions

Without external battery

6.3" x 9.8" x 2.2" (160 x 250 x 56 mm)

With external battery

6.3" x 9.8" x 3.2" (160 x 250 x 81 mm)

6.6 Using The Battery

Battery Performance

The OBSERVER1000 battery is not user serviceable.

 **NOTE:** Connect your battery using the AC adapter, to an electrical outlet, when you use your OBSERVER1000 for the first time. For best results, operate the OBSERVER1000 with the AC adapter until the battery is fully charged.

 **NOTE:** Battery operating time (the time the battery can hold a charge) decreases over time. Depending on how often the battery is used and the conditions under which it is used, you may need to purchase a new battery during the life of your OBSERVER1000.

Battery operating time varies depending on usage.

 **CAUTION:** Don't attempt to replace the OBSERVER1000 battery yourself—you may damage the battery, which could cause overheating, fire, and injury. The lithium-ion battery in your OBSERVER1000 should be serviced or recycled by Vibration Research or an authorized service provider, and must be recycled or disposed of separately from household waste. Dispose of batteries according to your local environmental laws and guidelines.