


i-box
Century

WiFi Speaker
79207PI



Contents

1. Safety information	page
Introduction	3
Safety information	3
2. Getting to know your Century Smart Speaker	
Controls and features	6
Controls and button functions	6
LED indicators	6
3. Getting started	
Before getting started -	
Downloading essential apps	7
Phone/Tablet network connection	7
Mains connection	7
Speaker connection main setup	7
Alternative connection setup	8
Naming your speaker	9
Signing into Amazon	9
Setting your location on Alexa	10
4. Operation	
Using the Amazon Alexa app	10
Alexa - Things to try	10
Alexa - Voice control your tunes	11
Using Spotify Connect	11
AUX-In connection	11
Bluetooth pairing	12
Grouping speakers using the i-box player app	12
Speaker reset using the i-box player app	13
Radio presets using the i-box player app	13
Control key functions	14
5. Other information	
Troubleshooting	14
Specifications	15
Disclaimer	15
Declaration of conformity	15
Technical support	15



Introduction

Your new Century plug in Wi-Fi Speaker is a voice-controlled smart speaker with Amazon's intelligent Alexa voice assistant. Just say the wake word "Alexa" and your Century speaker will play music, control your smart home devices, answer your questions, set calendars, report the weather, news, traffic and more.

The two 8W speakers deliver dynamic stereo audio room-filling sound, so you can truly enjoy your favourite playlists from subscription streaming services such as Spotify and Amazon Music as well as many free services such as TuneIn.

Setup is easy with the free "i-box Player" app. Use the "i-box Player" app to access 10000+ skills and services.



Safety information

Important - Please read these instructions fully before installing or operating your speaker.

The power adaptor is used as the disconnect device and must be easily reached to unplug in case of emergency.

Only use the power adaptor supplied if it needs to be replaced make sure the replacement's rating and polarity are the same as that supplied.

Keep away from flame sources such as lighted candles.

Do not expose to dripping or splashed fluids. Objects filled with liquids, such as vases, must not be placed close to the speaker.

The unit should not be exposed to direct sunlight, very high or low temperature, moisture, vibrations, strong magnetic fields, high frequencies and dusty environments.

Do not place the product in enclosed bookcases or racks without proper ventilation. Ventilation should not be impeded by covering the ventilation openings with items, such as newspapers, table-cloths, curtains, etc.

Never attempt to insert wires, pins or other such objects into the vents or openings of the unit.

Do not disassemble or modify the Speaker, there are no user serviceable parts.

If the Speaker is damaged in anyway or malfunctions do not use. Consult a qualified service engineer.

Do not use abrasives, benzene, thinner or other solvents to clean the surface of the unit. To clean, wipe with clean soft cloth and a mild detergent solution.


Do not dispose of this product with household waste at the end of its life cycle; hand it over to a collection centre for the recycling of electrical and electronic appliances.



1. Getting to know your Century Smart Speaker

Controls and features

- | | | |
|--------------------|---------------------------|-------------------------|
| 1. Mic On/Off | 5. Power/Mode | 9. Volume +/- |
| 2. Mic-Tap to talk | 6. Previous/Back | 10. WPS |
| 3. LED Bar | 7. Next/Forward | 11. AUX-In |
| 4. Mics | 8. Play / Pause / BT Pair | 12. 12V DC Power Socket |



Control button functions

Control Buttons	Long Press	Short Press/Rotate
1. Mic On / Off 		Switch Mic/Alexa On/Off
2. Mic-Tap to talk 		Activate Mic to talk to Alexa without saying Alexa first
3.  / MODE	Power ON/OFF	Switch Wi-Fi >> Bluetooth >> AUX-In >> Wi-Fi
4. Previous / Back 		Previous Track
5. Next / Forward 	-	Next Track
6. Play / Pause  / BT Pair	Enter BT Pairing Mode	Play / Pause
7. Volume +/-		 Increase Volume /  Reduce Volume
8. WPS		Enter Wi-Fi connection mode

LED Indicators for Wi-Fi Mode

Indicates	Idle	Listening	Thinking	Speaking	Mic off	System Error/ Setup Mode	Vol +/-
LED							
Colour	No Light	Cyan	Cyan/Blue	Cyan/Blue	Red	Orange	White
Action	-	100% Solid	Fast Alternate	Smooth Pulsing	100% Solid	100% Solid	Gradual On

LED Indicators for Bluetooth Mode

Indicates	Idle	Connecting	No Connection	Connected	Vol +/-
LED					
Colour	No Light	Cyan	Cyan/Blue	Cyan/Blue	White
Action	-	Fast Flashing	Slow Flashing	Smooth Pulsing	Gradual On

LED Indicators for AUX IN Mode

Indicates	Idle	Selected	Vol +/-
LED			
Colour	No Light	Green	White
Action	-	Green Solid	Gradual On

Before getting started

1. Download and install the i-box player app from Play Store or the App Store to your phone/tablet (Search for i-box)
2. Download and install the Amazon Alexa app from Play Store or the App Store to your phone/tablet (Search for Alexa)

i-box player
App Icon







Amazon Alexa
App Icon



Getting started





1. Make sure your phone is connected to the same Wi-Fi network as you wish to connect your speaker to. **This must be a 2.4GHz network - not 5GHz.**
4. Screen (B) will now open, select i-box Century on the device drop down menu and then tap "Next" to enter SETUP menu (C).
5. Tap "Settings" to enter your phone Wi-Fi settings menu (D) and connect to the Century speaker (E) then return to the i-box app, screen (H).

2. Plug the power adaptor supplied with your Century speaker into a suitable mains outlet (use the appropriate mains pin adaptor for your country from the 3 supplied) and plug the power adaptor lead into the DC socket (12) on the back of your Century. The LED bar will light up orange and after a few seconds you will hear a tone to indicate the speaker is ready to connect to Wi-Fi.
3. Open the i-box Player on your phone/tablet, screen (A) will appear showing searching for i-box wireless Hi-Fi system. Tap on "Add Device".



Setup continued



6. In the i-box player app you will first see screen (F) then the SELECT NETWORK screen (G) will open. Select your Wi-Fi network, enter the password and tap "Continue" you will hear a voice prompt "waiting for Wi-Fi connection" and screen (H) will appear then you will hear "Wi-Fi connected" and the Orange LED will stop flashing, screen (I) will open tap "Next". Go to page 9 opposite for further instructions.



Alternative Setup

If in step 5 your i-box player app is unable to connect to your Century speaker or find it, then return to the i-box player app, screen (J) and tap on "Could not find Century_XXXX". Screen (K) will open, follow the instructions "Press the WPS button on the rear of the speaker to activate network setup mode. Then select "Next" to continue."

This will open your phone Wi-Fi settings menu (D) connect to the Century speaker and you will hear a "Connected to speaker" voice prompt then return to the i-box player app, screen (F) and follow step 6. to connect the speaker to your Wi-Fi network.



Naming your speaker

After Wi-Fi connection the NAME DEVICE screen (L) allows you to name your speaker, enter a name or choose from the room list. Speaker default name is Century_XXXX. Tap "Next" to enter screen (M) tap on "Sign in with Amazon"

Signing into Amazon to use Alexa

To use Amazon Alexa you will need an Amazon account. If you don't already have an account go to "www.amazon.com" (in the USA) or "www.amazon.co.uk" (in the UK) to register. Sign in to Amazon using the sign in screen (N).

The next step is to choose your preferred language for Alexa using screen (O).







If for example you live in the UK select "English (United Kingdom)" and follow the on screen instructions.

This will enable Alexa to speak with a British accent and give more relevant answers to any questions relating to the UK.

Screen (P) will open next with suggested questions to ask Alexa.

Always say Alexa first then ask your question/request.

To get the full benefit of Alexa download and open the Alexa app and sign in (screen Q).



Using Alexa - setting location


Many of Alexa's services are location dependent and the default location is Seattle in the USA.

To change the default location* in the Amazon Alexa home screen (S) press the menu symbol top left, tap on tap on settings , tap on "This Device" go to "Device location" and enter your full address on the top line and postcode on the second line.

In settings you can use the menus to connect to apps like Amazon Music*, Live Radio, TuneIn, Spotify† and others as well as reviewing your Alexa history and many other options.

*To use weather, traffic and other "local" services you will need to set your location.

†For some services you will need to open an account.



Alexa - Things to try

Music:

Alexa, play some Prime Music.
Alexa, shuffle my mellow playlist.
Alexa, play my Classic Jazz station.
Alexa, what song is this?
Alexa, buy this song.

Shows, Podcasts, & Radio

Alexa, play the program In Our Time.
Alexa, play BBC 1 radio

Alarms & Timers

Alexa, set a timer for 30 minutes.
Alexa, set an alarm for 8.15 a.m.

Shop Amazon

Alexa, order bin bags.
Alexa, buy more kitchen towels.

Questions & Answers

Alexa, what Italian restaurants are near me.
Alexa, tell me a joke.
Alexa, Wikipedia Winston Churchill.

News, Weather, & Traffic

Alexa, what is the latest news?
Alexa, what's the weather forecast?

Smart Home

Control supported smart home devices like Philips Hue lights. To get started, go to the Alexa App.
Alexa, dim Hue lights to 50%.
Alexa, turn on the fan.

Use These Anytime

Alexa, pair my Bluetooth.
Alexa, stop.
Alexa, volume five. (1-10)
For more examples, go to "Things to Try" in the Alexa App.

Apart from using the Amazon Alexa app menus on your phone to connect and explore apps like Amazon Music, Live Radio, TuneIn and others.

You can review your Alexa history.

View shopping lists.

Check your purchase history.


Check your timer and alarm settings.

Using Alexa to voice control your tunes


Using the Alexa app you can open an Amazon Music account or link to an existing Premium* Spotify account.

Open the Amazon Alexa app. Select Settings, then the Music & Media (screen O). Tap on "CHOOSE DEFAULT MUSIC SERVICES". Screen (P) will open choose Amazon Music or Spotify account and press done.

If you chose Spotify the account is now linked to Alexa. Ask Alexa to play something ("Alexa, play Spotify"). Alexa will now automatically use Spotify as the default music player, so there's no need to specify "on Spotify" with your voice commands.



If you chose Amazon Music as your default, when you ask Alexa to play music by name artist or album without specifying a service, music from Amazon Music or your music library will be played automatically.



If you prefer not to use voice commands to select and play your music can open the i-box player app on your phone and play music from your phone library or any service you are registered with.

Spotify Connect

As an alternative to Alexa voice control, with Spotify Connect you can use the Spotify app on your phone, tablet or laptop to select and play your Spotify tunes sent via Wi-Fi to your Century speaker. Using your phone as a remote control.



Using Spotify Connect

1. Connect your **i-box Century** to your Wi-Fi network.
2. Open up the Spotify app on your phone, tablet or laptop using the same Wi-Fi network.
3. Play a song and select **Devices Available**.
4. Select your **Century_XXXX** and start listening.

*To play Spotify tunes on your Century speaker you will need a Premium Spotify account. For more information go to: www.spotify.com and select your country.

The Spotify Software is subject to third party licences found here: www.spotify.com/connect/third-party-licenses

Connecting to the speaker via the AUX-In socket (11)

Connection for audio devices without Wi-Fi or Bluetooth functions.

1. Connect the audio device to the AUX-In socket (11) using a 3.5mm plug to plug cable (not supplied).

2. Press the **Mode** button (5) twice to select the AUX-In mode, the LED will turn green when this mode is selected and the speaker will say "Line in mode".

3. You can now playback your audio device though the speaker.

Bluetooth pairing

If a Wi-Fi connection is not available you can make a short range connection (up to 10m) via Bluetooth. To enter Bluetooth mode press the **Mode** button (5).

Pairing your speaker with a Bluetooth enabled device:

1. Place the speaker and phone/tablet within 1 metre of each other. Long press on the Pair/▶▶ button (8) the speaker will enter Bluetooth pairing mode, you will hear the message "Bluetooth mode" and the LED status bar will flash blue.
2. Select the Bluetooth menu on your phone/tablet and search for Bluetooth devices, the speaker will appear as "Century_XXXX" in the Bluetooth device list, select and pair.

3. Connection will normally be automatic if a password is required enter (0000). After successful connection you will hear a message "Bluetooth connected" and the LED will stay a constant blue.

Please Note:

1. If the pairing is not successful, turn off the speaker and try pairing again.
2. After successful pairing, paired devices will remember each other. Unless pairing information is deleted, pairing should be automatic when both devices are switched on in range of each other.

3. To pair with a new device follow steps 1-3 above after disconnecting the existing pair.

Re-connecting a paired device

Each time the speaker is turned on in Bluetooth mode, there are two possible outcomes:

The speaker will connect automatically to the last connected device, just press play on your device for playback.

The speaker will be listed on your devices screen as an available output channel, select the speaker as the output channel and play your music.

Grouping speakers using the i-box app




In Wi-Fi mode, switch on the speakers you want to group they will show a solid white LED. In the Device list (A) opposite, you will see "How to switch between solo and multi mode?" tap on this to open the instruction screen (B).

As shown in (B), to pair 2 speakers grab and drag one speaker and drop it over another speaker. The speaker you drag becomes the (Secondary) speaker part of a group and plays the same music as the other (Master) speaker.

To ungroup, grab and drag the secondary speaker below the middle line.

The Secondary speaker becomes a solo speaker again and can play different music independently.

While grouping the LED will flash white on the Secondary speaker when grouped the Secondary speaker LED will change to solid Red.



Grouping 2 speakers

Note: While grouped Alexa voice control will only function on the Master speaker. You can make one or more groups.

You can have more than one Secondary speaker grouped with the same Master.

You can simultaneously control the volume of all the speakers in a group by using the Volume buttons of your phone/tablet.

For a group configuration, you can choose which speaker plays Left (L), Right (R) stereo channel or Left/Right (L/R) for mono, by touching the relevant icon.

Radio presets using the i-box app

To save internet radio stations to presets follow steps 1-3, to recall a preset, steps 4-5.






1. Go to the TUNEIN screen tap on search and the TUNEIN SEARCH screen will open.

2. Find the station you want to make a preset for and tap on the small speaker symbol beside the station and the PRESET screen will open.

3. Up to 5 presets can be saved, tap on a number to save the preset to it, the station will appear beside it and you will hear a message saying "preset saved".

4 & 5. To recall a preset go to the DEVICE LIST tap on settings  select Preset Content.




6. In the PRESET CONTENT screen tap on the preset for the station you want to listen to.



Speaker reset using the i-box player app

If you need to clear the settings on your speaker you can restore factory settings in the i-box player app:

(1.) In the DEVICE LIST tap on settings  (2.) Select SPEAKER INFO and (3.) scroll down and tap "Restore Factory Settings".



Control key functions

Mic Tap to Talk ● (1):

Short press – Activates Alexa ready for voice command without the need to say Alexa first.

Mic On/Off 🎤 (2):

Short press – disables Alexa function (turns off mic) / enables Alexa function (turns on mic)

When Alexa function is Off LED is RED.

Volume +/-

Rotate clockwise to increase volume.

Rotate anticlockwise to reduce volume.

Troubleshooting

1. There is no response from the speaker.

Make sure you are using the power adaptor supplied.

Make sure it is plugged into a mains power socket and the socket is switched on.

Make sure the power adaptor cable is connected to the DC in socket on the back of your Century speaker

2. Your Century speaker cannot connect to your Wi-Fi network

Switch off the power at the mains socket and switch it back on again then try making a Wi-Fi connection following the instructions in this guide.

Check if there is any Internet connection problem.

Make sure you have a Wi-Fi connection between your Century speaker and your phone/tablet.

3. Alexa is not responding

Make sure the microphone is switched on (press the Mic On/Off 🎤 button (2)).

Make sure you are using correct Alexa requests.

Always speak the wake word "Alexa" first when making your request.

Repeat your request.

Speak naturally and clearly to Alexa in English.

Make sure your Century speaker is at least 20cm (eight inches) away from walls or other objects that may cause interference (such as microwave ovens).

Specifications

Power Adaptor Input:	110-240V~50/60Hz
Power Adaptor Output:	12V $\pm$ 2A
Speaker Output:	2x 8 Watts RMS
Speaker Driver:	62mm (2.5")
Frequency Response:	60Hz ~ 20KHz (+/-10 dB)
Signal noise ratio (SNR):	> 70 dB @ 1KHz

Disclaimer

Updates to Firmware and/or hardware components are made regularly. Therefore some of the instructions, specifications and pictures in this documentation may differ slightly from your particular situation. All items described in this guide are for illustration purposes only and may not apply to your particular situation. No legal right or entitlements may be obtained from the description made in this manual.

Declaration of conformity

Hereby, Philex Electronic Ltd. declares that the radio equipment: model Century Amazon Alexa Wi-Fi Speaker for radio broadcast reception in domestic premises is in compliance with the Radio Equipment Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the following internet address: www.philex.com/doc

Technical support

For further help, advice, information or live chat visit www.iboxstyle.com

Amazon, Alexa and all related logos are trademarks of Amazon.com, Inc or its affiliates

All Spotify trademarks, service marks, trade names, logos, domain names, and any other features of the Spotify brand are the sole property of Spotify or its licensors.

© Philex Electronic Ltd 2018.v1
MK42 ONX



Waste electrical and electronic products should not be disposed of with household waste. Please recycle where facilities exist.

Check with your Local Authority for recycling advice.



Support

For further help, advice, information or live chat visit
www.iboxstyle.com

Amazon, Alexa and all related logos are trademarks of
Amazon.com, Inc or its affiliates

© Philex Electronic Ltd 2018.v1
MK42 ONX

FCC Warning:

FCC ID: 2AO5X-79207PI

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.