



SmartFill Gen 3 OPT Installer Manual



Warranty Information
Wiring Diagrams
Installation Menu Options
Website Configuration
SmartDip
ATG

Contents

1	General Information	8
1.1	Introduction	8
1.2	Overview	8
1.3	Terminology	8
1.4	Safety Warnings	9
1.4.1	Installing Company / Personnel Requirements	10
1.4.2	Power Conditioners/Voltage Regulators	10
1.4.3	Backup Generators	10
1.5	Ratings	10
1.6	Certifications/Approvals	11
1.6.1	Regulatory Compliance and RF Exposure Information (U.S. Only)	12
1.6.1.1	FCC Compliance Statement	12
1.6.1.2	RF Exposure Statement (FCC KDB 784748 Section A.8)	12
1.6.1.3	Detachable Antenna Notice	12
1.6.1.4	Approved Antenna Information	12
1.7	Warranty Information	13
1.7.1	WARRANTY	13
1.7.2	WARRANTY CLAIM PROCEDURE	13
1.7.3	GENERAL EXCLUSIONS AND LIMITATIONS OF THE WARRANTY	13
1.7.4	LIMITATION OF LIABILITY	14
1.8	Recommended Tools for Installers	15
1.9	Pre-Installation Checks	15
1.10	Safety Related Inspections and Preventative Maintenance	15
1.11	Cleaning Instructions	15
1.12	Support	15
2	SmartFill OPT Installation and Configuration	16
2.1	Mounting the SmartFill OPT	16
2.1.1	Choosing the Location	16
2.1.2	Mount the SmartFill OPT to the pump / flowmeter	16
2.1.3	Mounting Dimensions	17
2.1.3.1	Wall mounting dimensions	17
2.1.3.2	Pedestal mounting dimensions	18
2.2	Power Wiring	19
2.2.1	General Warnings	19
2.2.2	Emergency Stop Switch Recommendations	19
2.2.3	Backup Generators	19
2.2.4	Bypass Operation	19
2.3	Termination of a Transaction	20
2.3.1	Nozzle Switch	20
2.4	AC System Wiring	21
2.4.1	Single AC Wiring	21
2.4.2	Dual AC Wiring Two Flowmeters	22
2.4.3	Dual AC Hoses with One Flowmeter	23
2.5	Pulser Installation	24
2.5.1	Pulse input theory	24
2.5.2	Acme EPU 200 Pulser	25
2.5.3	Dual Pulse Pulser Connection	25
2.6	Calibrating and Testing the Unit	26
2.6.1	Calibrate by setting the K-Factor	26
2.6.2	Setting the K-Factor using Auto Calibrate	27
2.6.3	Starting a Test Transaction	27
2.7	Gilbarco Comms SmartFill OPT	28
2.7.1	Data Cabling	28

2.7.2	Wiring schematic	28
2.7.3	Gilbarco comms basics	29
2.7.4	5 / 6 Digit purpose and setup	29
2.7.4.1	5 / 6 digit Litres setup procedure	29
2.7.5	Gilbarco comms test procedure	30
2.7.5.1	Comms loop current check	30
2.7.5.2	Comms loop voltage drop check	31
2.7.5.3	Troubleshooting	31
2.8	NZ Pump Protocol (Compac/TT/ Gallagher) Module Wiring	32
2.9	Communications Setup	33
2.9.1	3G/4G	33
2.9.1.1	Details for the 3G/4G SIM	33
2.9.2	Ethernet	34
2.9.2.1	Enable Static IP Addressing:	34
2.10	MicroSD Card	35
2.11	Using the System to Get Fuel	35
2.11.1	Printing a receipt from a previous transaction	38
2.11.2	Supported Payment types	39
2.12	The SmartFill OPT Installation Menu	40
2.12.1	Testing	40
2.12.2	Network	41
2.12.2.1	Network	41
2.12.3	System Information	44
2.12.4	Transactions	44
2.12.5	Unit	45
2.12.6	Time and Date	45
2.12.7	Tanks (This menu only appears if a SmartDip or TLS module is installed in the unit)	46
2.12.8	Pumps/Flowmeters	46
2.12.8.1	Pump Menu When Using Pump Modules	46
2.12.8.2	Pump Menu When Using Bulk Fuel Delivery	47
2.12.8.3	Flowmeter Menu	48
2.12.8.4	Volumetric Units	48
2.12.8.5	Receipt Printer	49
2.12.8.6	Loading paper	49
2.12.8.7	How to fix a paper jam	49
3	SmartFill Gen 3 Website Operation and Configuration	50
3.1	Configuring and Using Website Page	50
3.1.1	Creating Your Website and Adding Your First Unit	50
3.1.2	Logging In Once the Website is Created	51
3.1.3	Dashboards	51
3.1.3.1	Dashboards - Creating a Dashboard	51
3.1.4	Transactions Page	52
3.1.4.1	Transactions	52
3.1.4.2	Transactions - Edit Columns	53
3.1.5	Reports - Configure Reports	53
3.1.6	Setting up Vehicle and Plant Details	54
3.1.6.1	View	55
3.1.6.2	Edit Columns	55
3.1.6.3	Add Vehicle	55
3.1.6.4	Unit Allocation	55
3.1.6.5	Transaction Input	55
3.1.6.6	Time of Day Access	55
3.1.6.7	Fill Limits	56
3.1.6.8	Daily Allocation	56
3.1.6.9	ISO/Access Registration	57
3.1.7	Setting up Drivers	58
3.1.7.1	Add Driver	58
3.1.7.2	Drivers - View	58
3.1.7.3	Drivers - Edit Columns	58
3.1.7.4	Unit Allocation	59
3.1.7.5	Time of Day Access	59
3.1.7.6	Fill Limits	59
3.1.7.7	Daily Allocation	59
3.1.7.8	Transaction Input	59
3.1.7.9	Supervisor Inputs	59

3.1.8	Pricing	60
3.1.9	Tanks	61
3.1.9.1	Tanks Page	61
3.1.9.2	Tank Level - Columns	62
3.1.9.3	Tanks - Dips	62
3.1.9.4	Tanks - Transfers	62
3.1.9.5	Tanks - Deliveries	62
3.1.9.6	Tanks - Fuel Suppliers	62
3.1.9.7	Configure Tanks - Add Smart Tanks	62
3.1.9.8	Configure Tanks - Combine Tanks	62
3.1.9.9	Configure Tanks - Pumps	63
3.1.9.10	Configure Tanks - Transfer Meters	63
3.1.9.11	Configure Tanks - Mobile Tanks	63
3.1.9.12	Configure Tanks - Email Schedule	63
3.1.9.13	Configure Tanks - Email Alerts	63
3.1.9.14	Configure Tanks - Delivery Email Alerts	63
3.1.10	Custom User Data	63
3.1.10.1	Configure User Data - Unit Allocation	64
3.1.11	Jobs	65
3.1.11.1	Add Job	65
3.1.11.2	Configure Jobs - Unit Allocation	65
3.1.12	Units	66
3.1.12.1	Units	66
3.1.12.2	Sites	66
3.1.12.3	Alerts	66
3.1.12.4	Software Update	66
3.1.12.5	Import (From Unit to Website)	66
3.1.12.6	Export (From Website to Unit)	66
3.1.12.7	Add New Unit	66
3.1.12.8	Unit - Configure	67
3.1.12.9	Configure - Pumps	68
3.1.12.10	Tank Gauges	69
3.1.12.11	Configure - Admin	71
3.1.13	Admin	71
3.1.13.1	View/Edit Users	72
3.1.13.2	Invite New User	72
3.1.13.3	My Profile - Change Password	73
3.1.13.4	Setting up 2FA as a User	73
3.1.13.5	Reset or Remove 2FA from your account	73
3.1.13.6	Roles	73
3.1.13.7	Admin - Settings	74
3.1.13.8	API	75
3.1.13.9	Installer Access	75
4	Automatic Tank Gauging Interface	76
4.1	Introduction	76
4.2	Operation	76
4.3	ATG Setup	76
4.4	Smart Fill Set Up	78
5	SmartDip Installation and Configuration	79
5.1	Overview	79
5.2	Installation	79
5.2.1	Tank sensor installation to tank.	80
5.2.2	Tank sensor electrical connections.	80
5.3	Set Up of SmartDip	82
5.3.1	Tanks	82
5.3.2	Tank Gauging Settings	82
5.3.2.1	Tank Configuration	83
5.3.2.2	Tank 1...8 Configuration	83
5.3.2.3	Notifications	84
5.3.2.4	Tank Levels	84
5.4	Troubleshooting	85
5.4.1	Tank level not changing on the website	85
5.4.2	Tank level incorrect	85
5.4.3	No tank level showing	85

5.4.4	Tank level at 100%	85
5.4.5	The SmartDip module	85
5.4.5.1	Open Circuit	85
5.4.5.2	Short Circuit (current > 27.6mA)	85
5.4.5.3	For testing the module there should be a 1K resistor fitted to input 4.	85
6	Troubleshooting at the SmartFill OPT unit.	86
6.0.1	Key Problems ?	86
6.0.1.1	Require vehicle keys ?	86
6.0.1.2	SmartFill OPT does nothing when a key is presented.	86
6.0.1.3	Keys shows as 'INVALID'.	86
6.0.1.4	Lost vehicle keys.	86
6.0.1.5	Lost door lock key.	87
6.0.2	Not asking for additional data (userdata, job, hourmeter, odometer .etc)?	87
6.0.3	Pump / dispenser problems.	87
6.0.3.1	Pump stops after a short period.	87
6.0.3.2	SmartFill OPT is not recording Litres accurately.	87
A	SmartFill OPT Terminology.	88
B	Operating Principles.	89
B.0.1	Relay control.	89
B.0.1.1	Relay.	89
B.0.2	Communication access control.	89

List of Figures

1.1	SmartFill OPT Payment Hardware	9
1.2	Boundaries for Hazardous Locations	11
2.1	Enclosure wall mounting dimensions.	17
2.2	Wall mounting brackets	17
2.3	Pedestal mounting dimensions	18
2.4	Nozzle Switch Wiring for AC and DC Pump Modules	20
2.5	Wiring for Single Hose with Mains Switching	21
2.6	Wiring for Dual Hoses with Mains Switching and Two Flowmeters	22
2.7	Wiring for Dual Hoses with AC Switching and One Flowmeter	23
2.8	Acme EPU200 Wiring.	25
2.9	Dual Pulse Pulser connection	25
2.10	Installation Menu	27
2.11	Testing Menu	27
2.12	SmartFill OPT Gilbarco Wiring diagram.	28
2.13	Multimeter set up to measure DC milliamp in the comms loop.	30
2.14	Multimeter set up to measure voltage drop over the comms loop.	31
2.15	NZ Pump Protocol Wiring	32
2.16	Installing SIM	33
2.17	MicroSD Card Slot on the Door Board	35
2.18	User Interface - Main Screen	35
2.19	User Interface - Payment Selection Screen	36
2.20	User Interface - Pump Selection Screen	36
2.21	User Interface - Choose purchase amount	36
2.22	User Interface - Refer to pinpad screen	37
2.23	User Interface - Main Screen	38
2.24	User Interface - Tap card to find receipt	38
2.25	Supported Payment Types	39
2.26	Installation Menu	40
2.27	Testing Menu	40
2.28	Cellular Menu	41
2.29	Addressing Menu	42
2.30	Static Addressing Menu	42
2.31	DNS Servers	43
2.32	System Information	44
2.33	Transactions Menu	44
2.34	Unit Menu	45
2.35	Time and Date Menu	45
2.36	Pumps Menu - Pump Module(s)	46
2.37	Pump Menu - Bulk Delivery	47
2.38	Flow Meter Menu	48
2.39	Receipt Printer	49
3.1	Initial Account Activation Page	50
3.2	Dashboard Page	51
3.3	Website Transaction Page	52
3.4	Configuring the Transactions Page	53
3.5	Admin Report Settings	53
3.6	Vehicles Page	54
3.7	Time of Day Setup	56
3.8	Admin ISO/Access Registration	57
3.9	Add ISO/Access Pair	57
3.10	Drivers Page	58
3.11	Add Driver Page	58
3.12	Pricing Page	60

3.13	Tanks Page	61
3.14	Add SmartTank Page	62
3.15	Pump to Tank Mapping on the Website	63
3.16	User Defined Data Page	64
3.17	Jobs Page	65
3.18	SmartFill Units Page	66
3.19	Configuration - General	67
3.20	Configuration - Pumps	68
3.21	Configuration - Tank Gauges	69
3.22	Admin	71
3.23	Admin View/Edit Users	72
3.24	Admin Add User	72
3.25	Admin Change Password	73
3.26	Admin - Roles Tab	74
3.27	Admin - Settings	74
4.1	RS232 Wiring	77
4.2	RS485 Wiring	77
5.1	Tank Pressure Sensor Installation	80
5.2	Tank Pressure Sensor Connections	81
5.3	Installer Menu with SmartDip fitted	82
5.4	Tank Gauging Settings Menu	82
5.5	Tank x Configuration Menu	83

Chapter 1

General Information

1.1 Introduction

This manual provides step-by-step instructions for installing a SmartFill OPT system, in the order that the tasks are typically completed during a normal installation. If you have any suggestions or notice any errors in the manual, please contact the manufacturer.

Throughout the manual, you will see the following icons, which are used to highlight important information:

WARNING



WARNING: This icon indicates a potential hazard or mishap that may occur if you do not read and follow the advice provided. It is extremely important that you pay attention to and fully understand any information following a Warning icon.



TIP: This icon provides helpful tips, suggestions, or shortcuts to improve the installation process.

1.2 Overview

The SmartFill OPT is a sophisticated fuel management system that is built to withstand even the most challenging environments. It is housed in a rugged metal enclosure, and its modular design makes it easy to install, upgrade, and repair. To access fuel, users can start a transaction and select the desired purchase amount using a credit card (note: this will place a preauthorization on the user's credit card, but they will not be charged until the transaction is complete). Unit owners can also add keys to the system. All transactions are logged and include the time and date, the amount of fuel dispensed, the pump from which the fuel was taken, and (if applicable) the key or code used.

The unit stores all data locally and can also send it automatically to a secure website (www.fmtdata.com) if it is connected to the internet via Ethernet or a 3G/4G connection. The unit can be configured either through the keypad and on-screen menus or through the website.

1.3 Terminology

Term	Meaning
Key	Swipe card or NFC card/Fob used to identify a driver or vehicle
Module	A plug in module that is used in the unit e.g pump module
AC	Alternating Current - normally 240VAC/Mains power



Figure 1.1: SmartFill OPT Payment Hardware

1.4 Safety Warnings.

WARNING



- **HIGH VOLTAGE WARNING** - Some SmartFill OPT systems involve / require hazardous electrical voltages to be present. Any electrical installation, testing, maintenance or repairs **MUST** be carried out by a suitably licensed electrician.
- To help prevent electrical shock, connect the SmartFill OPT into properly grounded sources.
- To help avoid possible damage to the SmartFill OPT and or other interfacing equipment, wait 5 seconds after turning off all equipment before disconnecting any interconnecting cables.
- To help protect your SmartFill OPT from sudden, transient electrical increases, your SmartFill OPT is equipped with surge protection. All equipment connected to the SmartFill OPT needs to use a surge suppressor, line conditioner, or un-interruptable power supply (UPS).
- Be sure nothing rests on your SmartFill OPT cables and that the cables are not located anywhere where they can be stepped on or tripped over.
- Do not push any objects into the openings of your SmartFill OPT. Doing so can cause fire or electrical shock by shorting-out internal components.
- In addition, take note of these safety guidelines when appropriate:
 - When you disconnect a cable, pull on its connector or its strain-relief loop, not on the cable itself. Some cables have a connector with locking tabs. To disconnect this type of cable, press in the locking tabs before disconnecting the cable. As you pull connectors apart, keep them evenly aligned to avoid bending any connector pins. Also, before you connect a cable, make sure both connectors are correctly oriented and aligned.
 - Hold components by their edges or by their metal mounting brackets.
- Any safety concerns about the system should be immediately reported to your SmartFill OPT supplier and the manufacturer.
- The system must be marked as out of order, suitably tagged as dangerous or out of service and must not be used if any safety concerns arise.

- The SmartFill OPT manufacturer's bear no responsibility / liability for any work carried out by unqualified service personnel.
- All wiring MUST be in accordance with the relevant local / state / national regulations as required, and in accordance with AS/NZS 3000:2000.
- Special care must be taken to ensure that the wiring and location of SmartFill OPT systems is in accordance with the relevant regulations and authorities for that particular location.
- Special attention must be paid to locating equipment in possibly hazardous areas.
- The manufacturer can not provide advice or specifications for correct wiring or hazardous area regulations, and in no way implies its suitability for use in any given area, this information MUST be sought by the installer, from the relevant authorities.
- SmartFill OPT enclosures are not rated for use in hazardous areas, and as such the SmartFill OPT must only be operated in a non-hazardous area.

1.4.1 Installing Company / Personnel Requirements.

- The quality of the installation has a lasting effect on the performance of the equipment, and the value the end user receives from the system. We can not stress enough the importance of safe and high standard installation and commissioning practice's. Thorough initial basic training of the client is also crucial to the client getting the best value from the equipment. Obviously, adequate initial training also reduces the number of support calls that the installer receives.
- The installing company is responsible for ensuring that installation staff are competent, they are suitably qualified and that work is performed in a safe manner to a high standard.

1.4.2 Power Conditioners/Voltage Regulators

In locales where power sources fluctuate significantly and over voltages or brownouts occur, power conditioners or voltage regulators may be installed between the SmartFill OPT and its power source for protection against high or low power inputs. These devices condition or regulate power to a constant or maximum output. Power conditioners maintain a constant power input when voltage may otherwise fluctuate between highs and lows which may not be acceptable to SmartFill OPT. Voltage regulators protect SmartFill OPT from high voltage inputs similar to what may occur when an unregulated generator is initially turned on. Power conditioners are more complex and substantially more expensive to purchase.

1.4.3 Backup Generators

Some facilities are equipped with backup generators to supply AC power when the regular power supply goes down. During start-up of the backup generator the initial power surge may be extremely high until all connected equipment is restored to operation. This power surge has the same potential for damage to the SmartFill OPT equipment as a lightning strike. Ensure the installed equipment is protected (regulated) from current surges during start-up of the backup power source. If possible, turn off the SmartFill OPT power until non-regulated generator power stabilizes.

1.5 Ratings

	AC	DC
Operating Voltage	90 - 250 VAC	10 - 36 VDC
Operating Current	0.38A - 0.15A	2A - 0.6A
Pulser	15V @ 2.5mA	15V @ 2.5mA
Nozzle Switch	3.3V @ 0.2mA	3.3V @ 0.2mA
Fuse Rating	1A	2A
Maximum Switching	250VAC @ 10A	24VDC @ 5A
Delay Power Switch	N/A	36V @ 2A

1.6 Certifications/Approvals

Figure 1.2 illustrates the boundaries of a hazardous location which dispenses flammable liquids such as gasoline and E85. These standards are defined in Australian Standard AS/NZS 60079.10.1:2009




Figure 1.2: Boundaries for Hazardous Locations

The boundary area around a compressed natural gas (CNG) dispenser is different. It extends 5 feet from, and above, the dispenser. Any electrical device installed within these boundaries must be intrinsically safe or must be enclosed within an explosion-proof enclosure. Intrinsically safe devices are generally limited to very low voltage and low current devices, such as that portion of a pulser before the barrier. Examples of explosion-proof enclosures are rigid metal conduit, and junction boxes and conduit fittings approved for use in hazardous locations. If the electrical device is not intrinsically safe, or is not explosion-proof, then it must be installed outside the hazardous area.

1.6.1 Regulatory Compliance and RF Exposure Information (U.S. Only)

1.6.1.1 FCC Compliance Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

1.6.1.2 RF Exposure Statement (FCC KDB 784748 Section A.8)

To satisfy FCC RF exposure requirements, this device and its 4G/LTE antenna must be installed and operated with a minimum separation distance of 20 cm (approximately 8 inches) between the antenna and all persons during normal operation.

Note: While the device includes an NFC reader designed for close-range interaction (e.g., under 1 cm), the 4G/LTE antenna is physically located more than 20 cm away from the user interaction area. This ensures compliance with RF exposure limits.

1.6.1.3 Detachable Antenna Notice

This device is designed to operate only with the manufacturer-provided detachable antenna. Use of any other antenna is strictly prohibited and may result in non-compliance with FCC regulations.

1.6.1.4 Approved Antenna Information

Antenna Type	Connector Type	Max Gain (dBi)	Impedance (Ω)
4G/LTE External Fiberglass Antenna	SMA Male	1.66	50

1.7 Warranty Information

1.7.1 WARRANTY

1.7.1.1 FMT shall provide to the Customer a warranty for all Goods against defects in materials and workmanship for a two-year period (the Warranty Period) commencing on the sale date to the Customer (the Warranty Commencement Date) of the relevant Goods.

1.7.1.2 The Product Warranty only applies to the Customer who originally purchased the Goods. It is personal and may not be assigned or transferred without the prior written consent of FMT.

1.7.1.3 Subject to Clause 1.7.2, FMT (at its option) will replace or repair for the Customer, free of charge, any part or parts, found upon examination by FMT, to be eligible for this Product Warranty. If any Goods or part is replaced or repaired under this Product Warranty, that Goods or part will carry the remainder of the Product Warranty from the Warranty Commencement Date.

1.7.1.4 The Product Warranty is in addition to any consumer guarantees existing available to the Customer at law and the Product Warranty does not exclude such consumer guarantees.

1.7.1.5 All enquiries regarding the Product Warranty may be directed to FMT at +61 8 8240 5585.

1.7.2 WARRANTY CLAIM PROCEDURE

1.7.2.1 In order to make a claim under the Product Warranty, the Customer must notify FMT in writing of any defect in the Goods discovered during the Warranty Period as soon as the Customer becomes aware of the alleged defect specifying in reasonable detail the nature of the defect. Such notice may be made by any one or more of the following methods:

i. By Post addressed to: Fluid Management Technology Pty Ltd, PO Box 1224, Beverley, South Australia, 5009, Australia

ii. By Email to: sales@fluidmt.com.

1.7.2.2 Upon FMT verifying the validity and currency of the Product Warranty in respect of the Customer's claim, the Customer must upon request by FMT send the Goods to FMT.

1.7.2.3 The Customer must ensure that the Goods are properly packaged so as to ensure that no damage occurs to the Goods during transit. The Customer is responsible for all posting, shipping, freight and insurance charges in respect of the Goods returned to FMT. Whilst in transit, the Goods remains at the Customer's risk.

1.7.2.4 FMT may, in its absolute discretion reimburse the Customer for the Customer's cost to undertake such repairs to the Goods, provided that the Customer has first provided to FMT a written quote as to the estimated costs of the Customer undertaking such repair, and FMT has approved (in writing) the Customer to proceed with such repairs up to that agreed estimated cost.

1.7.2.5 Upon receiving the Customer's written quote, the Customer acknowledges that FMT shall have sole discretion as to whether FMT engages its own contractors to undertake the required repairs, or if the Customer may undertake such repairs.

1.7.2.6 The Customer agrees that FMT shall have no obligation or liability to reimburse the Customer for the costs of any repairs undertaken by the Customer that have not been agreed in writing with FMT beforehand.

1.7.2.7 FMT reserves the right at its sole discretion to determine whether to replace or repair, free of charge, any part or parts, or the entire Goods.

1.7.2.8 The Customer is responsible for all packaging, posting, shipping, freight and insurance charges in respect of any Goods returned by FMT to the Customer. The Customer agrees to pay such charges upon the same payment terms as apply to FMT's sales of Goods current at the time of the Product Warranty claim. Whilst in transit, the Goods remains at the Customer's risk.

1.7.3 GENERAL EXCLUSIONS AND LIMITATIONS OF THE WARRANTY

1.7.3.1 The Product Warranty is limited to replacement or repair of defective parts or defects in workmanship and does not include any labour costs (whether such labour costs are supplied by FMT or the Customer).

1.7.3.2 In the event that no identical parts are available to repair the defective Goods, FMT has the right to replace the Goods with similar Goods of equal age and condition as the defective Goods, or offer the Customer the choice to upgrade the defective Goods. These may incur additional costs to the Customer and the Customer in those circumstances agrees to pay those additional costs upon the same payment terms as apply to FMT's sales of Goods current at the time of the Product Warranty claim.

1.7.3.3 Replacement Goods or parts may include remanufactured or refurbished parts or components. Repaired or replaced Goods will continue be warranted for the remainder of the Product Warranty from the Warranty Commencement Date.

1.7.3.4 The Product Warranty does not cover consumables, including but not limited to batteries and surge protectors.

1.7.3.5 The Warranty will not apply, and FMT will be under no obligation or liability whatsoever if, in the opinion of FMT, the Goods have been:

- i. installed and maintained other than in compliance with FMT's product specifications, instructions and directions;
- ii. installed or used other than in a manner approved by FMT as suitable for the Goods;
- iii. handled in a manner which contravenes any direction, instruction or warning issued by FMT from time to time;
- iv. misused, abused, altered or damaged in any way;
- v. tampered with, including if any factory applied serial number has been altered or removed from the Goods;
- vi. damaged through normal wear and tear including exposure to the elements (on both exposed and unexposed surfaces), exposure to abnormally corrosive conditions, rust, or entry by any insect, vermin or foreign object in the Goods; or