



册所提到的产品规格和资讯仅供参考, 如有内容更新, 恕	VAP1
行通知。除非有特殊约定, 本手册仅作为使用指导, 本手	VAP1
册的所有陈述、信息等均不构成任何形式的担保。	VAP1


供电电源参数表		
供电电压范围	输入功率	典型供电电源
DC5--15V	≥5W	5V/1A
DC5--15V	≥5W	5V/1A
DC5--15V	≥10W	5V/2A
DC5--15V	≥10W	5V/2A

The diagram illustrates the experimental setup. A laptop is connected to a VME64X-2 interface card. The interface card is connected to a power supply and a monitor. The power supply is connected to the interface card via a cable. The monitor is connected to the interface card via a cable. The interface card is also connected to a power supply via a cable.

[illegible][illegible]

录配置界面，建议使用配置域名：<http://vonets.com>。
行窗口，输入命令：`ping vonets.cfg`，获取设备的

- 原因5: 设备的上一级WiFi热点的参数配置错误。此时只要数并重启设备即可;



NETS is the registered trademark of Shenzhen Tian Network Communication Technology Co., Ltd. All other trademarks or registered trademarks mentioned in this documents are belong to the individual owners. The product specifications and information technology mentioned in this manual are just for reference, if any updates, without other notice. Except special agreements, this manual is just for user guidance, any statements, information and so on in this manual can't constitute the warranty of any forms.

Power supply parameter list		
Power Supply Voltage Range	Input Power	Typical Power Supply
DC5--15V	≥5W	5V/1A
DC5--15V	≥5W	5V/1A
DC5--15V	≥10W	5V/2A
DC5--15V	≥10W	5V/2A

A diagram showing a laptop connected to a power strip. A power cable runs from the laptop's power jack to a power strip, which is plugged into a wall outlet. The power strip has multiple outlets, and the laptop is the only device connected to it.

the hotspot" is default ticked, it means The SSID is associated with the SSID of the source password is the same as the password of the

1) Log in to the configura

monets.cfg (or IP:
er, both user name and

domain name: `http://vonets.cfg`. Or in Windows the command: `ping vonets.cfg`, to get the IP address in configuration page with this IP.

- First, check the status light to know the current state of the device, then according to the state of the device to analyze the reason.
- Reason 1. The distance between the device and source is too long, cause the communication performance degradation, affect the user's access to the Internet. At this time, you can move the device closer to the source.

- Reason 4. The IP address of the device input error. For the new device from the factory, user only need input the correct IP address according to the instruction guide; for the device that has connected the network, user only operate according to the instruction guide.

FCC STATEMENT :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.