




Manual


NÜO AIR
42272 | 42328



GENERAL FEATURES

NÜO AIR (ref. no.: 42272 and 42328)

- Maximum security proximity reader for contactless MIFARE Plus® and NFC cards.
- Reader status indicated via acoustic-light display.
- Communications with authentication and data encryption using AES and 3DES
- IP67 protection and IK08 impact ratings.
- Assembled in an embedded case using a screw-less hidden fastener with an automatic interlock.
- Optional stainless steel casing for surface mounting.



TECHNICAL SPECIFICATIONS

NÜO AIR:

INPUT VOLTAGE	24 VDC
STAND BY POWER	1.7 W - 60 mA
MAXIMUM POWER	2.8 W - 100 mA
READING DISTANCE	4 - 8 cm
COMMUNICATIONS	BYBUS RS-485 Full-Duplex
INDICATORS	Lights automatically regulated according to environment. Different colours and sounds according to status. - Red/White: Terminal offline. - Degraded Red/Pink: Terminal in card enrolment mode. - Flashing blue: Terminal in firmware update mode. - Blue: Terminal on standby. - Green: Access granted. - Red: Access denied. - White: Card writing operation.
OPERATING TEMPERATURE	-25°C to 60°C
READER DIMENSIONS	Height 115 mm, width 115 mm, depth 62 mm



Information



Features




Wiring

TYPE OF WIRING AND WIRING DISTANCE:

The NÜO AIR reader incorporates a male overhead connector.

NÜO AIR is supplied with a 3.5 metre piped cable with 4 wires (2 twisted pairs) and a female connector at one end to correctly connect it.

The other end of the piped cable is connected to a single door controller or to the corresponding Wili following the simple colour coding.



The wiring distance from the reader and the single door controller or Wili should not exceed 15 metres in length under any circumstances.

WIRING SPECIFICATIONS:

The built-in piped cable used to connect the reader has the following technical characteristics:

- Gauge: 0.22 mm
- Arrangement: 2 twisted pairs
- Resistance: <2 Ohms
- Capacitance, core to earth: <160 pF/m
- Capacitance, core to core: <100 pF/m

DISTANCE BETWEEN READERS:

A minimum distance of 12 cm must be maintained for installations using doors with 2 input/output readers or if there are 2 readers that are very close together.




The NÜO AIR reader can be flush mounted in various environments.


The various installation methods are described below:

FLUSH MOUNTING


- 1) Remove the reader from the flush mount support using the detachable clip. Insert it and pull down.




- 2) Using a level, make a hole in the wall measuring 92 x 92 mm and 51 mm deep. Pass the connecting cable through and grout the hole.




- 3) Insert the flush mount support and connect the assembly.



- 4) Insert the reader module into the flush mount support using the detachable clip. Insert it and pull down.




- 5) Set the reader module in place and take out the disassembling lever.





To mount the reader on a plasterboard wall, the support should be screwed using CL82Z-3.1 x 16 countersunk screws (NOT INCLUDED).




SURFACE MOUNTING

The NÜO AIR reader can be surface mounted by using the surface support kit.

Instructions for assembly are as follows:

- 1) Mark the position of the 4 screws used to fasten the surface support to the wall.
- 2) Drill and place the wall plugs for the screws. Screws should have a diameter of 3.5 mm and a minimum length of 25 mm (included).
- 3) Fasten the surface support to the wall.
- 4) Remove the reader from the surface support (see instructions for flush mounting).
- 5) Insert the flush mount support into the surface support.
- 6) Fasten the flush mount support to the surface support using the screws provided.




Once the reader module has been fastened to the wall, use the suction cup provided and the detachable clip to remove it.



NÜO AIR readers can be directly connected to two types of devices depending on the architecture of the installation:

- Connection to a Wili.
- Connection to a single door controller.

The connection to be made for both types of devices is exactly the same. The colour code must be followed. For more detailed information, consult the equipment manuals referenced earlier.



READER WIRING:

COLOUR	SIGNAL	BYBUS
Orange	+ 24VDC	
Orange/White	0V / GND	
Green	RS-485-A	
Green/White	RS-485-B	



Install and connect the reader before powering the system.



NÜO readers use the 24 VDC input voltage corresponding to the controller equipment to which they are connected, the power sources of which are rigorously prepared for such purpose.



These signals must be perfectly isolated in order to prevent damaging the equipment or installation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC ID: 2ARQ3-MTA42328

By TechDesign SL

Model name: Door control system

Model No.: MTA 42328

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.