


# RETEVIS



## MB4 User's Manual




# Contents


|                              |                |
|------------------------------|----------------|
| <b>Supplied Accessories</b>  | <b>-----01</b> |
| <b>Optional Accessories</b>  | <b>-----01</b> |
| <b>KNOW ABOUT THIS RADIO</b> | <b>-----02</b> |
| <b>LCD</b>                   | <b>-----03</b> |
| <b>HOW TO USE THIS RADIO</b> | <b>-----03</b> |
| <b>CTCSS TONE LIST</b>       | <b>-----07</b> |
| <b>DCS CODE LIST</b>         | <b>-----08</b> |
| <b>SPECIFICATION</b>         | <b>-----09</b> |
| <b>CAUTION!</b>              | <b>-----10</b> |
| <b>Guarantee</b>             | <b>-----13</b> |

For downloading further resources:  
Brochures, Software/Firmware, Manual etc, Please contact  
your direct reseller first OR go to website [retevis.com](http://retevis.com) and  
check “support” in the each product link to download it.

**Supplied Accessories**




Microphone




Mobile Bracket




Microphone Hanger




non-slip mat




Pads




Tapping screws



Adjusting screws




Spare Fuses  
5A 250V




User Manual

**Optional Accessories**




DIN Rack



DIN Removal Keys

KNOW ABOUT THIS RADIO



|    |                                                             |
|----|-------------------------------------------------------------|
| 1  | Modulation Mode Select : AM, FM and PA                      |
| 2  | Noise Reduction (NR) On/Off ~ Noise Blanker (NB) On/Off     |
| 3  | CTCSS/DCS Enable ~ Backlight Brightness Setting             |
| 4  | Scan On/Off ~ RF Gain Control                               |
| 5  | Enter into Memory Mode ~ Enter into Channel Storage Setting |
| 6  | Emergency Channel ~ Keypad Lock ~ VOX On/Off                |
| 7  | Menu                                                        |
| 8  | Channel Knob ~ Configuration Select                         |
| 9  | ASQ (Automatic Squelch Control) ~ Squelch                   |
| 10 | Power On/Off ~ Volume Control                               |
| 11 | LCD Display                                                 |
| 12 | Microphone Plug                                             |
| 13 | RX (Receive) / TX (Transmit) LED Indicator                  |
| 14 | External Optional Speaker Jack                              |
| 15 | Antenna Jack                                                |

## LCD



 Key Lock activated

 ROGER BEEP function activated

 VOX function activated

**AQ** ASQ function activated

**NR** NR function activated

**RFG** RF GAIN function activated

**88** Indicates the active channel

**1 3 5 7 9 +** T X or RX bargraph

**AM** AM mode selected

**FM** FM mode selected

**PA** PA mode selected

**NB** NB function activated

**HIC** HI-CUT filter activated

 SCAN function activated

 Memory channel indicator

## DIN rail installation and removal guide



## HOW TO USE THIS RADIO

### 1. Power On/Off the Radio

Turn the VOL knob clockwise to power on the radio, the LCD displays the Norms and then displays channel number.

Turn the VOL knob anti-clockwise, until hear Ka Ta, the radio is powered off.

### 2. Volume Control

Turn the VOL knob clockwise to increase the volume, turn it anti-clockwise to decrease the volume.

### 3. ASQ ~ SQ Control

#### ●ASQ (Automatic Squelch Control)

Turn the **A/S** knob anti-clockwise to the leftmost position enables the **ASQ** function. "**AQ**" appears on the LCD. No repetitive manual adjustment and a permanent improvement between the sensitivity and the listening comfort when **ASQ** is active. This function can be disconnected by turning the switch clockwise. In this case the squelch adjustment becomes manual. "**AQ**" disappears from the LCD.

#### ●SQ (Manual Squelch Control)

Turn the **A/S** knob clockwise to the exact point where all background noises disappear. This adjustment should be done with precision as, if set to maximum (fully clockwise), only the strongest signals will be received.

#### 4. Rotary CH Knob

Turn rotary **CH** knob to change the channel. Clockwise to increase, and anti-clockwise to decrease the channel.

#### 5. UP / DN Buttons on Microphone

Short press **UP / DN** buttons on the microphone to change the channel. **UP** to increase, and **DN** to decrease the channel.

In MENU mode, the **UP** or **DN** buttons allows to select the menu to be set.

#### 6. AM/FM ~ PA

##### ●AM/FM (short press)

Short press  key to modify the modulation mode **AM** or **FM**. Corresponding mode is appears on the LCD.

##### ●PA (long press)

Long press  key to alternate between **CB** and **PA** mode.

When the **PA** mode is activated, the modulation of the microphone and the received signal are transmitted to the internal loudspeaker or external optional loudspeaker connected to jack EXT.SP. "**PA**" blinks alternate with the modulation mode (**AM** or **FM**).

Turn the VOL knob to adjust the PA volume

#### 7. NR ~ NB

##### ●NR (short press)

Short press  key to activate or deactivate the Noise Reduction if a **RX** or **TX NR** set value other than **OFF** has been stored ( consult the Menu Operations).

"**R**" is displayed when the function is active. If both **RX NR** and **TX NR** are set to **OFF**, the "**R**" icon blinks three times on the LCD and the device emits an error beep.

##### ●NB (long press)

Long press  key to activate or deactivate the Noise Blanker.

"**B**" is displayed when the function is active.

#### 8. TSQ ~ DIM

##### ●TSQ (short press)

Select a desired channel, short press  key to activate or deactivate the CTCSS/DCS function.

If a CTCSS/DCS code has been stored ( consult the Menu Operations), if becomes active, "**C**" or "**D**" icon appears on the LCD.

If no CTCSS/DCS code has been stored, the "**C**" icon blinks three times on the LCD and the device emits an error beep.

Note: Codes can only be used in FM.

##### ●DIMMER (long press)

Long press  key to adjust the brightness of the lighting.

#### 9. SCAN ~ RFG

##### ●Channels Scan (short press)

Short press  key to activate the 40 channels scan function. The dot between the two channel digits blinks to indicate that the function is active. The scanning stops as soon as there is a busy channel. In scanning mode, turn the rotary **CH** knob or press the **UP/DN** keys on the microphone to change scan direction. Press any key to exit **SCAN**.

##### ●RFG (long press)

Long press  key to enter the RF GAIN level control, "**G**" blinks and the present RF Gain level appears on the LCD. Turn the rotary **CH** knob or press the **UP/DN** keys on the microphone to change the level of attenuation. Press any key to exit RF Gain level control.

When RFG function is on, "**RFG**" icon appears on the LCD.

## 10. MEM ~ MEM Store

### ●MEM (short press)

Short press  key to enter into Memory Mode, the memorized channel number appears on the LCD. If no storage setting, the device emits an error beep.

Turn the rotary **CH** knob or press the **UP/DN** keys on the microphone to select the pre-stored channel (5 memories).

Short press  key again to exit Memory Mode.

### ●MEM Store (long press)

Select desired channel and modulation mode.

Long press  key to enter into channel storage setting, memorized channel number blinks on the LCD.

Turn the rotary **CH** knob or press the **UP/DN** keys on the microphone to select the storage memory 1~5.

Long press  key until the memorized channel number stop blinks. Storage finished and exit channel storage setting.

## 11. Emergency Channels ~ Key Lock ~ VOX

### ●Emergency Channels (short press)

Press the  key, the radio automatically tune to channel 9.

Press the  key again, the radio automatically tune to channel 19.

Press the  key third time to return to the previous channel.

### ●Key Lock (long press)

Long press  key to lock the keys, "🔒" appears on the LCD.

Long press  key again to unlock the keys, "🔒" disappears from the LCD.

### ●VOX (PTT + EMG)

Press and hold the PTT button.

Short press  key to activate or deactivate the VOX function, "🔒" appears on the LCD when the function is active.

## 12. Frequency Band Selection

Hold the  key to power on the radio, the icon corresponding to the current configuration is blinking.

Turn the rotary **CH** knob or press the **UP/DN** keys on the microphone to change the configuration. When the configuration is selected, switching off the radio and the switching it on again to confirm the selection.

## 13. Install External Speaker

Choose a 8Ω external optional speaker with 3.5 mm mono connector.

## 14. Menu Operations

Long press  key to enter the menu function setting.

Turn the rotary **CH** knob or press the **UP/DN** keys on the microphone to select the menu to set.

Short press  key to validate, the parameter blinks on the LCD.

Turn the rotary **CH** knob or press the **UP/DN** keys on the microphone to modify the value of the parameter.

Short press  key again to store the chosen value and return to the previous level to set another menu.

Press PTT button or long press  key or wait for 10 seconds to store and exit MENU.

| NO. | LCD display | Function detail                        | Setting details                                                                     |
|-----|-------------|----------------------------------------|-------------------------------------------------------------------------------------|
| 1   |             | Beep sound                             | on: turn on beep sound<br>oF: turn off beep sound<br>Default : oF                   |
| 2   |             | Roger beep                             | oF (default), 01~06<br>oF: turn off RB sound function                               |
| 3   |             | ASQ level setting                      | 01~09<br>Default : 04                                                               |
| 4   |             | CTCSS/DCS setting in reception (RX)    | oF: no code (default)<br>CTC: 01~38, Total 38 tones<br>DCS: 01~104, Total 104 codes |
| 5   |             | CTCSS/DCS setting in transmission (TX) |                                                                                     |
| 6   |             | CTCSS/DCS setting in RX and TX         |                                                                                     |
| 7   |             | Microphone gain control                | 01~09<br>Default : 05                                                               |
| 8   |             | Microphone type setting                | EL: electric (default)<br>dy: dynamic                                               |
| 9   |             | VOX sensitivity level setting          | 01~09<br>Default : 03                                                               |
| 10  |             | VOX delay time setting                 | 01~09<br>Default : 04                                                               |
| 11  |             | HI-CUT filter setting                  | oF: turn off HI-CUT filter (default)<br>on: turn on HI-CUT filter                   |
| 12  |             | RX noise reduction level setting       | oF, 01~05<br>Default : oF                                                           |
| 13  |             | TX noise reduction level setting       | oF, 01~05<br>Default : oF                                                           |
| 14  |             | Time out timer                         | oF(default), 01~09 Min<br>Default : 03                                              |

15. Resume Factory Default

Long press  key to enter the menu function setting.  
Turn the rotary **CH** knob or press the **UP/DN** keys on the microphone to select the **r5** menu .

Short press  key to validate, the parameter blinks on the LCD.  
Turn the rotary **CH** knob or press the **UP/DN** keys on the microphone to select a parameter to be reset :

 : memory reset  
 : reset all parameters

Long press  key until the chosen parameter stop blinks.

Release  key, the device automatically reseted.

CTCSS TONE LIST

| No. | Freq. (Hz) | No. | Freq. (Hz) | No. | Freq. (Hz) | No. | Freq. (Hz) |
|-----|------------|-----|------------|-----|------------|-----|------------|
| 01  | 67.0       | 11  | 97.4       | 21  | 136.5      | 31  | 192.8      |
| 02  | 71.9       | 12  | 100.0      | 22  | 141.3      | 32  | 203.5      |
| 03  | 74.4       | 13  | 103.5      | 23  | 146.2      | 33  | 210.7      |
| 04  | 77.0       | 14  | 107.2      | 24  | 151.4      | 34  | 218.1      |
| 05  | 79.7       | 15  | 110.9      | 25  | 156.7      | 35  | 225.7      |
| 06  | 82.5       | 16  | 114.8      | 26  | 162.2      | 36  | 233.6      |
| 07  | 85.4       | 17  | 118.8      | 27  | 167.9      | 37  | 241.8      |
| 08  | 88.5       | 18  | 123.0      | 28  | 173.8      | 38  | 250.3      |
| 09  | 91.5       | 19  | 127.3      | 29  | 179.9      |     |            |
| 10  | 94.8       | 20  | 131.8      | 30  | 186.2      |     |            |

## DCS CODE LIST

| Code No. | DCS (Octal) | Code No. | DCS (Octal) | Code No. | DCS (Octal) | Code No. | DCS (Octal) |
|----------|-------------|----------|-------------|----------|-------------|----------|-------------|
| 1        | 023         | 27       | 152         | 53       | 311         | 79       | 466         |
| 2        | 025         | 28       | 155         | 54       | 315         | 80       | 503         |
| 3        | 026         | 29       | 156         | 55       | 325         | 81       | 506         |
| 4        | 031         | 30       | 162         | 56       | 331         | 82       | 516         |
| 5        | 032         | 31       | 165         | 57       | 332         | 83       | 523         |
| 6        | 036         | 32       | 172         | 58       | 343         | 84       | 526         |
| 7        | 043         | 33       | 174         | 59       | 346         | 85       | 532         |
| 8        | 047         | 34       | 205         | 60       | 351         | 86       | 546         |
| 9        | 051         | 35       | 212         | 61       | 356         | 87       | 565         |
| 10       | 053         | 36       | 223         | 62       | 364         | 88       | 606         |
| 11       | 054         | 37       | 225         | 63       | 365         | 89       | 612         |
| 12       | 065         | 38       | 226         | 64       | 371         | 90       | 624         |
| 13       | 071         | 39       | 243         | 65       | 411         | 91       | 627         |
| 14       | 072         | 40       | 244         | 66       | 412         | 92       | 631         |
| 15       | 073         | 41       | 245         | 67       | 413         | 93       | 632         |
| 16       | 074         | 42       | 246         | 68       | 423         | 94       | 654         |
| 17       | 114         | 43       | 251         | 69       | 431         | 95       | 662         |
| 18       | 115         | 44       | 252         | 70       | 432         | 96       | 664         |
| 19       | 116         | 45       | 255         | 71       | 445         | 97       | 703         |
| 20       | 122         | 46       | 261         | 72       | 446         | 98       | 712         |
| 21       | 125         | 47       | 263         | 73       | 452         | 99       | 723         |
| 22       | 131         | 48       | 265         | 74       | 454         | 100      | 731         |
| 23       | 132         | 49       | 266         | 75       | 455         | 101      | 732         |
| 24       | 134         | 50       | 271         | 76       | 462         | 102      | 734         |
| 25       | 143         | 51       | 274         | 77       | 464         | 103      | 743         |
| 26       | 145         | 52       | 306         | 78       | 465         | 104      | 754         |

SPECIFICATION

| GENERAL                     |                                      |                                       |
|-----------------------------|--------------------------------------|---------------------------------------|
| Modulation Mode             |                                      | AM/FM                                 |
| Frequency Range             |                                      | 26.565-27.99125MHz                    |
| Frequency Tolerance         |                                      | ±5.0ppm                               |
| Input Voltage               |                                      | 12/24V                                |
| Dimensions                  |                                      | 145x188x58mm                          |
| Weight                      |                                      | 667g                                  |
| Operating Temperature Range |                                      | -20°C to +50°C                        |
| Current Drain               | Transmit                             | 3A MAX                                |
|                             | Receiver                             | Squelched 0.3A                        |
|                             | VOL Max                              | 0.7A                                  |
| Antenna Connector           |                                      | UHF, SO-239                           |
| TRANSMITTER                 |                                      |                                       |
| Power Output                |                                      | 4 Watts FM/AM                         |
| Transmission interference   |                                      | inferior to 4nW                       |
| Frequency Response          |                                      | 300-3000Hz                            |
| Modulated signal distortion |                                      | inferior to 5%                        |
| Output Impedance            |                                      | 50ohms                                |
| RECEIVER                    |                                      |                                       |
| Sensitivity                 |                                      | Less than 1uV for 10dB(S+N)/N         |
| Image Rejection             |                                      | 70dB                                  |
| Adjacent Channel Rejection  |                                      | 60dB                                  |
| IF Frequencies              | 1st 10.695MHz                        |                                       |
|                             | 2nd 455KHz                           |                                       |
| Automatic Gain Control(AGC) | Less than 10dB change in audio       |                                       |
|                             | Output for inputs from 10 to 50000uV |                                       |
| Squelch                     |                                      | less than 1uV                         |
| Audio Output Power          |                                      | 2Watts at 8Ω less than 10% distortion |
| Frequency Response          |                                      | 300-3000Hz                            |

| FREQUENCY LIST |            |        |            |
|----------------|------------|--------|------------|
| CH.NO.         | Freq.(MHz) | CH.NO. | Freq.(MHz) |
| 1              | 26.965     | 21     | 27.215     |
| 2              | 26.975     | 22     | 27.225     |
| 3              | 26.985     | 23     | 27.255     |
| 4              | 27.005     | 24     | 27.235     |
| 5              | 27.015     | 25     | 27.245     |
| 6              | 27.025     | 26     | 27.265     |
| 7              | 27.035     | 27     | 27.275     |
| 8              | 27.055     | 28     | 27.285     |
| 9              | 27.065     | 29     | 27.295     |
| 10             | 27.075     | 30     | 27.305     |
| 11             | 27.085     | 31     | 27.315     |
| 12             | 27.105     | 32     | 27.325     |
| 13             | 27.115     | 33     | 27.335     |
| 14             | 27.125     | 34     | 27.345     |
| 15             | 27.135     | 35     | 27.355     |
| 16             | 27.155     | 36     | 27.365     |
| 17             | 27.165     | 37     | 27.375     |
| 18             | 27.175     | 38     | 27.385     |
| 19             | 27.185     | 39     | 27.395     |
| 20             | 27.205     | 40     | 27.405     |

## CAUTION

### Unauthorized modification and adjustment

Changes or modifications not expressly approved by the party responsible for compliance may void the user's authority granted by the local government radio management departments to operate this radio and should not be made. To comply with the corresponding requirements, transmitter adjustments should be made only by or under the supervision of a person certified as technically qualified to perform transmitter maintenance and repairs in the private land mobile and fixed services as certified by an organization representative of the user of those services. Replacement of any transmitter component (crystal, semiconductor, etc.) not authorized by the local government radio management departments equipment authorization for this radio could violate the rules.

### Radio License

Governments keep the radios in classification. Two-way radios are only operated on authorized radio frequencies that are regulated by the local radio management departments (such as FCC, ISSED, OFCOM, ANFR, BFTK, Bundesnetzagentur, and so on.). The detailed classification and the use of your two-way radios, please contact the local government radio management departments. Use of this radio outside the country where it was intended to be distributed is subject to government regulations and may be prohibited.

### FCC Requirements

This device complies with part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference. (Licensed radios are applicable);

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(Other devices are applicable)

(1) This device may not cause harmful interference.

(2) This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.

—Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.

### Disposal

The crossed-out wheeled-bin symbol on your product, literature, or packaging reminds you that all electrical and electronic products, batteries, or accumulators must be taken to designated collection locations at the end of their working life. Do not dispose of these products as unsorted municipal waste. Dispose of them according to the laws and rules in your area.



### RF Safety

This two-way radio uses electromagnetic energy in the radio frequency (RF) spectrum to provide communications between two or more users over a distance. RF energy, which when used improperly, can cause biological damage. Please refer to the following websites for more information on what RF energy exposure is and how to control your exposure to assure compliance with established RF exposure limits: <http://www.who.int/en/>

Transmit no more than the rated duty factor 50% of the time. Transmitting necessary information or less, is important because the radio generates measurable RF energy exposure only when transmitting in terms of measuring for standards compliance. For users who wish to further reduce their

exposure, some effective measures to reduce RF exposure include:

- Reduce the amount of time spent using your wireless device.
- Increase the distance between wireless devices and your body.

This radio is designed for and classified as "General population/uncontrolled use". General population/uncontrolled environments are defined as locations where there is exposure of individuals who have no knowledge or control of RF exposure level.

### **RF Safety distance**

Speak directly into the microphone. During operation, the separation distance between the user and the antenna subject to actual regulations. This separation distance will ensure that there is sufficient distance from a properly installed externally-mounted antenna to satisfy the RF exposure requirements. Transmit only when people are at the recommended minimum lateral distance away from a properly installed externally mounted antenna according to installation instructions.

### **Electromagnetic Interference/Compatibility**

Nearly every electronic device is susceptible to electromagnetic interference (EMI) if inadequately shielded, designed, or otherwise configured for electromagnetic compatibility. During transmissions, your radio generates RF energy that can possibly cause interference with other devices or systems. To avoid such interference, turn off the radio in areas where signs are posted to do so, such as hospitals or healthcare facilities.

Persons with pacemakers, implantable cardioverter defibrillators (ICDs) or other active implantable medical devices should:

- Consult with their physicians regarding the potential risk of interference from radio frequency transmitters, such as portable radios (poorly shielded medical devices may be more susceptible to interference).
  - Turn the radio OFF immediately if there is any reason to suspect that interference is taking place.
  - Do not carry the radio in a chest pocket or near the implantation site, and carry or use the radio on the opposite side of the body from the implantable device to minimize the potential for interference.
- Hearing Aids: Some digital wireless radios may interfere with some hearing aids. In the event of such interference, you may want to consult your hearing aid manufacturer to discuss alternatives.
- Other Medical Devices: If you use any other personal medical device, consult the manufacturer of your device to determine if it is adequately shielded from RF energy. Your physician may be able to assist you in obtaining this information.

**WARNING: MODIFICATION OF THIS DEVICE TO RECEIVE CELLULAR RADIOTELEPHONE SERVICE SIGNALS IS PROHIBITED UNDER FCC RULES AND FEDERAL LAW.**



Turn off your radio in the following conditions:

- Turn off your radio prior to entering any area with a potentially hazardous or explosive atmosphere. Only radio types that are especially qualified should be used in such areas as "Intrinsically Safe".

Note: the areas with potentially explosive atmosphere referred to above include blasting caps, blasting areas, inflammable gas, dust particles, metallic powders, grain powders, fueling areas such as below decks on boats, fuel or chemical transfer or storage facilities, areas where the air contains chemicals or particles (such as grain, dust or metal powders) and any other area where you would normally be advised to turn off your vehicle engine. Areas with potentially explosive atmospheres are often but not always posted.

- Turn off your radio when taking on fuel or parked at gasoline service stations.
- Turn off your radio when on board an aircraft. Any use of a radio must be in accordance with applicable regulations per airline crew instructions.
- Do not use any radio that has a damaged antenna. If a damaged antenna comes into contact with the skin when the radio is in use, a burn can result.
- Turn off your radio before removing or installing accessories.
- When the transceiver is used for long transmissions, the radiator and chassis will become hot.

### **Use of Communication Devices While Driving**

- Always check the laws and regulations on the use of radios in the areas where you drive. Use of Communication Devices, for example, mobile radio, may not be allowed.
- Give full attention to driving and to the road.



- Use hands-free operation, if available.
- Pull off the road and park before making or answering a call, if driving conditions or regulations so require.
- Do not place a portable radio in the area over an air bag or in the airbag deployment area. The radio may be propelled with great force and cause serious injury to occupants of the vehicle when the airbag inflates.

### **Protect your hearing**

- Use the lowest volume necessary to do your job. Turn up the volume only if you are in noisy surroundings.
  - Limit the amount of time you use headsets or earpieces at high volume.
  - When using the radio without a headset or earpiece, do not place the radio's speaker directly against your ear.
  - Use carefully with the earphone may be possible excessive sound pressure from earphones and headphones can cause hearing loss.
- CAUTION:** Exposure to loud noises from any source for extended periods of time may temporarily or permanently affect your hearing. The louder the radio's volume, the less time is required before your hearing could be affected. Hearing damage from loud noise is sometimes undetectable at first and can have a cumulative effect.



**WARNING: CHOKING HAZARD—Small Parts. Not suitable for children under 3 years old.**



### **RF Exposure Warning Statements:**

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment shall be installed and operated with minimum distance 51.4cm between the radiator & body.

## Guarantee

Model Number: \_\_\_\_\_

Serial Number: \_\_\_\_\_

Purchasing Date: \_\_\_\_\_

Dealer: \_\_\_\_\_ Telephone: \_\_\_\_\_

User's Name: \_\_\_\_\_ Telephone: \_\_\_\_\_

Country: \_\_\_\_\_ Address: \_\_\_\_\_

Post Code: \_\_\_\_\_ Email: \_\_\_\_\_

### Remarks:

- 1.This guarantee card should be kept by the user, no replacement if lost.
- 2.Most new products carry a two-year manufacturer's warranty from the date of purchase. Further details, pls read <http://www.retevis.com/after-sale/>
- 3.The user can get warranty and after-sales service as below:
  - Contact the seller where you buy.
  - Products Repaired by Our Local Repair Center
- 4.For warranty service, you will need to provide a receipt proof of purchase from the actual seller for verification

### Exclusions from Warranty Coverage:

- 1.To any product damaged by accident.
- 2.In the event of misuse or abuse of the product or as a result of unauthorized alterations or repairs.
- 3.If the serial number has been altered, defaced, or removed.





Points de collecte sur [www.quefairedesdechets.fr](http://www.quefairedesdechets.fr)  
Privilégiez la réparation ou le don de votre appareil !



**Shenzhen Retevis Technology Co.,Ltd.**

7/F, 13-C, Zhonghaixin Science&Technology Park, No.12 Ganli  
6th Road, Jihua Street, Longgang District, Shenzhen, China

Web:[www.retevis.com](http://www.retevis.com)

E-mail:[info@retevis.com](mailto:info@retevis.com)

Facebook:[@retevis.fans](https://www.facebook.com/retevis.fans)



Made in China

说明书印刷要求：

尺寸：120\*160mm

样式：胶装

印刷：黑色， 质保卡为单独一页

纸张：封面157G 铜版纸，内页双胶纸

此面不用印刷