

YoLink Uno WiFi Camera

YS1B01-UN



Revision Mar. 23, 2023

A Welcome!

Thank you for purchasing YoLink products! We appreciate you trusting YoLink for your smart home & automation needs. Your 100% satisfaction is our goal. If you experience any problems with your installation, with our products or if you have any questions that this manual does not answer, please contact us right away. See the Contact Us section for more info.

Thank you!

Eric Vanzo
Customer Experience Manager

The following icons are used in this guide to convey specific types of information:



Very important information
(can save you time!)



Pour des instructions en français, scannez les codes QR dans la section suivante.



Para obtener instrucciones en español, escanee los códigos QR en la siguiente sección.

B Before You Begin

Please note: this is a quick start guide, intended to get you started on the installation of your YoLink Uno WiFi Camera. Download the full Installation & User Guide by scanning this QR code:



Installation & User
Guide

You can also find all guides and additional resources, such as videos and troubleshooting instructions, on the YoLink Uno WiFi Camera Product Support page by scanning the QR code below or by visiting:

<https://shop.yosmart.com/pages/uno-product-support>




Product Support
Support produit
Soporte de producto



The Uno WiFi Camera has a MicroSD memory card slot, and supports cards up to 128GB in capacity. It is recommended to install a memory card (not included) in your camera.

C In the Box



YoLink Uno WiFi
Camera



Quick Start Guide



AC/DC Power
Supply Adapter



USB Cable
(Micro B)



Anchors (3)



Screws (3)



Mounting Base




Template

D Required Items

You may require these items:




Drill with Drill Bits




Medium Phillips
Screwdriver

E Get to Know Your Uno Camera



The camera supports a MicroSD card that is up to 128 GB.

E Get to Know Your Uno Camera, Cont.




LED & Sound Behaviors:

- **Red LED On**
Camera Start-Up or WiFi Connection Failure
- 🔊 **One Beep**
Start-Up Complete or Camera Received QR Code
- **Flashing Green LED**
Connecting to WiFi
- **Green LED On**
Camera is Online
- **Flashing Red LED**
Waiting for WiFi Connection Information
- **Slow Flashing Red LED**
Camera Updating

F Power Up

Plug in the USB cable to connect the camera and power supply. When the red LED is on, it means the device is on.

Install your MicroSD memory card, if applicable, in the camera at this time.



G Install the App

If you are new to YoLink, please install the app on your phone or tablet, if you have not already. Otherwise, please proceed to the next section.

Scan the appropriate QR code below or find the "YoLink app" on the appropriate app store.



Apple phone/tablet
iOS 9.0 or higher



Android phone or
tablet 4.4 or higher

Open the app and tap **Sign up** for an account. You will be required to provide a username and a password. Follow the instructions, to set up a new account. Allow notifications, when prompted.

You will immediately receive a welcome email from no-reply@yosmart.com with some helpful information. Please mark the yosmart.com domain as safe, to ensure you receive important messages in the future.

Log in to the app using your new username and password.

The app opens to the **Favorite** screen. This is where your favorite devices and scenes will be shown. You can organize your devices by room, in the **Rooms** screen, later.

H Add Your Uno Camera to the App


1. Tap **Add Device** (if shown) or tap the scanner icon:

Scanner icon



H Add Your Uno Camera to the App, Cont.

2. Approve access to your phone's camera, if requested. A viewfinder will be shown on the app.



3. Hold the phone over the QR code so that the code appears in the viewfinder. If successful, the **Add Device** screen will be displayed.

You can change the device name and assign it to a room later. Tap **Bind device**.

If successful, the screen will appear as shown. Tap **Done**.

I Warnings

1. The camera must not be installed outdoors or in environmental conditions outside of the range specified. The camera is not water resistant. Refer to the environmental specifications on the product support page.
2. Ensure the camera is not exposed to excessive smoke or dust.
3. The camera should not be placed where it will be subjected to intense heat or sunlight
4. It is recommended to use only the supplied USB power adapter and cable, but if either or both must be replaced, use only USB power supplies (do not use unregulated and/or non-USB power sources) and USB Micro B connector cables.
5. Do not disassemble, open or attempt to repair or modify the camera, as damage sustained is not covered by the warranty.

I Warnings, Cont.

5. Do not disassemble, open or attempt to repair or modify the camera, as damage sustained is not covered by the warranty.
6. The camera pan & tilt is operated by the app. Do not manually rotate the camera, as this may damage the motor or gearing.
7. Cleaning of the camera should only be done with a soft or microfiber cloth, dampened with water or a mild cleaner suitable for plastics. Do not spray cleaning chemicals directly on the camera. Do not allow the camera to get wet in the cleaning process.

J Installation

It is recommended that you setup and test your new camera before installing it (if applicable; for ceiling-mounting applications, etc.)

Location considerations (finding a suitable location for the camera):

1. The camera can be placed on a stable surface, or mounted on the ceiling. It can not be directly mounted to a wall.
2. Avoid locations where the camera will be subjected to direct sunlight or intense lighting or reflections.
3. Avoid locations where the objects viewed may be intensely backlit (intense lighting from behind the viewed object).
4. While the camera has night vision, ideally there is ambient lighting.
5. If placing the camera on a table or other low surface, consider small children or pets that may disturb, tamper with, or knock down the camera.
6. If placing the camera on a shelf or location higher than the objects to be viewed, please note the camera's tilt below the camera 'horizon' is limited.

J Installation, Cont.

- Ceiling-mounting:
1. Determine the location for the camera. Before permanently installing the camera, you may wish to temporarily place the camera at the intended location, and check the video images in the app. For example, hold the camera in position on the ceiling, while you or a helper checks the images and field of view and range of motion (by testing the pan and tilt positions).
 2. Remove the backing from the mounting base template and place it at the desired camera location. Select an appropriate drill bit and drill three holes for the included plastic anchors.
 3. Insert the plastic anchors in the holes.
 4. Secure the camera mounting base to the ceiling, using the included screws, and tightening them securely with a Phillips screwdriver.
 5. Place the bottom of the camera on the mounting base, and snap it into place with a clockwise twisting motion. Twist the base of the camera, not the camera lens assembly. Check that the camera is secure and that it does not move from the base, and that the base does not move from the ceiling or mounting surface.
 6. Connect the USB cable to the camera, then secure the cable to the ceiling and to the wall, over its course from the plug-in power supply. An unsupported or dangling USB cable will apply a slightly downward force on the camera, which, combined with a poor installation, may lead to the camera falling off the ceiling. Use a suitable technique for this, such as cable staples intended for the application.
 7. Plug the USB cable into the plug-in power supply/power adapter.

Refer to the full Installation & User Guide, to complete the setup and configuration of the camera.

K FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.

L Contact Us

We are here for you, if you ever need any assistance installing, setting up or using a YoLink app or product!

Need help? For fastest service, please email us 24/7 at service@yosmart.com

Or call us at **831-292-4831** (US phone support hours: **Monday - Friday, 9AM to 5PM** Pacific)

You can also find additional support and ways to contact us at: www.yosmart.com/support-and-service

Or scan the QR code:



Support
Home Page

Finally, if you have any feedback or suggestions for us, please email us at feedback@yosmart.com

Thank you for trusting YoLink!

Eric Vanzo
Customer Experience Manager

YOLINK

15375 Barranca Parkway
Ste. J-107 | Irvine, California 92618

© 2023 YOSMART, INC IRVINE,
CALIFORNIA