



tonies®

Setup Guide

Nice to
meet you!


OPEN
HERE

Welcome to the Tonie-Universe


Hi! I'm Playtime Puppy, one of the many Tonies compatible with your new Toniebox. Before you begin, I will walk you through a simple connection process. Your Toniebox will be up and running in no time!



Setting up your Toniebox is easy! You will need:



Toniebox and charger



Tonie or Creative-Tonie



Wireless network



Access to the internet




Tip: You need to keep the Toniebox within close range of your Wi-Fi signal during setup. The better the connection, the sooner you can start listening!

Setting up your Toniebox

Set up your Toniebox and start listening

Before you can use your new Toniebox, you must first set it up. You'll need a smartphone, tablet or computer to get started.



Download the free **mytonies** app and follow the step-by-step guide to set up your Toniebox.



mytonies



You can also visit
my.tonies.com/setup-toniebox

You can always access your Tonies and Toniebox settings through your free Tonie-Account.



Find additional answers, instructions and video tutorials at:
support.tonies.com

KEEP GOING

♥ FAVORITE ♥ CHILDREN'S SONGS

Hi! I'm **Playtime Puppy**.
I like to sing songs
that get you moving
and grooving!



Playtime Songs

Here's a list of songs we can sing together:

The Wheels on the Bus
If You're Happy and You Know It
The Muffin Man
Jack Be Nimble
Itsy Bitsy Spider
Rain, Rain, Go Away
Baby Shark
Let's Get Ready
Old MacDonald Had a Farm
Mary Had a Little Lamb
All the Little Raindrops
Down by the Bay
Jack and Jill
Clean Up Song
Bingo
Hot Cross Buns
One Potato, Two Potato

Pat-a-Cake
It's Raining, It's Pouring
The Alphabet Song
Miss Polly
I Wanna Be Clean/Hygiene Song
The Ants Go Marching
I Know an Old Lady (Who Swallowed a Fly)
Hickory Dickory Dock
I Had a Little Nut Tree
Row, Row, Row Your Boat
I'm Growing Up
Skip to My Lou
Peter Piper
I'm a Little Teapot
Oats, Peas, Beans, and Barley Grow
Head, Shoulders, Knees, and Toes
Skidarmarink



Running time: approx. 45 minutes

The Toniebox makes listening *easy*.

Using the Toniebox is so simple:



How to turn your Toniebox on

Pinch one of the ears with your thumb and forefinger or place the box on its charging station.



Playing and pausing


When the light on your Toniebox turns green, place a Tonie on top. Want to pause the story or song? Just remove the Tonie from the Toniebox. When you place your Tonie back on, it will pick back up from the same spot as long as another Tonie hasn't been played in between.



How to turn the volume up and down

Pinch the big ear to turn up the volume of the Toniebox. Use the little ear to turn it down.

YOU CAN SET THE
MAXIMUM VOLUME
AND MUCH MORE
IN YOUR
TONIE-ACCOUNT!




Skip back and forth

To skip back and forth between chapters, hold your Toniebox with one hand and tap on its side with the other. To fast-forward or rewind, tilt the box to one side.

How to charge your Toniebox


Even a Toniebox needs a little rest and relaxation sometimes. The LED will glow green when the battery is sufficiently charged. The LED lights up orange when the battery is low.



LED display overview

The Toniebox has different LED indicators. Here's a brief overview:

Color	LED Display Meaning
 Flashing green	Factory setting: Please install
 Green light	Everything's good to go. The battery is sufficiently charged and the Toniebox is ready to play.
 Pulsing blue	The Toniebox is in connection mode and can now look for new wireless internet connections.
 Flashing blue	This may mean the following: a. The Toniebox is connected to the internet and is downloading new Tonie content. b. The Toniebox is looking for available wireless internet connections before it switches into connection mode (lasts approximately 20 seconds).
 Orange light	Warning – low battery! Place your Toniebox on the charging station to recharge the battery.
 Red light	Oops! An error has occurred. Your Toniebox will tell you which error it is in a voice message.
 White light	Offline mode



Welcome to the Tonie- Universe

With Creative-Tonies you can upload and play your own custom content

aaarrgh!

LOVE IS IN THE AIR

BOO

I can't wait to hang out with you!

I'M HAND-PAINTED

I'M COLLECTIBLE

I'M VERY STURDY

HAPPY BIRTHDAY TO YOU!

Can't sleep?

ZZzzzz

Sweet dreams and lullabies await you.

Take your Toniebox with you.

With its **offline mode** the Toniebox is a great companion on road trips.

Truly!

Let's shake a leg

Songs for celebrating: Playtime Songs

1,2,3 - I'M THERE

Learning to count is more fun with friends.

RECORD YOUR OWN AUDIO CONTENT

WE ARE CREATIVE-TONIES

Your favorites from the Disney family

ROAR!

Who will you spend storytime with?

The Toniebox is **durable and softly padded**, making it ideal for adventures on the go.

I'LL FALL ASLEEP WITH YOU

Slip into sweet dreams without interruption. **The Toniebox turns itself off** 10 minutes after stories or songs have ended.


Need help?

Here are a few tips to get you started.

For additional help visit:

support.tonies.com

Quick troubleshooting tips



Tip 3: Check the support code word

In the event of a more complex problem, your Toniebox will provide a code word. You can find out what it means and how to resolve the problem by calling our support line at **877-MY-TONIES** (877-698-6643) or by visiting support.tonies.com

Tip 1: The classic restart

If your Toniebox is having a hard time, sometimes a restart will do the trick. To restart, remove your Toniebox from the charging station, turn it on its head and press both ears until you hear a sound (approximately 10 seconds).

Tip 2: Reset the Toniebox to its factory settings

As a last resort, you can reset your Toniebox to its factory settings.

To do this, turn both the Toniebox and its connected charging station upside down. Press both ears of the Toniebox until you hear a sound (approximately 10 seconds).

Warning: By resetting your Toniebox to factory settings, all network connections, contents and settings will be deleted.

