

Installation / User Manual

Photovoltaic Grid-connected
Microinverter(Built-in WIFI-G5)

Table of Contents

Important Safety Instructions	01
<u>Safety Instructions</u>	
Radio Interference Statement	
The Meaning of Symbols	
Microinverter System Introduction	06
Microinverters Maximize PV Energy Production	
More Reliable than Centralized or String Inverters	
Simple to Install	
Microinverter Introduction	07
Microinverter System Installation	07
Required Parts and Tools from You	
Parts list	
Installation Procedures	
Microinverter System Operating Instructions	13
Troubleshooting	13
Status Indications and Error Reporting	
Troubleshooting a Non-operating Microinverter	
Replacement	16
Technical Data	16
M65 / 80 /100 G5 Microinverter Datasheet	
Wiring Diagram	20
Monitoring Platform	22
How to connect in APP	23
Maintenance	25
Troubleshooting	25

IMPORTANT SAFETY INSTRUCTIONS

This manual contains important instructions to follow during installation and maintenance of the Photovoltaic Grid-connected Inverter (Microinverter). To reduce the risk of electrical shock and ensure the safe installation and operation of the Microinverter, the following symbols appear throughout this document to indicate dangerous conditions and important safety instructions.

Specifications subject to change without notice - please ensure you are using the latest manual found at the manufacturer website.

WARNING

This indicates a situation where failure to follow instructions may cause a serious hardware failure or personnel danger if not applied appropriately. Use extreme caution when performing this task.

AVERTISSEMENT

Ceci indique que le non-respect des instructions peut entraîner une défaillance matérielle grave ou un danger personnel si les instructions ne sont pas appliquées de manière appropriée. Soyez d'une extrême prudence lors de l'exécution de cette tâche.

NOTE

This indicates information that is important for optimized Microinverter operation. Follow these instructions strictly.

REMARQUE

Ceci indique des informations importantes pour un fonctionnement optimisé du micro-onduleur. Suivez strictement ces instructions.

CAUTION

IMPORTANT TO READ CAREFULLY AND KEEP FOR EVENTUAL REQUESTS.

ATTENTION

IL EST IMPORTANT DE LIRE SOIGNEUSEMENT LES INSTRUCTIONS ET CONSERVER LA NOTICE POUR UTILISATIONS ULTÉRIEURES.

SAFETY INSTRUCTIONS

- **DO NOT** disconnect the PV module from the Micro Inverter without disconnecting the AC power.
- Only qualified professionals should install and/or replace the Microinverters.
- Perform all electrical installations in accordance with local electrical codes.
- Before installing or using the Microinverter, please read all instructions and cautionary markings in the technical documents and on the Microinverter system and the solar-array.
- Be aware that the body of the Microinverter is the heat sink and can reach a temperature of 80°C. To reduce risk of burns, do not touch the body of the Microinverter.

When the Microinverter is working properly, please maintain a distance of at least 20 cm from it.

- **DO NOT** attempt to repair the Microinverter. If it fails, contact technical support to obtain an RMA number and start the replacement process. Damaging or opening the Microinverter will void the warranty.
- Caution!
The external protective earthing conductor is connected to the inverter protective earthing terminal through AC connector.
When connecting, connect the AC connector first to ensure the inverter earthing then do the DC connections.
When disconnecting, disconnect the AC by opening the branch circuit breaker first but maintain the protective earthing conductor in the branch circuit breaker connect to the inverter, then disconnect the DC inputs.
- In any circumstance, do not connect DC input when AC connector is unplugged.
- Please install isolation switching devices on the AC side of the inverter.

INSTRUCTIONS DE SÉCURITÉ

- NE PAS déconnecter le module PV du micro-onduleur sans l'avoir débranché de l'alimentation CA.
- Seuls les professionnels qualifiés doivent installer et/ou remplacer les micro-onduleurs.
- Effectuez toutes les installations électriques conformément aux codes électriques locaux.

INSTRUCTIONS DE SÉCURITÉ

- Avant d'installer ou d'utiliser le micro-onduleur, veuillez lire toutes les instructions et marquages de mises en garde se trouvant dans les documents techniques et sur le système du micro-onduleur et le panneau solaire.
- Sachez que le corps du micro-onduleur est un dissipateur thermique et peut atteindre une température de 80°C. Pour réduire le risque de brûlures, ne touchez pas le corps du micro-onduleur.
- Lorsque le micro-onduleur fonctionne normalement, veuillez maintenir une distance d'au moins 20 cm de celui-ci.
- N'essayez PAS de réparer le micro-onduleur. En cas de panne, contactez l'assistance technique pour obtenir un numéro RMA et lancer le processus de remplacement. L'endommagement ou l'ouverture du micro-onduleur par l'utilisateur annulera la garantie.
- Attention !
Le conducteur de mise à la terre de protection externe est connecté à la borne de mise à la terre de protection de l'onduleur à l'aide du connecteur CA. Lors du branchement, branchez d'abord le connecteur CA pour assurer la mise à la terre de l'onduleur, puis effectuez les branchements DC. Lors du débranchement, débranchez le courant alternatif en ouvrant d'abord le disjoncteur de branchement, mais maintenez le conducteur de mise à la terre de protection dans le disjoncteur de branchement, connectez-vous à l'onduleur, puis débranchez les entrées CC.
- En aucun cas, ne branchez pas l'entrée CC lorsque le connecteur CA est débranché.
- Veuillez installer les dispositifs de commutation d'isolement sur le côté CA de l'onduleur.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC warning:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Radio Interference Statement

The equipment could radiate radio frequency energy and this might cause harmful interference to radio communications if not following the instructions when installing and using the equipment. But there is no guarantee that interference will not occur in a particular installation. If this equipment causes harmful interference to radio or television reception, the following measures might resolve the issues:

- A) Relocate the receiving antenna and keep it well away from the equipment.
- B) Consult the dealer or an experienced radio / TV technical for help.

Changes or modifications not expressly approved by the party responsible for compliance may void the user's authority to operate the equipment.

WiFi information

Frequency range: 2.412~2.472GHz

WiFi maximum transmitting power: 16dBm $\pm$ 2dBm

The Meaning of Symbols

Labels	Description
	Caution, risk of electric shock. — Attention, risque d’électrocution.
	Caution, risk of burn - Do not touch. — Attention, risque de brûlures - Ne pas toucher.
	Caution, hot surface. — Attention, surface chaude.
	Symbol for the marking of electrical and electronics devices according to Directive 2002/96/EC. Indicates that the device, accessories and the packaging must not be disposed as unsorted municipal waste and must be collected separately at the end of the usage. Please follow Local Ordinances or Regulations for disposal or contact an authorized representative of the manufacturer for information concerning the decommissioning of equipment. — Symbole pour le marquage des appareils électriques et électroniques conformément à la directive 2002/96/CE. Indique que l’appareil, les accessoires et l’emballage ne doivent pas être jetés avec les ordures ménagères non triées et doivent être collectées séparément à la fin de leurs utilisations. Veuillez suivre les ordonnances ou règlements locaux pour la disposition de l’équipement ou contactez un représentant agréé du fabricant pour obtenir des renseignements concernant la mise hors service des équipements.
	Refer to the operating instructions. — Référez-vous au mode d’emploi.
Qualified personnel	Person adequately advised or supervised by an electrically skilled person to enable him or her to perceive risks and to avoid hazards which electricity can create. For the purpose of the safety information of this manual, a "qualified person" is someone who is familiar with requirements for safety, refrigeration system and EMC and is authorized to energize, ground, and tag equipment, systems, and circuits in accordance with established safety procedures. The inverter and endues system may only be commissioned and operated by qualified personnel. — Personne adéquatement conseillée ou supervisée par une personne ayant des compétences en électricité et pouvant percevoir les risques et d’éviter les dangers liés à l’électricité. Aux fins de l’information sur la sécurité, dans ce manuel, une « personne qualifiée » est une personne qui est familière avec les exigences en matière de sécurité, de système de réfrigération et de CEM, et est autorisée à mettre sous tension, mettre à la terre et étiqueter l’équipement, les systèmes et les circuits de l’équipement conformément aux procédures de sécurité établies. L’onduleur et son système ne peuvent être mis en service et utilisés que par un personnel qualifié.


Microinverter System Introduction

The Microinverter is used in utility-interactive grid-tied applications, comprised of two key elements:

- Microinverter
- Router

This series Microinverter has built-in WIFI module so it can communicate with router directly.

60 / 80 / 100 / 110G5



Inverter Model	SUN-M60G5-US-M2-Q1	SUN-M80G5-US-M2-Q1	SUN-M100G5-US-M2-Q1	SUN-M110G5-US-M2-Q1
PV Input Voltage	42.5V(15V-60V)			
PV Array MPPT Voltage Range	25V-55V			
No. of MPP Trackers	2			
No. of Strings per MPP Tracker	1			

 **NOTE**

If the wireless signal in the area where the Microinverter is installed is weak, it is necessary to add a wifi signal booster at a suitable place between the router and the Microinverter.

 **REMARQUE**

Si le signal sans fil dans la zone où le micro-onduleur est installé est faible, il est nécessaire d'ajouter un amplificateur de signal wifi à un endroit approprié entre le routeur et le micro-onduleur.

This integrated system improves safety; maximizes solar energy harvest;increases system reliability, and simplifies solar system design, installation,maintenance, and management.

Microinverters Maximize PV Energy Production

Each PV module has individual Maximum Peak Power Tracking (MPPT) controls, which ensures that the maximum power is exported to the utility grid regardless of the performance of the other PV modules in the array. When PV modules in the array are affected by shade, dust, orientation, or any situation in which one module underperforms compared with the other units, the Microinverter ensures top performance from the array by maximizing the performance of each module within the array.

More Reliable than Centralized or String Inverters

The distributed Microinverter system ensures that no single point of system failure exists across the PV system. Microinverters are designed to operate at full power at ambient outdoor temperatures of up to 113°F (45°C). The inverter housing is designed for outdoor installation and complies with the IP67 environmental enclosure rating.

Simple to Install

You can install individual PV modules in any combination of Module quantity, orientation, different type and power rate. The Ground wire (PE) of the AC cable is connected to the chassis inside of the Micro Inverter, potentially eliminating the installation of grounding wire (check local regulation).

Data collection adopts internal wifi, wireless router is needed near the Microinverter. When complete the installation of Microinverter, configure wireless router with internal wifi (refer to the wifi user manual). The data will be uploaded automatically. Users can monitor and manage the Microinverter through corresponding website or APP.

Microinverter Introduction

The Microinverters connect with the single-phase grid.
For more information, please see the Technical Data page (P16-P19) of this manual.

Model Number	AC grid	Max. # Per branch
SUN-M60G5-US-M2-Q1	60Hz, 208/240V	8 for 40A breaker
SUN-M80G5-US-M2-Q1	60Hz, 208/240V	6 for 40A breaker
SUN-M100G5-US-M2-Q1	60Hz, 208/240V	5 for 40A breaker
SUN-M110G5-US-M2-Q1	60Hz, 208/240V	5 for 40A breaker

Microinverter System Installation

A PV system using Microinverters is simple to install. Each Microinverter easily mounts on the PV racking, directly beneath the PV module(s). Low voltage DC wires connect from the PV module directly to the Microinverter, eliminating the risk of high DC voltage. Installation MUST comply with local regulations and technical rules.

WARNING

- Perform all electrical installations in accordance with local electrical codes.
- Be aware that only qualified professionals should install and/or replace Microinverters.
- Before installing or using an Microinverter, please read all instructions and warnings in the technical documents and on the Microinverter system itself as well as on the PV array.
- Be aware that installation of this equipment includes the risk of electric shock.

AVERTISSEMENT

- Effectuez toutes les installations électriques conformément aux codes électriques locaux.
- Sachez que seuls les professionnels qualifiés doivent installer et/ou remplacer les micro-onduleurs.
- Avant d'installer ou d'utiliser un micro-onduleur, veuillez lire toutes les instructions et avertissements dans les documents techniques et sur le système du micro-onduleur ainsi que sur le générateur photovoltaïque.
- Sachez que l'installation de cet équipement comporte un risque de choc électrique.

NOTE

- Strongly recommend to install Surge protection Devices in the dedicated meter box.
- The product is suitable for residential, commercial and light industrial environments, not for industrial environments.

REMARQUE

- Il est fortement recommandé d'installer des dispositifs de protection contre les surtensions dans la boîte de compteur dédiée.
- Le produit convient aux environnements résidentiels, commerciaux et industriels légers, mais pas aux environnements industriels.






Required Parts and Tools from you

In addition to your PV array and its associated hardware, you will need the following items:

- An or several AC connection junction boxes
- Mounting hardware suitable for module racking
- Sockets and wrenches for mounting hardware
- Continuous grounding conductor and grounding washers
- A Phillips screwdriver
- A torque wrench

Parts list


Please check the following table, to see whether all the parts are included in the package:

 Microinverter x1	 User manual x1	 AC extension cable (optional) x N-1
 Bus AC connector (optional) x1	 T-connector (optional) x N-1	 Clip x1


* Choose either Bus AC connector or Extension cable with European standard plug, can't use them in the same project.

Installation Procedures

Step 1 - Install the AC branch circuit junction box



- Install an appropriate junction box at a suitable location on the PV racking system (typically at the end of a branch of modules).
- Connect the open wire end of the AC cable into the junction box using an appropriate gland or strain relief fitting.
- Connect the AC branch circuit junction box to the point of utility Grid Interconnection (Usually it is inside a distribution box).



⚠ WARNING


Wiring colour code can be different according local regulation, check all the wires of the installation before connecting to the AC cable to be sure they match. Wrong cabling can damage irreparably the Microinverters, such an issue is not covered by the warranty.

⚠ AVERTISSEMENT

Le code couleur du câblage peut être différent selon la réglementation locale, vérifiez tous les fils de l'installation avant d'effectuer le branchement au câble secteur pour s'assurer qu'ils correspondent. Un mauvais câblage peut endommager irrémédiablement les micro-onduleurs et ce type de problème n'est pas couvert par la garantie.


Step 2 - Attach the Microinverters to the racking or the PV module frame

- Mark the location of the Microinverter on the rack, with respect to the PV module and junction box or any other obstructions.
- Mount one Microinverter at each of these locations using hardware recommended by your module racking vendor.



M60 / 80 / 100 / 110 G5 (2MPPT)

Mounting



The AC wire on the Microinverter is a TC-ER wire with a wire cross-section area of 1mm^2 (18AWG).

WARNING


- Prior to installing any of the Microinverters, verify that the utility voltage at the point of common connection matches the voltage rating on Microinverter label.
- Do not place the inverters (including DC and AC connectors) where exposed to the sun, rain or snow, even gap between modules. Allow a minimum of 3/4(1.5cm.) between the roof and the bottom of the Microinverter to allow proper air flow.

AVERTISSEMENT

- Avant d'installer un micro-onduleur, vérifiez que la tension de service au point de connexion commune correspond à la tension nominale indiquée sur l'étiquette du micro-onduleur.
- Ne placez pas les onduleurs (y compris les connecteurs CC et CA) à un endroit exposé au soleil, à la pluie ou à la neige, ou encore dans l'espace entre les modules. Prévoyez un minimum de distance de 1,5 cm entre le toit et le bas du micro-onduleur pour permettre une bonne circulation d'air.

Step 3 - Connect the Microinverters in parallel

- Check the Microinverter technical data page 6 for the maximum allowable number of Microinverters on each AC branch circuit.
- As to parallel connection, please refer to page (P20), use the T-connector, AC extension cable, Bus AC connector to connect the Microinverter in each branch.



Male connector


Model	Wire Size	Cable(mm ²)	Torque value(max)	Max cable length
SUN-M60G5-US-M2-Q1	10AWG	5.3	1Nm	Outside cable (L1+L2+PE)20m
SUN-M80G5-US-M2-Q1	10AWG	5.3	1Nm	
SUN-M100G5-US-M2-Q1	10AWG	5.3	1Nm	
	10AWG	5.3	1Nm	

WARNING

DO NOT exceed maximum number of Microinverters in an AC branch circuit, as displayed on the page 6 of this manual.

AVERTISSEMENT

NE PAS dépasser le nombre maximal de micro-onduleurs dans un circuit de dérivation CA comme indiqué à la page 6 de ce manuel.



T-connector


NOTE

Port marked with two-way arrow on T-type plug can only connect with extended cable and Port marked with one-way arrow on T-type plug can only connect with Microinverter


REMARQUE

Le bout marqué d'une flèche bidirectionnelle sur la prise de type T ne peut se connecter qu'avec un câble d'extension et le bout marqué d'une flèche unidirectionnelle sur la prise de type T ne peut se connecter qu'avec le micro-onduleur.

Step 4 - Connect the wire open of branch end to the junction box.



Step 5 - Connect Microinverter to the PV Modules



General Guidelines:

- a. PV modules should be connected to DC input ports of a Microinverter.
- b. In order to meet the relevant regulatory requirements, the cable length must be <3M. Please consult the local power operator to make sure that the DC cable complies with local regulations.

NOTE

When plugging in the DC cables, if AC already available, the Microinverter should immediately blink red light and will start work within the setting time (default 60 seconds). If AC is not available, the red light will blink 3 times quickly and repeat after one second until AC is connected.

REMARQUE

Lors du branchement des câbles CC, si le courant alternatif est déjà disponible, le voyant du micro-onduleur doit clignoter immédiatement en rouge et le micro-onduleur commencera à travailler selon le temps de réglage (60 secondes par défaut). Si le courant alternatif n'est pas disponible, le voyant rouge clignotera 3 fois rapidement et répétera la même action après une seconde jusqu'à ce que le courant alternatif soit connecté.

NOTE

The entire installation process shall adopt the wiring method in accordance with the national electrical code, ANSI/NFPA 70, NEC: CSA C22.1.

REMARQUE

L'ensemble du processus d'installation doit adopter la méthode de câblage conformément au code national de l'électricité ANSI/NFPA 70.

Microinverter System Operating Instructions

To operate the Microinverter PV system:

1. Turn ON the AC circuit breaker on each Microinverter AC branch circuit.
2. Turn ON the main utility-grid AC circuit breaker. Your system will start producing power after a one-minute waiting time.
3. The units should start blinking red one minutes after turning on the AC circuit breaker. Then blue led blinking. This means they are producing power normally, the faster blinking of the blue led means more power generated.
4. Configure the internal wifi module according to its user manual.
5. The Microinverters will start to send performance data over wifi module to the network every 5 minutes. It enables customers to monitor performance data of each Microinverter through website and APP.

When AC power is applied but the Microinverter not started up, about 0.1A current and 25VA power for each Micro Inverter may be measured by a power meter. This power is reactive power,not consume from utility grid.

Troubleshooting

Qualified personnel can use the following troubleshooting steps if the PV system does not operate correctly:

Status Indications and Error Reporting

Start up LED

One minute after DC power is first applied to the Microinverter,one short red blinks indicate a successful Microinverter startup sequence, be equal or greater than two short red blinks after DC power is first applied to the Microinverter indicate a failure during Microinverter setup.

Operation LED

- Flashing Slow Blue - Producing small power
- Flashing Fast Blue - Producing big power
- Flashing Red - Not producing power
- Red blinking two times - AC low-voltage or high-voltage
- Red blinking three times - Grid failure

GFDI Error

A four time red LED indicates the Microinverter has detected a Ground Fault Detector Interrupter (GFDI) error in the PV system. Unless the GFDI error has been cleared, the LED will remain four times blinking.

Other Faults

All other faults can be reported to the website and APP.



WARNING

Never disconnect the DC wire connectors under load. Ensure that no current is flowing in the DC wires prior to disconnecting. An opaque covering may be used to cover the module prior to disconnecting the module.



AVERTISSEMENT

Ne débranchez jamais les connecteurs de fils CC sous charge. Assurez-vous que le courant ne circule pas dans les fils CC avant de les débrancher. Un revêtement opaque peut être utilisé pour recouvrir le module avant de le débrancher.

Troubleshooting a Microinverter

There are two possible overall areas of trouble:

- A. The Microinverter itself may be having problems.
- B. The Microinverter itself is working fine but the communication between Microinverter and network has problem. Refer to communication issues, not Microinverter issues.

One quick way to tell whether the issue is the Microinverter or the communication problem:

Diagnosing from the network:

- a. No-Data-Display: The website and APP don't display any data. Check the network configuration.
- b. Only display Microinverter is online but no data. This may be because server is updating.

To troubleshoot a abnormal Microinverter, Follow the steps below in order:

1. Verify the utility voltage and frequency are within ranges shown in the Technical Data section of this manual.
2. Check the connection to the utility grid. Disconnect AC firstly, then disconnect DC and make sure the utility grid voltage can be measured at AC connector. Never disconnect the DC wires while the Microinverter is producing power. Re-connect the DC module connectors and watch for three short LED flashes.
3. Check the AC branch circuit interconnection between all the Microinverters. Verify each inverter is energized by the utility grid as described in the previous step.
4. Make sure that any AC breaker are functioning properly and are closed.
5. Check the DC connections between the Microinverter and the PV module.
6. Verify the PV module DC voltage is within the allowable range shown in the Technical Data of this manual.
7. If the problem still persists, please contact technical support.

WARNING

Do not attempt to repair the Microinverter. If troubleshooting methods fail, please call for Technical Support.

AVERTISSEMENT

N'essayez pas de réparer le micro-onduleur. En cas d'échec des méthodes de dépannage, veuillez appeler l'assistance technique.

Replacement

Follow the procedure to replace a failed Micro Inverter

- A. Disconnect the Microinverter from the PV Module, in the order shown below:
1. Disconnect the AC by turning off the branch circuit breaker.
 2. Disconnect the AC connector of the Microinverter.
 3. Cover the module with an opaque cover.
 4. Disconnect the PV module DC wire connectors from the Microinverter.
 5. Remove the Microinverter from the PV array racking.
- B. Install a replaced Microinverter to the bracket then remove the opaque cover.
Remember to observe the flashing LED light as soon as the new Microinverter is plugged into the DC cables.
- C. Connect the AC cable of the replacement Microinverter.

Technical Data



WARNING

- Be sure to verify the voltage and current specifications of your PV module match with those of the Microinverter. Please refer to the datasheet or user manual.
- You must match the DC operating voltage range of the PV module with the allowable input voltage range of the Microinverter.
- The maximum open circuit voltage of the PV module must not exceed the specified maximum input voltage of the inverter.



AVERTISSEMENT

- Assurez-vous de vérifier que les spécifications de tension et de courant de votre module PV correspondent à celles du micro-onduleur. Veuillez-vous référer à la fiche technique ou au mode d'emploi.
- Vous devez faire correspondre la plage de tension de fonctionnement CC du module PV avec la plage de tension d'entrée admissible par le micro-onduleur.
- La tension maximale en circuit ouvert du module PV ne doit pas dépasser la tension d'entrée maximale spécifiée pour l' onduleur.

M60/80/100/110G5 Microinverter Datasheet

Model	SUN-M60G5-US-M2-Q1	SUN-M80G5-US-M2-Q1	SUN-M100G5-US-M2-Q1	SUN-M110G5-US-M2-Q1
PV String Input Data				
Max. PV Input Power(W)	210-420W (2 Pieces)	210-560W (2 Pieces)	210-700W (2 Pieces)	210-700W (2 Pieces)
Max. PV Input Voltage(V)	60V			
Start-up Voltage(V)	15V			
MPPT voltage range(V)	25V-55V			
Full Load MPPT Voltage Range(V)	27V-55V	30V-55V	33V-55V	39V-55V
Rated PV input voltage(V)	42.5V			
Max. Input Short-Circuit Current (A)	24A*2			
Max. Operating PV Input Current(A)	16A*2			
No. of MPP Trackers/ No. of Strings per MPP Tracker	2/1			
AC Output Side				
Rated AC Output Active Power(W)	600W	800W	1000W	1100W
Max.AC Output Apparent Power(VA)	660VA	880VA	1100VA	1100VA
Rated AC output current (A)	2.9/2.5A	3.9/3.4A	4.9/4.2A	5.3/4.6A
Max.AC Output Current(A)	3.2/2.8A	4.3/3.7A	5.3/4.6A	5.3/4.6A
Rated output voltage/range (V)	208/240V 0.88Un-1.1Un			
Grid Connection Form	L1+L2+PE			
Rated Output Grid Frequency/range(Hz)	60Hz/55Hz-65Hz			
Max. unit per branch	8	6	5	5

Model	SUN-M60G5-US-M2-Q1	SUN-M80G5-US-M2-Q1	SUN-M100G5-US-M2-Q1	SUN-M110G5-US-M2-Q1
AC Output Side				
Power Factor Adjustment Range	0.8 leading-0.8lagging			
Total Current Harmonic Distortion THDi	<5%			
DC Injection Current	<0.5%In			
Efficiency				
Max. Efficiency	96.5%			
CEC Efficiency	96.0%			
MPPT Efficiency	>99%			
Equipment Protection				
DC Polarity Reverse Connection Protection	yes			
AC Output Overcurrent Protection	yes			
AC Output Overvoltage Protection	yes			
AC Output Short Circuit Protection	yes			
Thermal Protection	yes			
DC Terminal Insulation Impedance Monitoring	yes			
Power Network Monitoring	yes			
Island protection monitoring	yes			
Earth Fault Detection	yes			
Overvoltage Load Drop Protection	yes			
Surge Protection Level	TYPE II(DC),TYPE II(AC)			


Model	SUN-M60G5-US-M2-Q1	SUN-M80G5-US-M2-Q1	SUN-M100G5-US-M2-Q1	SUN-M110G5-US-M2-Q1
Interface				
Communication Interface	WiFi			
General Data				
Protective Class	Class I			
Pollution Degree	PD 3			
Operating Temperature Range (°C)	-40°Cto +65°C			
Permissible Ambient Humidity	0-100%			
Permissible Altitude (m)	2000m			
Noise (dB)	≤ 25 dB			
Ingress Protection(IP) Rating	type6p			
Inverter Topology	Isolated			
Over Voltage Category	OVC II(DC),OVC IV(AC)			
Cabinet Size (W*H*D)[mm]	223.5×178.5×31.6 (Excluding connectors and brackets)			
Weight [kg]	2.75			
Warranty [year]	Standard 10 years, extended warranty			
Type Of Cooling	Natural cooling			
Grid Regulation	IEEE 1547/SRD 2.0/CSA C 22.2			
Safety EMC/Standard	UL1741/FCC			

* Note : 15 years warranty (only installed in Germany and Austria).

Wiring Diagram


Sample Wiring Diagram Single Phase

M60G5/80G5/100G5/110G5 (2MPPT)



M60G5/80G5/100G5/110G5 (2MPPT)

Sample Wiring Diagram Three Phase



Monitoring Platform

This series Microinverter has built-in WIFI modular which is able to connect router directly. For WIFI configuration, please check the manuals of “User Manual”.

Web monitoring address: <https://pv.inteless.com>

For mobile phone monitoring system, scan the QR code to download the APP.

Also you can find it by searching “PV Pro” in App store or Google Play store.




Scan QR Code To Download APP

How to connect in APP


1. Registration

Open the app of PV Pro and register an account.
Click "Register" and create your account here.




2. Create a Plant

Go to the power station list page,click “Create plant”button to enter the create plant page ,you can choose scan OR code or manual input SN and Key,Please fill in plant basic info and other info here.



3. Network Configuration

Please configure the network to ensure normal operation.
Click the bottom “Me” button to select from the menu “Tools”.
Then you should choose “Mesh network configuration”.



NOTE: 5G WiFi is not supported .

 NOTE
5G WiFi is not supported .
 REMARQUE
Le Wi-Fi 5G n'est pas pris en charge.

Maintenance

Deye microinverters do not require any specific regular maintenance.

Troubleshooting

If you have any question you can't handle during using Deye products, please contact with our after services by email: service@deye.com.cn, details can refer to products' warranty.

NINGBO DEYE INVERTER TECHNOLOGY CO., LTD.

Add.: No.26 South YongJiang Road, Daqi, Beilun, NingBo, China.

Tel.: +86 (0) 574 8622 8957

Fax.: +86 (0) 574 8622 8852

E-mail: service@deye.com.cn

Web.: www.deyeinverter.com