


BP32 Wireless Alarm Panel



NOT YET PUBLISHED
Remove when first published

Document Details

Version

v1.0 [EDIT]

(*v1.0 published [EDIT]*)

Firmware

Firmware version can be verified on Verkada Command
command.verkada.com.

Product Models

This install guide pertains to model BP32.

© Copyright 2025 Verkada Inc. All rights reserved.

Verkada and the Verkada logo are registered trademarks or service marks of Verkada Inc. (“Verkada”). All other trademarks are the property of their respective owners.

Verkada may make changes to this document at any time without notice. The information presented herein may be inaccurate or outdated, and Verkada is under no obligation to maintain it. ALL INFORMATION IS PROVIDED “AS-IS” AND WITHOUT ANY WARRANTIES, IMPLIED, EXPRESS, OR OTHERWISE. VERKADA DISCLAIMS LIABILITY FOR ALL DAMAGES, INCLUDING WITHOUT LIMITATION ANY DIRECT, INDIRECT, SPECIAL, INCIDENTAL, PUNITIVE, OR CONSEQUENTIAL DAMAGES, ARISING OUT OF USE OF THIS DOCUMENT.

Any intellectual property rights relating to Verkada products are and shall remain Verkada’s exclusive property. Use of any Verkada product is subject to Verkada’s end user agreement or other executed agreement with Verkada. No license, either expressed or implied, to use or distribute any Verkada product is granted under this document.


This document may not be sold, resold, licensed or sublicensed and may not be transferred without Verkada’s prior written consent. No part of this document may be reproduced in whole or in part without the express written consent of Verkada.



What's in the Box




Wireless Alarm Panel



Mount Plate
(Attached to device)



Antennas (2 pcs)



Wall Anchors (4 pcs)



M4 Wall Screws (4 pcs)
Length: 25mm Drive: #2 Phillips



T10 Security Torx Screwdriver

What you'll need

- A smartphone or laptop
- 1/4 inch (6.5mm) drill bit for wall anchors (if using mount plate)
- 1/8 inch (3mm) drill bit for pilot holes (if using mount plate)
- A Cat5 or Cat6 Ethernet cable with a 0.2-0.25 inch diameter (5-6.5mm)


Connect

For easy registration and setup, scan the QR code on the product.

If you prefer to manually register your product, please proceed to:
verkada.com/start

Introduction


Overview



Overview

Mount plate details

- A** Wall/Ceiling/Square Junction Box
(4 inches / 101.6 mm)
- B** Single Gang Junction Box
- C** Round Junction Box
(4 inches / 101.6 mm) and (3½ inches / 88.9 mm)
- D** Double Gang Junction Box
- E** European Junction Box



1 Status LED Behaviors


-  **Solid Orange**
[EDIT] is on and booting up.
-  **Flashing Orange**
[EDIT] is updating firmware.
-  **Solid Blue**
[EDIT] is running and online.
-  **Flashing Blue**
[EDIT] is running and offline.

Signal Strength LED Behaviors

If all LEDs are lit, the connection is optimal.



Fewer lights indicate a weaker signal. Try adjusting the antenna position for better signal strength.



Slide 5



- 1 double check how LED behaviour is described on Jonas and Piranha - is status LED separate from LTE signal strength?
Austin Huang, 7/16/2025
- 1 @austin.huang@verkada.com See LED behavior for Piranha on the left, which is different from that of Jonas. Can you confirm which one is accurate for Elrond?
Haoda Ma, 7/16/2025

Installation

External Sub-G Installation

4 To extend VLINK range for outdoor coverage, remove the Sub-G SMA cover and install ACC-VLANT-1.

Refer to the install guide for ACC-VLANT-1 for more details.



Slide 6

- 2 Done
Austin Huang, 7/15/2025
- 3 Thanks! Do we need to put a reference link?
Haoda Ma, 7/16/2025
- 2 Please put in the writing for this section. @austin.huang@verkada.com
Haoda Ma, 7/16/2025
- 4 Also, do you want this page here or at the end after the installation?
Haoda Ma, 7/16/2025
- 1 @siddharth.dedhia@verkada.com are we launching with external antenna or not?
Assigned to siddharth.dedhia@verkada.com
Jana Beck, 8/20/2025

3 Technical Specifications

1	Power Draw	1.5W standby(TBC) , 24.5W maximum.
3	Input Voltage	PoE 42V - 57V DC input, 0.58A - 0.43A
2	Output Voltage	36V +/- 3% (available when DC input is present) Output current 167mA max
	Battery Life	24-hour battery backup (57.6 Wh rechargeable LiFePo4 battery)
	RF connectivity	VLink sub-GHz transceiver with internal/external Antenna (863MHz - 928MHz). LTE: WWXD Band 1, 2, 3, 4, 5, 7, 8, 9, 12, 13, 14, 18, 19, 20, 25, 26, 28, NFXD: Band 2, 4, 5, 12, 13, 14, 66, 71 BLE transceiver with internal Antenna (TBC) (2.4000 GHz to 2.4835 GHz)
	RF Range	≥ 400m when paired with any of Verkada's VLink capable devices
	Tamper Detection	Yes
	I/O ports	PoE In, RS485 Out, USB, Nano SIM Card, Power Switch, Mic Disable Switch
	LEDs	Status LEDs: RGB + Orange x1 Radio Signal Strength: White x4
	Operating Temp. & Humidity	0°C-50°C / 32°F-122°, 0-90% RH non-condensing
	Dimension	7.5 (in) x 7.5 (in) x 1.75 (in)
	Compliance	FCC, CE, AUS, NZ RF & EMC: FCC, IC (for CA), CE (for EU) Cellular: PTCRB, GCF, Verizon, AT&T, T-Mobile Safety: UL/IEC 62368-1, CSA C22.2 No. 62368-1

Slide 7

- 4 these will need to be verified
Austin Huang, 6/11/2025
- 3 cert list should be double checked
Austin Huang, 6/11/2025
- 1 @justin.lin@verkada.com please help update this page's spec
Jane Wang, 6/12/2025
- 3 Updated, BLE and Power Draw standby is TBC.
Justin Lin, 6/12/2025
- 1 Do we have the height with antennas?
Max Shen, 8/18/2025
- 2 Do we also have the weight?
Max Shen, 8/18/2025
- 2 Change to PoE?
Jana Beck, 8/26/2025
- 1 Yes, should be changed to PoE at. And also mention that there will be no DC out when using PoE af.
Justin Lin, 8/26/2025
- 2 By following the BK21, we might only provide the peak power. This means we only provide a 24.5W and do not provide standby information.
Justin Lin, 8/26/2025




Preparation

Remove the protective caps on the LTE SMA connectors and install the antennas.

6

Use the T10 Security Torx Screwdriver to loosen the Security Screw on the bottom.

Slide the Mount Plate downward and separate the Mount Plate from the device.




Slide 8

- 5 Good catch, you push the mount plate down to release so please switch the arrow orientation
Austin Huang, 7/15/2025
- 5 Confirming this step is pushing the mount plate upward to release it? @austin.huang@verkada.com
Haoda Ma, 7/15/2025
- 6 Gotya, and we still need to loosen the security screw first to release it correct?
@austin.huang@verkada.com
Haoda Ma, 7/15/2025


Installation

Mounting (1/2)


Install wall anchors and screws to secure the mount plate to the wall. Use the bubble level to assist with leveling the device before tightening screws.




Cable Routing Options



Through the Wall



Through the Top




Through the Bottom


Installation

Routing Through the Wall

Route the cables through the central hole on the mount plate.




Plug the wires into the device. Ensure device is powered on and set mic to desired operating state.




Installation

Routing Through the Top


Remove the Cable Cover from top of the device.



Use the T10 Security Screw to remove the Bubble Level.




Plug the wires into the device. Ensure device is powered on and set mic to desired operating state.




Installation

Routing Through the Bottom


Remove the Cable Cover from bottom of the device.



Plug the wires into the device. Ensure device is powered on and set mic to desired operating state.




Ensure that the wires are routed through the opening on the bottom of the Mount Plate.



Installation

Mounting (2/2)

Engage the mounting pegs on the Mount Plate and push down to lock the device in place.



Tighten the Security Screw on the bottom of the device to secure it.



Appendix

Compliance

FCC Compliance

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

FCC Radiation Exposure Statement :

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body. Any changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

Professional Installation:

This device must be professionally installed. The intended use is generally not for the general public. It is generally for industrial and commercial use. Installers must be provided with antenna installation instructions and transmitter operating conditions for satisfying RF exposure compliance and other FCC rules.

Appendix

Compliance

ISED Compliance

This device complies with ISED's licence-exempt RSSs. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Le présent appareil est conforme aux CNR d'ISED applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) le dispositif ne doit pas produire de brouillage préjudiciable, et (2) ce dispositif doit accepter tout brouillage reçu, y compris un brouillage susceptible de provoquer un fonctionnement indésirable.

IC Radiation Exposure Statement:

This equipment complies with IC RSS-102 radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Déclaration d'exposition aux rayonnements d'IC : Cet équipement est conforme aux limites d'exposition aux rayonnements IC RSS-102 définies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec une distance minimale de 20 cm entre le radiateur et votre corps.

Supported Antennas:

This radio transmitter 26271-60B5601 has been approved by Innovation, Science and Economic Development Canada to operate with the antenna types listed below, with the maximum permissible gain indicated. Antenna types not included in this list that have a gain greater than the maximum gain indicated for any type listed are strictly prohibited for use with this device.

Le présent émetteur radio 26271-60B5601 a été approuvé par Innovation, Sciences et Développement économique Canada pour fonctionner avec les types d'antenne énumérés ci-dessous et ayant un gain admissible maximal. Les types d'antenne non inclus dans cette liste, et dont le gain est supérieur au gain maximal indiqué pour tout type figurant sur la liste, sont strictement interdits pour l'exploitation de l'émetteur.

Appendix

Support

Thank you for purchasing this Verkada product. If for any reason you're experiencing issues or need assistance, please contact our 24/7 Technical Support Team immediately.

Sincerely,
The Verkada Team
verkada.com/support




[DELETE BEFORE PUBLICATION] Document Assets

Signal	AWG	Conductor	Shielded	Max Length
Power (22 Gauge)	22	Yes	Yes	600 ft
Power (18 Gauge)	18	Yes	Yes	1500 ft

 **Warning**

Text that customer needs to see



● **QR Code**
Scan after connecting to power to register camera in Command.

Wall Screws (3 pcs)
Length: 25mm **Diameter:** 4mm
Drive: #2 Phillips

Cable Gland (1 pc)
Size: 5.0-6.5mm
(Attached to camera)

