

SONIC BOOM 120

WIRELESS PARTY SPEAKER

120W PEAK POWER

WIRELESS PARTY SPEAKER
WITH LIGHTING EFFECTS



ITEM: IMT9000



QUICK START GUIDE

1.


IN THE BOX



IMT9000 Sonic Boom 120
Wireless Party Speaker



Wired Microphone




Adaptor

2.

SPEAKER CONTROLS

PARTY SYNC

Used to activate Party Sync for
>100 Sonic Boom speakers.
See later section.



USB INPUTS

USB C for charging / USB Audio.
USB A for charging / memory sticks.

BT

Press for direct access to
Bluetooth Mode

FM/AUX/USB

Press for access to FM/AUX plus
USB Audio / USB memory stick
playback when connected to
those devices.

MENU

Press to access Bass and
Treble menus.

BASS MODES


Press to select from 3 bass modes.

LIGHT MODES

Press to cycle round lighting modes.
Press and hold for off.

PRESETS

Press for access to FM presets 1-4





◀ Previous Track/Station
▶ Play/Pause
▶ Next Track/Station

Master Volume
& Up/Down in Menus.

3.

INPUT/OUTPUT PORTS




4.

BLUETOOTH


Bluetooth Pairing:

Go to the Bluetooth page in Settings on your phone/tablet. Make sure Bluetooth is turned on and connect to the device called “AL SonicBoom120”

Once paired the speaker will automatically reconnect to any nearby paired devices the next time BT is selected.



To disconnect a currently paired device and connect another simply either forget the speaker in your Bluetooth Settings, or turn off Bluetooth on the connected phone/tablet or press and hold the ►| button on the speaker for 5S. This will cause the speaker to drop the connection and go to pairing mode.




5.

FM

FM Radio Mode:

- Make sure the speaker is placed in an area of good reception.
- Press the FM/AUX/USB button and cycle round till you see the FM tuning frequency "XX.X" in the display.
- Press and hold ◀ or ▶ to cause the speaker to scan down/up to the next strong station.
- Press and hold one of the buttons 1-4 to save the current frequency/station as a preset.
- Briefly press the preset buttons 1-4 to recall a preset.
- Once presets have been set briefly press the ◀ or ▶ buttons to step down/up to the next preset.
- You can have the speaker automatically populate the presets with the strongest stations by using the Band Scan function. Press and hold the Play/Pause button and the speaker will find and store presets across the whole band. Once stored you can use the ◀ and ▶ buttons to step through them and then the 1-4 buttons to store 4 of them into 1-4 for easy recall.



6.


AUX/MICS

Aux Mode:

- Connect a suitable source to the rear 3.5mm 1/8th" jack. This can be any line level source (such as a CD player, games console etc.) or the headphone output of a Phone/PC/Laptop etc.
- Press the FM/AUX/USB button and cycle round till you see the 'AUX' in the display.
- Adjust volume on both the external source and speaker.

Mic Inputs:

- The speaker has two microphone inputs with individual volume and reverb.
- Any standard microphone with a 1/4" mono jack output can be used.




7.

LIGHTING

Lighting:

Press the LIGHT MODES button to cycle between 8 lighting modes and off. You can also press and hold the button to turn the lights off.

- Mode 1: "Bargraph" with step color change
- Mode 2: Slow fade between colors
- Mode 3: Rotating color with step color change
- Mode 4: Flash to music with step color change
- Mode 5: Fire Mode
- Mode 6: Fast Rotating multi color ring
- Mode 7: "Bargraph" sweep up and down
- Mode 8: Slow Rotating color ring



USB Memory Stick Playback:

- The speaker can play from USB memory sticks via the USB C or USB A ports. Only one memory stick can be inserted at a time.
- Insert your USB memory stick and give the speaker 5 seconds (sometimes longer) to recognise it.
- Press the FM/AUX/USB button and cycle round till you see “USB” in the display.
- You can now use the play/pause and track skip buttons to play your content.
- MP3/WMA/WAV file types are support. Max memory stick size is 128Gb.

USB PC Audio Playback:

- The speaker can play from a PC/Laptop via USB Audio by acting as a soundcard.
- Connect a USB A to USB C or other suitable lead from your PC/Laptop to the USB C port. In your PC's settings select the “USB Audio1.0” device for playback (as the output soundcard).
- 16 Bit/44.1kHz connection to the PC is supported. Whatever you play on the PC/Laptop will be output via the speaker.
- Connect your USB cable and give the speaker/laptop/PC 5 seconds (sometimes longer) to recognise it.
- Press the FM/AUX/USB button and cycle round till you see “PC” in the display.
- You can now use the PC/Laptop to play content. Adjust volume on both the PC/Laptop and speaker.
- It is possible to have a memory stick connected to the USB A port and PC/Laptop to the USB C port at the same time and selectbetween them.
- Party Sync is not possible in USB PC Audio Mode.


9.

PARTY SYNC

Party Sync:

- The SonicBoom120 can connect to >100 other speakers from the SonicBoom range (SonicBoom120/180 models, see website for details).
- Party sync works in BT/FM/Aux/USB memory stick modes*. Whatever is playing on the *primary* speaker will then be heard on the *secondary* speakers at the same time.
- Note the Microphone inputs when used are heard on the speaker to which they are connected. This is because they are directly mixed in for zero latency. You can connect microphones to *secondary* speakers as well as the *primary* so that many people can sing to the same content.
- Choose one speaker as the *primary*. Start playing your preferred source (BT/FM/Aux/USB memory stick).
- Press and hold the PARTY SYNC button for 5S until 't-On' (transmit on) appears on the display.
- For each *secondary* speaker in turn, select the BT source, then double press its PARTY SYNC button (BT/SYNC button on SonicBoom180), 'r On' (receive on) will appear on its display.
- The *secondary* speaker will say SYNC when connected
- To exit Party Sync press and hold the PARTY SYNC button for 5s on the speaker you wish to disconnect. "OFF" will appear on the display. Each speaker is disconnected individually.

***PC Mode (USB Audio / soundcard mode) does not support Party Sync.**



10.

SAFETY PRECAUTIONS



WARNING!

Sealing flaps on top and rear must be fully closed to maintain waterproof rating

11.

SPECIFICATIONS

Peak Output Power: 120W

Play Time: 16 Hours approx. @ 50% volume

Waterproofing: IP66, all flaps closed

Drivers: 1 x 8" Woofer

1 x 1" horn loaded compression driver

1 x Slot loaded Auxiliary Bass Radiator

Memory stick playback: MP3/WMA/WAV Max size 128Gb

Bluetooth Range: up to 33 Feet

Power Supply

Input: 100-240V AC

Output 18V DC 2A

FCC STATEMENT

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
- The device has been evaluated to meet general RF exposure requirement.
- The device can be used in portable exposure condition without restriction.

Having Trouble? We're here to help!

Call us 24/7 at 1-855-292-4087
E-mail us at support@alteclansing.com
or visit us at alteclansing.com

Altec Lansing
Edison, NJ 08817

Keep manual and all relevant
information for future reference.

WARRANTY CARD

This warranty covers the original consumer purchaser only and is not transferable.

This warranty covers products that fail to function properly UNDER NORMAL USAGE, due to defects in material or workmanship. Your product will be repaired or replaced at no charge for parts or labor for a period of one year.

What Is Not Covered by Warranty:

Damages or malfunctions not resulting from defects in material or workmanship and damages or malfunctions from other than normal use, including but limited to, repair by unauthorized parties, tampering, modification or accident.

To Obtain Warranty Service and Troubleshooting Information:

Call 1-855-292-4087 or Visit our website at www.alteclansing.com.

To receive Warranty service along with the name and address of an authorized product service center, the original consumer purchaser must contact us for problem determination and service procedures. Proof of purchase in the form of a bill of sale or receipted invoice, evidencing that the Product is within the applicable Warranty period(s), MUST be presented in order to obtain the requested service. It is your responsibility to properly package and send any defective products along with a dated copy of proof of purchase, a written explanation of the problem, and a valid return address to the authorized service center at your expense. Do not include any other items or accessories with the defective product. Any products received by the authorized service center that are not covered by warranty will be returned unrepaid.

NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSLY DESCRIBED ABOVE SHALL APPLY. DISTRIBUTOR FURTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE. NO OTHER EXPRESS WARRANTY OR GUARANTY GIVEN BY ANY PERSON, FIRM OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BE BINDING ON DISTRIBUTOR. REPAIR, REPLACEMENT, OR REFUND OF THE ORIGINAL PURCHASE PRICE - AT DISTRIBUTOR'S SOLE DISCRETION -ARE THE EXCLUSIVE REMEDIES OF THE CONSUMER. IN NO EVENT WILL DISTRIBUTOR, ITS MANUFACTURERS, OR SAKAR INT. BE LIABLE FOR ANY INCIDENTAL, DIRECT, INDIRECT, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS, SAVINGS, DATA OR RECORDS) CAUSED BY THE USE, MISUSE OR INABILITY TO USE THE PRODUCT. EXCEPT AS STATED HEREIN, NO OTHER WARRANTIES SHALL APPLY. NOTWITHSTANDING THE FOREGOING, CONSUMER'S RECOVERY AGAINST DISTRIBUTOR SHALL NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT SOLD BY DISTRIBUTOR. THIS WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT AND IS NOT TRANSFERABLE.

Some countries, states or provinces do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on warranties, so limitation or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state or province to province. Contact your authorized retailer to determine if another warranty applies. This product is manufactured, distributed and sold by SAKAR International, Inc. All other trademarks are the property of the respective owner, who has not sponsored, endorsed or approved this product.

JUST LISTEN.

The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and use of such marks by AL Infinity, LLC is under license. Other trademarks and trade names are those of their respective owners.