

HPP-M14

User Manual



Table of Contents

INTRODUCTION.....	4
Display Layout and icons	4
Specifications	5
Hardware Installation	5
DEVICE CONFIGURATION	9
Login to your Device	9
Home Page.....	10
SMS.....	13
Settings.....	13
Internet.....	13
Wireless	14
WLAN MAC Filter	15
Network.....	17
Firewall	17
IP Filter	18
Port Forwarding	19
DMZ Settings.....	20

SNTP.....	21
PIN Management.....	22
Device Information	23
Statistics.....	23
System Admin	24
Upgrade	25
Reboot & Reset.....	26
Logout.....	27
Trouble Shooting.....	27
Q&A.....	27
Health and Safety Information	29

INTRODUCTION

Display Layout and icons



Icon	Description
	Signal and roaming status icon
	Network mode icon
	Data flow icon
	Wi-Fi signal and number of access users
	The number of unread messages, maximum is 100
	Battery capacity icon, if battery capacity is lower than 25%, this icon is red
	Data Statistics, used/total
	WPS status indicator
	Download and upload data speed

Specifications


CPU platform	Qualcomm MDM9207
Working frequency band	WCDMA: B2/B4/B5 TDD-LTE: B41 FDD-LTE: B2/B4/B5/B12/B13/B25/B26/B66/B71
LTE Rate	CAT:4/DL-150Mbps/UL-50Mbps 2*2MIMO
WIFI band	2.4G/5.8G
WIFI standard	IEEE 802.11b/g/n/ac
Working temperature	-0 ~ 40°C
Storage temperature	-20 ~ 50°C

Hardware Installation

Installing the SIM Card

Follow the instruction to install the SIM card.

1. Remove the SIM card from the outer card, being careful not to touch the gold contacts.
2. Turn the power off. Remove the battery cover and remove the battery. Locate the SIM card slot. Hold the card so the writing on the back of the card is facing you and the gold contacts are properly aligned with the SIM card slot.
3. Insert the SIM card into the slot until it is fully inserted.




Note: DO NOT remove SIM card when the device is powered on since this may damage the card and the device.

Inserting and Charging the Battery

1. Remove the battery cover and align the battery contacts with the terminals in the battery compartment as shown. Push the battery down until it clicks into place.
2. Place the battery cover over the battery compartment and press it downward until it clicks into place.

Removing the LTE SIM Card

1. Turn the power off. Remove the battery cover and take out the battery.
2. Gently remove the SIM card from the SIM card slot.



Connecting Wi-Fi Enabled Devices To Your Device

Note: It is recommended the battery be fully charged in order to use your device via Wi-Fi for the first time.

Follow these Steps:

1. Enable your Wi-Fi application to allow your mobile device to establish a connection with your device.
2. Look for the network (SSID) named "4G-WIFI-2.4G_xxxx" or "4G-WIFI-5G_xxxx" . Where *xxxx* are the last four digits of the Mac address.
3. The default Wi-Fi password is the last 8 digits of the device IMEI (For example: 12345678).

Note: Your Wi-Fi SSID and password will also be displayed on the WI-FI Info page of the device screen each time the device is powered on.

Accessing the Internet

After successfully establishing the connection between your device and Wi-Fi clients, you can have access the Internet.

Setting up your WPS

If your terminal support WPS, you do not have to input the password manually once your WPS has been set up.

To use WPS please follow these steps:

1. Enable WPS in the WebUI through
Settings->Wireless->WLAN Settings->WPS
2. Press "**Menu**" button on the device to select "**WPS Active**" page on the screen
3. Press "**Power**" button to active WPS function.

Then you can enable the WPS function on your terminal to connect the hotspot.

DEVICE CONFIGURATION


Login to your Device

To configure your device, open your web browser and input the default URL:

1. Make sure to connect your device (tablet, pc, etc) to the hotspot via Wi-Fi or Micro-USB cable.
2. Log in to ***http://192.168.1.1*** in your browser.
3. The default user name is: **admin**
4. The default password is **12\$** following with last 3 digits of the device IMEI (For example: 12\$123).

Note: You can find the default User Name and Password printed in the device label by removing the back cover and battery.

It is suggested to change the default login password of the WebUI to prevent unauthorized users from changing the hotspot's settings.

A login form is centered on a dark gray background. The form is enclosed in a light gray rounded rectangle. It contains two input fields: the first is labeled 'User Name' and has a placeholder text 'Please enter username'; the second is labeled 'Password' and has a placeholder text 'Please enter password'. Below these fields is a black rounded button with the text 'Log In' in white.

Congratulations! You have successfully logged in to your Hotspot. Once you have logged in to your Hotspot via your web browser, you can see the Home page for the hotspot.

Home Page

In this section you can select any of the three options to configure your device.

HomeSMSSettings



Internet Info Button




Wi-Fi Status Button




Clients Button

Internet Mode:	Mobile Data
Network Status:	Connected
Connection Uptime:	2 Mins
MAC Address:	58:32:77:14:F9:7D
IP Address:	10.0.62.39
Subnet Mask:	255.255.255.240
Default Gateway:	10.0.62.40

Internet Info Button: you can check the Internet Status by clicking the icon , the Internet mode, network status, connection time and connection related parameters will be displayed.



Wi-Fi Status Button: You can check the Wi-Fi information of the hotspot by clicking the icon , the 2.4GHz & 5GHz Wi-Fi status, SSID and password will be displayed.




Clients Button: You can check the connected client information by clicking the icon , the connected client's device name, IP address and Mac address will be displayed.

SMS

You can click **"SMS"** to see the SMS information.

InBox: You can read, select, delete, refresh and select multiple SMS messages.



Note: The device only receives SMS, and does not send SMS.

Settings

You can click **"Settings"** on the main page to configure the hotspot.

Internet

Mobile Connection

In this section, you can configure your mobile data connection.

Note: If you are unsure of your APN Settings, please contact your service provider. The device supports auto APN, which means you do not need to edit APN settings for most cases.

Internet ▾
Mobile Connection
 Wireless ▸
 Network ▸
 Features ▸
 Management ▸

Mobile Connection

Mobile Data:
 Data Roaming:
 Carrier Name:
 Authentication Type:
 APN:
 User Name:
 Password:
 IP Type:
 MCC: 311
 MNC: 480
 GID1: ba01270000000000
 APN Type: Default
 Bear: 4G

Network Mode:
 Network Operator:

Mobile Data: To Enable/Disable Mobile connection

Data Roaming: To Enable/Disable Roaming connection **Carrier**

Name: APN Profile Name **Network Mode:** 4G **Network**

Operator: Auto/Manual, it is suggested to select **"Auto"**

Wireless

WLAN settings

In this section you can configure the Wi-Fi settings for your Hotspot device.

You can change the Wi-Fi SSID and password in this section, after updating your settings click **"Apply"**. Please note that any changes made in this section may require you to reconnect the

Wi-Fi.

2.4GHz is for **802.11b/g/n**

5GHz is for **802.11 ac/n**

The screenshot shows a router's web interface with a dark header bar containing 'Home', 'SMS', 'Settings' (highlighted), 'Logout', and a language dropdown set to 'English'. Below the header, a left sidebar lists navigation options: 'Internet', 'Wireless' (expanded), 'WLAN Mac Filter', 'Network', 'Features', and 'Management'. The 'Wireless' section is active, showing three sub-sections: 'WPS', 'Wi-Fi 2.4G', and 'Wi-Fi 5G'. Each sub-section contains a list of settings with dropdown menus and text input fields. The 'WPS' section has 'WPS Mode' set to 'Disable'. The 'Wi-Fi 2.4G' section has 'Status' set to 'Disable', 'Wi-Fi Name (SSID)' as 'JG-MP1-2.4G-F97D', 'Security Mode' as 'WPA/WPA2-PSK', 'Password' as '*****', '802.11 Mode' as '802.11n', 'Wi-Fi Channel' as 'Auto', 'Channel Width' as 'Auto', 'Visibility Status' as 'Enable', and 'Sleep Time' as '10 Minutes'. The 'Wi-Fi 5G' section has 'Status' set to 'Disable', 'Wi-Fi Name (SSID)' as 'JG-MP1-5G-F97E', 'Security Mode' as 'WPA/WPA2-PSK', 'Password' as '*****', '802.11 Mode' as '802.11ac', 'Wi-Fi Channel' as 'Auto', 'Channel Width' as 'Auto', 'Visibility Status' as 'Enable', and 'Sleep Time' as '10 Minutes'.

Section	Setting	Value
WPS	WPS Mode	Disable
Wi-Fi 2.4G	Status	Disable
	Wi-Fi Name (SSID)	JG-MP1-2.4G-F97D
	Security Mode	WPA/WPA2-PSK
	Password	*****
	802.11 Mode	802.11n
	Wi-Fi Channel	Auto
	Channel Width	Auto
	Visibility Status	Enable
	Sleep Time	10 Minutes
Wi-Fi 5G	Status	Disable
	Wi-Fi Name (SSID)	JG-MP1-5G-F97E
	Security Mode	WPA/WPA2-PSK
	Password	*****
	802.11 Mode	802.11ac
	Wi-Fi Channel	Auto
	Channel Width	Auto
	Visibility Status	Enable
	Sleep Time	10 Minutes

If you are unsure of Wi-Fi Channel and Channel Width, it is suggested to select **"Auto"**.

WLAN MAC Filter

MAC address filtering (also known as link-layer filtering) is a feature for IPv4 addresses that allows you to include or exclude computers and devices based on their MAC address. Every

Ethernet device has a unique MAC (Media Access Control) address. The MAC address is assigned at the factory and consists of six pairs of hexadecimal characters, for example, 00:DS:GG:22:35:01.

You need to know the MAC address of the devices you wish to filter.

You can choose **"Whitelist"** or **"Blacklist"** , both can be configured by selecting WLAN Mac Filter option.

Disable will disable the WLAN MAC filter.

Whitelist will only allow devices with the selected MAC address connect.

Blacklist will only deny devices with the selected MAC address from connecting.




Network

DHCP

In this section you can configure the DHCP settings. The Default values are:

1. DHCP server is enabled
2. Gateway IP address: 192.168.1.1
3. DHCP IP Range: 192.168.1.100 to 192.168.1.200
4. DHCP lease time: 24 hours(86400 seconds) Click **"Apply"** after configuring the new settings.




The screenshot shows a web interface for configuring network settings. At the top, there is a navigation bar with links for Home, SMS, Settings (highlighted in orange), Logout, and a language dropdown set to English. Below the navigation bar, there is a status bar showing 4G connectivity and various system icons. On the left side, there is a sidebar menu with options: Internet, Wireless, Network, DHCP (highlighted in orange), Features, and Management. The main content area is titled 'DHCP' in orange. It contains the following configuration fields: 'DHCP server' set to 'Enable' with a dropdown arrow; 'IP address' set to '192.168.1.1' with input boxes for each octet; 'DHCP IP range' set to '100 to 200' with input boxes, and the full range '192.168.1.100 to 192.168.1.200' displayed below; and 'DHCP lease time' set to '86400' seconds. At the bottom right of the configuration area, there is an orange 'Apply' button.

Firewall

Your hotspot's high-performance firewall feature continuously monitors internet traffic, protecting your network and connected devices from malicious internet attacks. In this section you can **"enable"** or **"Disable"** for Firewall/IP Filter settings.

Note: In order to enable IP Filter, the Firewall setting must be set to "Enable" first.



IP Filter

You can filter the packages by IP address, Protocol, Port number. IP Filtering's configuring includes LAN IP address, LAN port, WAN IP address, WAN port and Protocol functions.

Whitelist: Set the websites that users are allowed to access. If the whitelist is empty, users will not be able to access the Internet.

Blacklist: Set the websites that you do not want users to access. The value range of LAN/WAN Port is 1-65535.

Settings will not take effect until the "**Apply**" button is clicked.

Home
SMS
Settings
Logout
English

4G

Internet
Wireless
Network
Features
Firewall
IP Filter
Port Forwarding
DMZ Settings
Management

IP Filter

Status: Blocklist

- Whitelist: Set the websites that users are allowed to access. If the whitelist is empty, users will not be able to access the Internet.
- Blocklist: Set the websites that you do not want users to access.
- The value range of LAN/WAN Port is 1-65535.
- Settings will not take effect until the "Apply" button is clicked.

LAN IP Address	LAN Port	WAN IP Address	WAN Port	Protocol	Status	Options
192.168.1.100	5555	5.5.4.2	6666	TCP/UDP	On	<a>Edit <a>Delete
192.168.1.30	53333	5.5.4.2	44555	UDP	On	<a>Edit <a>Delete

Add

Apply

Port Forwarding

In this section you can enable external computers to access FTP or other services provided by the LAN.

IP address: Assigned to each device connected to a computer network that uses the Internet Protocol for communication.

LAN/WAN port: The part of the computer that provides services. It is a single part and the value range of LAN/WAN Port is 1-65535.

Protocol: Protocols applied by services.

Home SMS Settings Logout English

4G 40% 11:11

Internet Wireless Network Features Firewall IP Filter **Port Forwarding** DMZ Settings Management

Port Forwarding

-IP address: Designate a computer locales of the LAN to provide services.
 -LAN/WAN port: the port of the computer that provides services. It is a single port and the value range of LAN/WAN Port is 1-65535.
 -Protocol: Protocols applied by services.
 -Note: Settings will not take effect until the "Apply" button is clicked.

Name	WAN Port	LAN IP Address	LAN Port	Protocol	Status	Options
S.S.4.2	5555	192.168.1.122	6666	TCP/UDP	On	Edit Delete
S.S.4.3	6666	192.168.1.222	7777	UDP	On	Edit Delete

[Add](#)

[Apply](#)

Example: How to setup Port Forwarding for port 21 (FTP server)

Step 1: Assign a static IP to your local computer that is hosting the FTP server.

Step 2: Login to the Gateway and go to Settings / Features /Port forwarding

Step 3: Enter WAN Port to 21;

Enter LAN IP Address to be the static IP of computer,


Enter LAN port to 21;

Step 4: Click Apply to activate.

DMZ Settings

DMZ allows outside network to connect in and communicate

with internal LAN devices via this WAN interface.



The screenshot shows a web interface for a router. At the top, there are navigation links: Home, SMS, Settings (highlighted in orange), Logout, and a language dropdown set to English. Below the navigation bar, there's a status bar showing 4G signal, battery level, and notification icons. On the left side, there's a sidebar menu with items: Internet, Wireless, Network, Features, Firewall, IP Filter, Port Forwarding, DMZ Settings (highlighted in orange), and Management. The main content area is titled "DMZ Settings" in orange. It contains two settings: "DMZ status:" with a dropdown menu currently set to "Disable", and "DMZ IP address:" with a text input field containing "192.168.1.100". An "Apply" button is located at the bottom right of the settings area.

IP Address: Give a static IP address to the DMZ Host when Enabled radio button is checked. Be aware that this IP will be exposed to the WAN/Internet.

SNTP

In this section you can synchronize the internal clocks with the network.

Home SMS Settings Logout English

4G

Internet Wireless Network Features Management SNTP PIN Management Device Information Statistics System Admin Upgrade Reboot & Reset

SNTP

Status: Succeed to synchronize

Current time: 2020-04-29 06:16:29

☒ Enable auto-sync with network time

Time server1: time.windows.com

Time server2: clock.hk.he.net

Time server3: clocknyc.he.net

Time server4: clocksg.he.net

Time server5: clock.via.net

Time zone: (GMT+08:00)Easern Time

☐ Enable daylight saving time

PIN Management

In this section you can enable or disable the PIN of SIM card. Please be aware you can only input 3 times the wrong PIN number, otherwise the SIM card will be locked.

Home SMS Settings Logout English

4G

Internet Wireless Network Features Management Management SNTP PIN Management Device Information Statistics System Admin Upgrade Reboot & Reset

PIN Management

PIN operation: Enable

PIN code: *****

Remaining attempts: 3

Apply

Note: You will need to request the PUK code to your carrier.

Device Information

In this section you can check the basic information of the device. Please contact your carrier for more information.



The screenshot shows a web interface with a top navigation bar containing 'Home', 'SMS', 'Settings' (highlighted), 'Logout', and 'English'. Below the navigation bar is a status bar showing '4G' and various icons. On the left is a sidebar menu with items: 'Internet', 'Wireless', 'Network', 'Features', 'Management', 'SNTP', 'PIN Management', 'Device Information' (highlighted), 'Statistics', 'System Admin', 'Upgrade', and 'Reboot & Reset'. The main content area is titled 'Device Information' and contains two sections: 'Device Information' and 'RF Parameters'.

Device Information	
Device Name:	ORS400L
Software Version:	ORS400L_2.00.01_EQ100
Hardware Version:	ORB400L_V1.02_PCB
IMEI:	356640110000232
IMSI:	46007029113186
MAC:	88:32:77:14:F9:7D

RF Parameters	
RSRP:	-113dBm
RSS:	-79dBm
RSRQ:	-16dB
SINR:	0.0dB
PCI:	219

Device Name: Name of the Hotspot for identification purpose.

Software Version: Software version currently loaded in the Hotspot. **Hardware Version:** Hardware version currently loaded in the Hotspot. **IMEI:** The unique identification number that is used to identify the 4G-LTE module. **IMSI:** The international mobile subscriber identity used to uniquely identify the 4G-LTE module. **MAC:** A unique number that identifies the Hotspot.

Statistics

In this section you can easily monitor your data usage. Please note that upload, download and total data usage will be reset when the device is restored to default factory settings.



Clear history: Click it to clear the history statistics.

Traffic configuration: Click to configure data traffic plan as below.

Traffic configuration

Traffic starts to count time:

1
▼

day

Monthly data traffic quota:

0.00

MB
▼

Threshold:

80

% (0-100%)

This traffic statistic is for reference only. After reaching the monthly threshold, the router will not stop your data service.

Apply
Cancel

System Admin


The admin account can change all hotspot settings. Click **Apply** to save the new Username and the new Password.

Note: To keep your hotspot secure, it is recommended to create a stronger password.

The screenshot shows a web interface for a hotspot's system administration. On the left is a sidebar menu with options: Internet, Wireless, Network, Features, Management, SNMP, PIN Management, Device Information, Statistics, System Admin (highlighted in orange), Upgrade, and Reboot & Reset. The main content area has two sections. The 'Admin Username' section contains three input fields: 'Current Username', 'New Username', and 'Current Password', followed by an orange 'Apply' button. The 'Admin Password' section contains three input fields: 'Current Password', 'New Password', and 'Confirm Password', followed by an orange 'Apply' button. The top navigation bar includes links for Home, SMS, Settings, and Logout, along with a language dropdown set to English. The top status bar shows '4G' connectivity and various system icons.

Upgrade

Your hotspot can automatically detect firmware updates. In this section you can manually check if there is new firmware for your hotspot and update. When there is a new version, it will display a **"new"** icon in the WebUI, and you can select the icon to proceed with the update. You can also check the current software and hardware information in this page.




Online Update operation:

Click the button **“Check for update”** to confirm if there is an update available. If there is one available, it will guide you to confirm if you want to proceed with the update.

Reboot & Reset

In this section you can reboot your device or reset it to factory default settings.



Reboot: Select to reboot your device.

Reset: Select to reset your device.

Logout

Click **logout** to logout from your hotspot. Once you log out you will return to the login page.

Trouble Shooting

If you are having trouble with your device, here are a few things you can do to get it to function properly.

1. If the device is not responsive, reboot it by press the **"Power"** button for about 8 seconds
2. Restore factory settings

Q&A

Q: What do I do if I see the SSID but failed to connect?

- A: 1. Check if the password you entered is the correct one.
2. Check if WPS security is enabled on your PC? If so, check the device to see if it is expecting a WPS action from your PC.

Q: What to do if there is no service?

- A: The possible reasons are an unstable network signal, or a hardware problem. You can try the following solutions:
1. If you are inside a building or near a structure that may be blocking the signal, change the position or location of

the device. For example, try moving the device close to a window.

2. Check the hardware for any loose parts or damage.

Q: What to do if I have forgotten my Wi-Fi Key?

A: 1. You can find the Wi-Fi Key in the Wi-Fi Info page on the LCD.

2. You can also reset the device to factory defaults by press the reset button for 5 seconds.

Q: What to do if “PIN locks” or “PUK locks” ?

A: The SIM card is locked. Login into the WebUI (<http://192.168.1.1> or <http://device.WebUI>) and input the PIN or PUK code you received from your carrier provider and Enter your PIN code or PUK code you got from the operator.

Note: If you entered wrong PIN code 3 times, then PUK is needed, and if the wrong PUK is entered 10 times, the SIM card will be locked forever.

Q: Data connection failed.

A: You may be on a not network or limited coverage area, try to move to a different location or a better network coverage area.

Q: The modem cannot connect to the Internet when overseas

A: You can check if the data roaming function is enabled in the Device Setting page on the display of the device device.

Note: Make sure you have international roaming enabled on your

plan. You can contact your service provider before you go overseas to enable roaming.

Health and Safety Information

To the Owner

- Some electronic devices, such as the electronic system of vehicles, are susceptible to electromagnetic interference sent by your device if inadequately shielded. Please consult the manufacturer of your device before using if necessary.
- Operating your device may interfere with medical devices like hearing aids and pacemakers. Please always keep them more than 20 centimeters away from such medical devices when they are turned on. Turn your device off if necessary. Consult a physician or the manufacturer of the medical device before using your device.
- Be aware of the usage limitation when using your device at places such as oil warehouses or chemical factories, where there are explosive gases or explosive products being processed. Turn off your device if required.
- The use of electronic transmitting devices is forbidden in aircrafts, at gas stations, and in hospitals. Please observe and obey all warning signs and power off your device in these conditions.
- Do not touch the inner antenna area; it will affect your device's performance.

- Store your device out of the reach of little children. Your device may cause injury if used as a toy.
- Do not touch the metallic parts of your device when the device is operating as this may cause burns.

Using Your Device

- Please use original or authorized accessories only. Using any unauthorized accessories may affect your device's performance, and violate related national regulations about telecom terminals.
- Avoid using your device near or inside metallic structures or establishments that can emit electromagnetic waves; it may influence signal reception.
- Your device is not waterproof. Please keep it dry and store in a shady and cool place.
- Do not use your device immediately after a sudden temperature change. In such case, it will produce moisture inside and outside your device. Wait until it becomes dry.
- Handle your device carefully. Do not drop, bend, or strike it; your device may get damaged.
- Do not attempt to disassemble the device.
- An operating temperature range of -10°C to +45 °C and humidity range of 5% to 95% are recommended.

Battery Handling

- Do not short-circuit the battery, as this can cause excessive heat and fire.
- Do not store battery in hot areas or dispose of it in a fire, as this can cause an explosion.
- Do not disassemble or modify the battery.
- When not using the battery for a long period, remove it from your device and store it in a cool, dry place.
- Never use a damaged or worn-out charger or battery.
- Dispose used batteries in an approved recycling container.



WARNING! Do not handle or touch the battery if it is damaged.

Limited Warranty

This warranty does not apply to defects or errors in the Product caused by:

- i. Reasonable abrasion.
- ii. End User's failure to follow KonnectONE's installation, operation or maintenance instructions or procedures.
- iii. End User's mishandling, misuse, negligence, or improper installation, disassembly, storage, servicing or operation of the Product.
- iv. Modifications or repairs not made by KonnectONE or a

KonnnectONE-certified individual.

v. Power failures, surges, fire, flood, accidents, actions of third parties or other events outside KonnectONE's reasonable control.

vi. Usage of third-party products, or usage in conjunction with third-party products provided that such defects are due to the combined usage.

vii. Any other cause beyond the range of normal usage intended for the Product.

- End User shall have no right to reject or return the Product, or receive a refund for the Product from KonnectONE under the above-mentioned situations.
- This warranty is End User's sole remedy and KonnectONE's sole liability for defective or nonconforming items, and is in lieu of all other warranties, expressed, implied or statutory, including but not limited to the implied warranties of merchantability and fitness for a particular purpose, unless otherwise required under the mandatory provisions of the law.

Limitation of Liability

KonnnectONE shall not be liable for any loss of profits or indirect, special, incidental or consequential damages resulting from or arising out of or in connection with using of this product, whether or not KonnectONE had been advised, knew or should have known of the possibility of such damages, including, but

not limited to lost profits, interruption of business, cost of capital, cost of substitute facilities or product, or any downtime cost.

Radio Frequency (RF) Energy

This model device meets the government's requirements for exposure to radio waves. This device is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the U.S. Government: The exposure standard for wireless devices employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6 W/kg. Tests for SAR are conducted using standard operating positions accepted by the FCC with the device transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the device while operating can be well below the maximum value. This is because the device is designed to operate at multiple power levels so as to use only the position required to reach the network. In general, the closer you are to a wireless base station, the lower the power output. This device was tested for typical body-worn operations with the back of the handset kept 10mm from the body.

The highest SAR value for the model device as reported to the FCC when worn on the body, as described in this user guide, is 1.101 W/kg (Body-worn measurements differ among device models, depending upon available

enhancements and FCC requirements.)

While there may be differences between the SAR levels of various devices and at various positions, they all meet the government requirement.

The FCC has granted an Equipment Authorization for this model device with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this model device is on file with the FCC and can be found under the Display Grant section of

<http://www.fcc.gov/oet/ea/fccid/> after searching for: 2AWVS-M14

FCC Compliance

FCC ID: 2AWVS-M14 This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: Changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable

protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



WARNING: Cancer and Reproductive Harm
www.P65Warnings.ca.gov