



Instruction Manual

Sunrise Alarm Clock


Model: DS236



Thank you for purchasing DreamSky Sunrise Alarm Clock. To ensure the best product performance, please read this user manual in detail and retain in for future reference.


Questions? Contact Customer Service Center by Email:
info@dreamsky4u.com

Screen Overview



- 1. Night Light / Color Light
- 2. Sleep Sound
- 3. FM Radio
- 4. Bluetooth
- 5. Timer
- 6. Days of the Week
- 7. AM/PM
- 8. Time
- 9. Alarm 1
- 10. Alarm 2
- 11. Sunrise

Button Overview



- 1. **SUNRISE**: press to enter sunrise set

1

- 2. **ALARM 1 SET**: hold to enter alarm 1 set
press to check alarm 1 time
press to enable/disable alarm 1
- 3. **ALARM 2 SET**: hold to enter alarm 2 set
press to check alarm 2 time
press to enable/disable alarm 2

- 4. **Night Light / Color Light Dimmer**
- 5. **LIGHT**: press to turn on color light
hold to exit

- 6. **TIMER**: press to turn on timer
hold to exit

- 7. **ALARM OFF**: **When alarm goes off**
press to activate snooze,
hold to stop alarm

- At time keeping mode**
press to turn night light on or off
hold to enter snooze set

- 8. **Bluetooth**: press to turn on Bluetooth
hold to turn off Bluetooth

- 9. **SLEEP**: press to turn on sleep sound
hold to turn off sleep sound

- 10. **VOLUME CONTROL**: press to turn FM/Sleep Sounds/Bluetooth Speaker


- 11. **FM**: press to turn FM radio ON or OFF
hold to auto tuning

- 12. **PRESET**: press to turn on the preset radio station
hold to save the playing radio station

2

- 13. **BRIGHTNESS**: press to adjust display brightness
hold to enter time set mode

Back View



- 1. 5V1A USB Charging Port (Output)
- 2. Speaker
- 3. 5V13A Type-C Input
- 4. Battery Compartment
- 5. Radio Antenna

Get Started

- 1. Insert 2 x AAA alkaline batteries (not supplied) into the battery compartment.
- 2. Plug the included power adapter into a working socket.

Note:

- 1) The clock is powered by adapter only and batteries only work for storing the clock setting during power outage. With battery power

3

alone, time will not display.

- 2) For normal performance of the clock, please use the included power adapter and USB cord (5V13A).

Set Time

Tip: Connecting Bluetooth to your phone will synchronize time automatically (see page 9 for details).

- 1. Press and hold **ALARM 1 SET** button for 2s to enter time set mode, time format "12H" (24H) flashes.
- 2. Rotate **ALARM 1 SET** button to set time format.
- 3. Press **ALARM 1 SET** button, Hour digits flash.
- 4. Rotate **ALARM 1 SET** button to set hour.
- 5. Press **ALARM 1 SET** button, Minute digits flash.
- 6. Rotate **ALARM 1 SET** button to set minute.
- 7. Press **ALARM 1 SET** button, day of the week flashes.
- 8. Rotate **ALARM 1 SET** button to set day of the week.
- 9. Press **ALARM 1 SET** button to save and exit setting.

4

Set Display Brightness

At time keeping mode, press **BRIGHTNESS** button to set display brightness, 4 levels brightness and OFF optional.

Set Alarm

Tip: Setup steps for alarm 1 and alarm 2 are the same.

- 1. Press and hold **ALARM 1 SET** button for 2s to enter alarm 1 set mode, Hour digits flash.
- 2. Rotate **ALARM 1 SET** button to set hour.
- 3. Press **ALARM 1 SET** button, Minute digits flash.
- 4. Rotate **ALARM 1 SET** button to set minute.
- 5. Press **ALARM 1 SET** button, the alarm sound code (S01/S02...) flashes.
- 6. Rotate **ALARM 1 SET** button to select alarm sound (OFF-S08).
- * If OFF is selected, the alarm will go off with light only; and it will skip alarm volume setting steps (step 7 & 8).
- * If S08 (FM radio) is selected, it will play the last station listened to when alarm goes off.
- 7. Press **ALARM 1 SET** button, day of the week flashes.
- 8. Rotate **ALARM 1 SET** button to set day of the week.
- 9. Press **ALARM 1 SET** button to save and exit setting.

5

- 7. Press **ALARM 1 SET** button, alarm volume (U08/U09...) flashes.
- 8. Rotate **ALARM 1 SET** button to set alarm volume (U01-U16).
- 9. Press **ALARM 1 SET** button, alarm mode flashes.
- 10. Rotate **ALARM 1 SET** button to set alarm mode.
- * 1-7: Mon-Sun (Daily mode);
1-5: Mon-Fri (Weekday Mode);
6-7: Sat-Sun (Weekend Mode)
- 11. Press **ALARM 1 SET** button to save and exit setting.
- * At time keeping mode, you can press the **ALARM 1 SET** or **ALARM 2 SET** button to check the alarm time and alarm mode you set.

Set Sunrise

The sunrise alarm clock simulates the sun rising up gradually to wake you up naturally. You can set how early the clock starts to light up before alarm goes off and the maximum brightness of the sunrise light.

- 1. Press **SUNRISE** button to enter set mode, the sunrise duration (10 MIN/20 MIN...) flashes.

6

- 2. Rotate **SUNRISE** button to set sunrise duration (0/10/20/30/40/50/60 minutes).
- 3. Press **SUNRISE** button, brightness level for sunrise flashes.
- 4. Rotate **SUNRISE** button to set brightness (OFF-L20).
- * If OFF is selected, alarm will go off with sound only.
- 5. Press **SUNRISE** button to save and exit setting.

* Examples of when sunrise light turns on based on the alarm time and sunrise duration you set.

Alarm Goes off at	Sunrise Duration	Light Comes on at
7:00 AM	0 Minute	7:00 AM
7:00 AM	10 Minutes	6:50 AM
7:00 AM	30 Minutes	6:30 AM
7:00 AM	60 Minutes	6:00 AM

* If you set the sunrise duration shorter, it will light up to the maximum brightness you set faster.

Set Snooze

Tip: You can set the snooze duration and whether the sunrise light stays on during snooze.

- 1. Press and hold the **ALARM 1 SET** button for 2s to enter snooze set mode, snooze duration (5 MIN/6 MIN...) flashes.

7

- 2. Rotate **ALARM 1 SET** button to set snooze duration (5-30 minutes).
- 3. Press **ALARM 1 SET** button, sunrise light ON or OFF flashes.
- 4. Rotate **ALARM 1 SET** button to set the sunrise light on or off during snooze mode.
- 5. Press **ALARM 1 SET** button to save and exit setting.
- * When alarm goes off, press **ALARM 1 SET** button to activate snooze mode, alarm will go off again by the end of the snooze duration you set.

Stop Alarm

When alarm goes off, there are 2 methods to stop the alarm for the day.

- 1. Press the **ALARM 1 SET** or **ALARM 2 SET** button.
- 2. Press and hold the **ALARM 1 SET** button for 3s.
- * If there is no operation, the alarm will turn off automatically after 30 minutes.

Enable/Disable Alarm

- Press **ALARM 1 SET** to turn the alarm 1 on or off. If alarm 1 is disabled, the alarm 1 icon will disappear from the display.

8

- Press **ALARM 2 SET** to turn the alarm 2 on or off. If alarm 2 is disabled, the alarm 2 icon will disappear from the display.

Bluetooth Mode

Tip: Connecting Bluetooth to your phone will synchronize time automatically. Some phones may pop up a window asking access to messages, please allow access to you phone so the time could sync.

- 1. Press the **Bluetooth** button to turn on the Bluetooth, Bluetooth icon will flash on the display, indicating waiting pairing mode.
- 2. Turn on the Bluetooth on your phone and select "DS236" on the Bluetooth list to initiate pairing.
- * If pairing successfully, a voice prompt "connected" will be played and the Bluetooth icon will remain still.
- 3. Press the **Bluetooth** button to play or pause audio.
- 4. Rotate the **Bluetooth** button to play the previous or next track.
- 5. Press and hold the **Bluetooth** button for 2 seconds to turn off the Bluetooth.

9

Adjust the Audio's Volume

- 1) Scroll the volume wheel  of the clock.
- 2) Turn up/down your phone's volume.

Clear the Pairing History

-  +  Press and hold the  button and the  button together for 3 seconds to clear the pairing history, a voice prompt "disconnected" will be played and the Bluetooth icon  will flash on the display.

FM Radio

Tip: For best reception, please uncoil the antenna at the back and adjust the antenna's direction or position.

1. Press **FM** button to turn on the FM radio.
2. Rotate the  button to tune in radio station manually.
3. Press and hold the **FM** button for 2 seconds to tune in radio station automatically.
** It will stop tuning in when a strong station is located.*
4. Scroll the volume wheel  to adjust the radio's volume.
5. Press **FM** button to turn off the radio

FM Radio Preset

1. Press **FM** button to turn on the radio.
2. Rotate the  button to tune in radio station.
3. Press and hold the **PRESET** button, the preset number P01/P02... will flashes on the display.
4. Rotate the  button to select a preset number to save the currently playing station. (P01-P20 optional)
5. Press the **PRESET** button to confirm and exit.
** Repeat step 2-5 to preset other station.*
6. Press **FM** button to turn off the radio.

Listen to the Preset Radio Station

1. Press the **PRESET** button to turn on the preset radio station.
2. Press the **PRESET** button again to select other preset radio station
3. Press the **FM** button to exit.

Set Sleep Sounds

1. Press the  button to turn on the sleep sound.
2. Rotate the  button to switch to the previous or next sound.
3. Scroll the volume wheel  to adjust the volume.
4. Press and hold the  button for 2 seconds to turn off the sleep sound.

** There are 26 sounds with the order as below*

- | | |
|------------------------|-----------------------|
| 1. Brown Noise | 2. Pink Noise |
| 3. Blue Noise | 4. White Noise |
| 5. Soft Fan | 6. Household Fan |
| 7. Industrial Fan | 8. Loud Fan |
| 9. Rain | 10. Rain with Thunder |
| 11. Stream in the Cave | 12. Brook |
| 13. River | 14. Gentle Sea Wave |
| 15. Strong Sea Wave | 16. Little Sea Wave |
| 17. Bird | 18. Bonfire |
| 19. Train | 20. Tik-Tok |
| 21. Alpha Wave Music | 22. Heartbeat |
| 23. Summer Night | 24. Lullaby 1 |
| 25. Lullaby 2 | 26. Lullaby 3 |

Night Light

1. At time keeping mode, press the  button to turn on the night light.
2. Scroll the light wheel  to adjust the brightness (L01-L20)
3. Press the  button again to turn off the night light.
** The night light can't be turned on in Bluetooth mode.*

Color Light

1. Press the **LIGHT** button to turn on the color light.
2. Press the **LIGHT** button repeatedly to change the light color.
3. Scroll the light wheel  to adjust the brightness (L01-L20)
4. Press and hold the **LIGHT** button for 2 seconds to turn off the color light.
** There are 15 color lights (C01-C15) optional.*
C01-C05: RGB Light
C06-C07: RGB Music Light (light effect follows the audio rhythm)
C08-C15: Solid color light

Set Countdown Timer

Tip: you can set a countdown timer for both sound and light, for sound only or for light only.

1. Press the **TIMER** button to turn on the countdown timer, the countdown time 10 MIN/20 MIN... will flashes
2. While the countdown time flashes, rotate the  button to set the countdown time (10-480 minutes optional)
- Or press the **TIMER** button repeatedly to set the countdown time.
3. Press and hold the **TIMER** button for 2 seconds to turn off the timer.

** At time keeping mode, press the **TIMER** button once to check the remaining countdown time.*

USB Charging (5V/1A)

-  There is a USB port at the back of the clock to charge your cellphone or other electronic gadgets.
- * It is not recommended to charge high-power electronic products such as tablets and hair dryers.*

FAQ

1. How to set alarm to go off with sound only?

Enter the sunrise set mode and set the brightness of the sunrise light to OFF (see **Set Sunrise** part for details).

2. How to set alarm to go off with light only?

Enter alarm set mode and at alarm sound setting step, select OFF (see **Set Alarm** part for details)

3. How to set radio as alarm?

Enter alarm set mode and at alarm sound setting step, select S08 (see **Set Alarm** part for details).

4. How to set radio alarm to go off with the station I prefer?

If radio (S08) is selected as alarm sound, it will go off with the last station you listened to.
For example, if 90.5 MHz is the last station you listened to, when alarm goes off, it will play the 90.5 MHz station. If you change radio station to 104.3 MHz, when alarm goes off, it will play the 104.3 MHz station.

5. How to keep the light on/off during snooze mode?

Enter snooze set mode and at ON/OFF selection step, if you want to keep light on during snooze mode, select ON, if OFF wanted, select OFF (see **Set Snooze** part for details).

6. Why my alarm didn't go off?

- Please ensure the alarm is turned on (alarm icon  /  shows up on display).
- Please check the alarm mode you set (1-7: Mon-Sun; 1-5: Mon-Fri; 6-7: Sat-Sun).
- Please check if the alarm is set to AM or PM time.

7. The clock time does not sync with my phone after Bluetooth pairing.

Find Bluetooth device DS236 on your phone and proceed to forget this device, then scan and re-pair DS236, select allow access to your

messages if there is a pop-up window asking access to your phone (see **Bluetooth Mode** part for details).

** If the issue remains, please unplug the clock and try the above steps again.*

Our Warranty

30 days money back for any reason

Within 30 days after the date of purchase, you can return your undamaged product to Amazon and get a full refund for any reason.

12 months replacement for quality-related issue

Within 12 months after the date of purchase, we provide replacement for quality-related issues.

Kind reminder: be sure to use your products per instructions.

Lifetime user support

If you have any concerns, questions or need assistance while using this product please contact us by email: info@dreamsky4u.com

FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a

Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. In order to avoid the possibility of exceeding the FCC radio frequency exposure limits, Human proximity to the antenna shall not be less than 0cm during normal operation.