



CIRCOOTER

by Raptor & Raptor Pro

尺寸: 140 x 210 mm

材质及工艺: 封面彩印对折 200g铜版纸覆光膜
内容黑白105g铜版纸
骑马钉


日期: 20220624

备注: Raptor & Raptor Pro
说明书



CIRCOOTER

Raptor | Raptor Pro
User Manual



Keep exploring the world
www.circooter.com

Contents

Product Safety Notice	01
Package Contents	02
Product Overview	03
Specification	04
Display Content	05
Screen	07
E-Scooter APP	08
Assemble	09
Attention	09
Riding Basics	10
Riding Notice	12
Dangerous Actions	13
Charging	13
Disc Brake Adjustment	14
Safety Instructions	15
Limited Warranty Statement	16
Error Code	17
FAQ	18
Contact Us	18



Product Safety Notice



Don't Ride Until You Read This:

-  Always wear a helmet, elbow pads, and knee pads when riding your electric scooter.
-  Make sure your electric scooter has a full charge, and all screws are closely tightened before riding.
-  Always be aware of local road laws, and follow them.
-  Do not ride under the influence of drugs or alcohol.
-  Always respect pedestrians.
-  Do not ride under heavy rain or extreme temperature conditions. Do not ride in a puddle deeper than 1.5 inches. The electric scooter may slide causing injury. These conditions may damage the electronics and void the warranty.

Warning Message

Avoid Water --- The electric scooter has an IPX4 rating. The electronics may be damaged due to water and water damage is not covered by our warranty. Riding in heavy rain or extreme temperature conditions is also very dangerous and may result in injury.

Keep Away from Fire --- Do not bring the electric scooter near the fire.

Proper Storage --- Avoid prolonged exposure to sun or rain and avoid storage in places with high temperatures or corrosive gas.

Abuse --- We do not cover physical damage due to negligent care and extreme riding.

Safety Ride --- Whenever you ride the circooter electric scooter, you risk severe injury or even death from loss of control, collisions, and falls.

Be Careful --- Use caution and ride at your own risk.

No Modification --- Only use original brand accessories. Unauthorized modification is strictly prohibited.

Before Riding --- Be sure to check that the entire scooter is in good condition, such as whether the locking screws of the motor, front wheels, folding joints, etc. are fastened and reliable. Do not ride at will before correcting any problems.

Before Riding --- be sure to check that the braking system is functioning properly, also be sure to check that all safety labels are in place and you understand the safety warnings.

No Hanging --- Do not hang heavy objects on the handlebars.

No Use --- Pregnant women, the disabled, and those with heart problems should not use this product.

Save Electricity --- To conserve electricity, do not frequent braking, ride against the wind, and carry heavy loads including other people.

Age Limit --- The electric scooter should never be used by children under the age of 18.

Not Overload --- Never exceed the 440 lbs (200 kg) maximum load rating.

Away Danger --- Keep hands and all body parts away from moving parts while operating the electric scooter.


Caution --- Make note that additional insurance may be required to cover situations you encounter while riding an electric scooter. It is recommended that you contact an insurance company or broker for advice and consultation.




Package Contents

Carefully check package contents, if anything is missing or damaged, please contact circooter customer service for support: hello@circooter.com


Keep the package box to ship back the scooter if necessary.




1 x Scooter



1 x Charger




4 x Screws



1 x Allen Wrench



Product Overview





Specification




Project	Content	Raptor	Raptor Pro
Vehicle Parameters	Unfolded Dimensions	51*26*47 IN / 129*67*118 CM	51*26*47 IN / 129*67*118 CM
	Folded Dimensions	51*26*22 IN / 129*67*55 CM	51*26*22 IN / 129*67*55 CM
	Net Weight	54 LB / 24.5 KG	60.8 LB / 27.6 KG
	Top Speed	25 - 28 MPH / 40-45 KM/H	25 - 28 MPH / 40-45 KM/H
	Max. Range	21-25 Miles / 35-40 KM	28-31 Miles / 45-50 KM
	Hill Climbing	25% - 30% Grade	25% - 30% Grade
	Terrain	All-Terrain Wheels	All-Terrain Wheels
	Operating Temperature	14 °F - 104 °F	14 °F - 104 °F
	Storage Temperature	-4 °F - 104 °F	-4 °F - 104 °F
	Waterproof Rating	IPX4	IPX4
	Charging Time	5-6 H	7-8 H
Battery Parameters	Rated Voltage	48V	48V
	Capacity	15 Ah	20 Ah
Motor Parameters	Wheel Size	10 Inches	10 Inches
	Tire Type	Honeycomb Solid Off-Road Tyres	Honeycomb Solid Off-Road Tyres
	Rated Voltage	48 V	48 V
	Power	800 W	800 W x2
	Motor Type	Brushless DC Motor	Brushless DC Motor
Brake	Brakes	Front and rear mechanical disc brake + electric brake	Front and rear mechanical disc brake + electric brake
Charger	Input Voltage	100 V ~ 240 V	100 V ~ 240 V
	Output Voltage	54.6 V	54.6 V
	Output Current	2 Ah	2 Ah
	Maximum Load	440 LB / 200 KG	440 LB / 200 KG



Display Content




Display Content



	Battery level		Sport mode
	Single/ Dual Motor Mode		Drive mode
READY	Ready to start		ECO mode
	Cruise control		Top speed
	Headlight		Single mileage
	Temperature		



Display Content



Power ON/OFF button:

Press and hold for 3S to power on / off.



Light switch:

Press the switch to turn on / off light.



Klaxon:

Press and hold the switch to alarm.



Speed :

Click the speed switch button to increase speed.



Mode setting :

Switch from KM/H to MPH.



Screen



Battery Level Display:

6-bar battery level.



6 Bars:

90%~100% of battery level



5 Bars:

70%~90% of battery level



Charging prompt

when the battery runs out and the scooter slides to a natural stop due to inertia. So you have to charge it very soon. It is recommended not to drain the battery by 100%. Charge it before use.



READY:

After turning on the E-scooter, the word "READY" appears on the instrument display to remind rider to wear a helmet, knee pads, elbow pads, and abide by traffic regulations when riding.



Active Cruise Control:

Turn on the cruise function, you can release the thumb throttle, the scooter moves at a uniform speed. After you press the brake to stop, press the throttle again, and the scooter returns to the initial state.



Headlight:

After the scooter is powered on, press the headlight switch button for clicking the multi-function switch. Symbols appear on the instrument display when all the lights are turned on.



Maximum Speed:

It shows the highest speed of the whole ride.



Current Speed:

The display shows the current speed during riding.



Single Mileage:

Shows the current mileage during the ride, and automatically returns to zero after the scooter is powered off.