

Senquip QUAD User Guide

Release

Read the Docs, Inc \& contributors

Jan 24, 2024

List of Figures	iii
1 Introduction	1
1.1 What is the Senquip QUAD.	1
1.2 Who can use the Senquip QUAD.	2
1.3 You can rely on the Senquip QUAD	2
1.4 What is included with your Senquip QUAD	3
1.5 Regulatory Information	4
2 Getting Started	7
2.1 Opening the Box	7
2.2 Mounting	8
2.3 User access	9
2.4 Anti tamper screw	11
2.5 SIM card install	13
2.6 Wiring guide	14
2.7 Fitting the antenna	17
2.8 Initial setup	18
3 Power Supply	27
3.1 Permanent power	27
3.2 Internal rechargeable battery	28
3.3 Power consumption.	29
3.4 Freight mode	29
4 General Setup	31
4.1 Measurement and transmit intervals	31
4.2 Power supply	33
4.3 Settings.	34
5 Internal Sensors	37
5.1 Light sensor	37
5.2 Accelerometer	37
5.3 Pressure sensor	40
5.4 Magnetic switch.	40
5.5 Temperature sensor.	41
5.6 GPS.	42
5.7 Bluetooth interface	44
5.8 Internal sensor settings.	45
6 External Sensors	49


6.1	Inputs and Outputs	49
6.2	Serial interface.	57
6.3	CAN Bus interface	61
6.4	External Sensor Settings	62
7	Scripting	71
7.1	Risks	71
7.2	Access	71
7.3	Writing and deploying a script	72
8	Network Connection	75
8.1	Wi-Fi specification	75
8.2	4G LTE specification	75
8.3	Connecting to a Wi-Fi network	76
8.4	Connecting to a mobile network	79
8.5	Network settings	80
9	Endpoint Setup	81
9.1	Data security	81
9.2	Data format	81
9.3	Data buffer.	82
9.4	UDP	83
9.5	HTTP	83
9.6	HTTPS	83
9.7	MQTT	83
9.8	MQTT over TLS	83
9.9	Settings.	84
10	Senquip Portal	87
10.1	Using the Senquip Portal.	87
10.2	Management and Hosting on the Senquip Portal	98
11	Mechanical Specification	101
11.1	Mechanical drawings	101
11.2	Mechanical Fittings	102
11.3	Environmental	103
11.4	Material Specification	104
12	Maintenance	107
12.1	Replacing the LiPo Battery	107
13	Frequently Asked Questions	111
13.1	Introduction	111
13.2	Senquip Portal	111
13.3	Network	113
13.4	GPS / GNSS	115
13.5	Power	115
13.6	Setup	118
13.7	Operation.	119
13.8	Scripting	119
14	Glossary	121
	Index	123

Figure 1.1: 1 x Senquip QUAD	3
Figure 1.2: 1 x GNSS and 4G LTE combination antenna	3
Figure 1.3: 1 x 2-hole and 1 x 3-hole gland insert	3
Figure 1.4: 1 x 3mm Allen key	3
Figure 1.5: 1 x Getting started guide	4
Figure 1.6: Regulatory information including FCC ID	6
Figure 2.1: Senquip QUAD packaging with intact security seal.	7
Figure 2.2: Senquip QUAD mounting points circled in red	8
Figure 2.3: Rail mounting the Senquip QUAD	9
Figure 2.4: Removing from a DIN Rail.	9
Figure 2.5: User access for the Senquip QUAD	10
Figure 2.6: Four cover screws	11
Figure 2.7: Tamper evident screw	12
Figure 2.8: Tamper evident screw in place on a Senquip QUAD.	12
Figure 2.9: SIM Card sizes	13
Figure 2.10: Identifying the SIM card slot	13
Figure 2.11: Correct insertion of a SIM card	14
Figure 2.12: Insert SIM to the right	14
Figure 2.13: Interface pin numbers	15
Figure 2.14: Wiring example with a sheathed cable.	17
Figure 2.15: GNSS and 4G LTE combination antenna.	18
Figure 2.16: Press the tab to remove the connector	18
Figure 2.17: Buttons and LEDs for setup	19
Figure 2.18: The default passwords can be found under the lid	20
Figure 2.19: Label with general information and passwords.	21
Figure 2.20: Matching device ID label	22
Figure 2.21: Search for Wi-Fi networks	23
Figure 2.22: Enter the Wi-Fi password	24
Figure 2.23: Accessing the web-server	25
Figure 2.24: Browsing the web-server.	26
Figure 3.1: Typical Senquip QUAD solar panel	27
Figure 3.2: Entering freight mode	30
Figure 4.1: Timing flowchart.	32
Figure 5.1: Definition of pitch	38
Figure 5.2: Definition of roll	38
Figure 5.3: Definition of tilt	39
Figure 5.4: Location of magnetic switch	41
Figure 5.5: GPS alert parameters	43
Figure 5.6: Example BLE beacons from ELA	44
Figure 6.1: Simplified internal IO architecture.	50
Figure 6.2: Powering external devices on an IO	51
Figure 6.3: 2-wire 4-20mA device install	52
Figure 6.4: 3-wire 4-20mA device install	53

Figure 6.5: Pulse counting	54
Figure 6.6: Hysteresis	55
Figure 6.7: Voltage accuracy across all IO channels	56
Figure 7.1: Senquip scripting page	72
Figure 7.2: Feedback on unsuccessful script	73
Figure 8.1: FAKRA-D 4G LTE antenna connector	76
Figure 8.2: Save changes and reboot	77
Figure 8.3: Note the IP address on your network	78
Figure 8.4: Access via local IP	79
Figure 9.1: Example JSON data packet	82
Figure 9.2: Pending change where the base interval has been changed to 600 seconds	84
Figure 10.1: Welcome to the Senquip Portal	88
Figure 10.2: View or add Senquip devices	89
Figure 10.3: Senquip device dashboard.	90
Figure 10.4: Example chart showing the days temperature	91
Figure 10.5: Data visualisation in different formats	91
Figure 10.6: Buttons to trigger remote operations	92
Figure 10.7: Navigate to device configuration pages	92
Figure 10.8: Dashboard with an image showing the system being monitored.	93
Figure 10.9: Data associated with the selected device shown in a table.	94
Figure 10.10: Remote update of device settings via the Senquip Portal.	96
Figure 10.11: Remote firmware updates via the Senquip Portal	97
Figure 10.12: Configure event forwarding	98
Figure 11.1: Dimensioned front view	101
Figure 11.2: Dimensioned side view.	102
Figure 11.3: Dimensioned rear view.	102
Figure 11.4: Dimensioned bottom view	102
Figure 11.5: IP number description	104
Figure 12.1: LEDs and configuration switches.	108
Figure 12.2: Remove the SIM card before opening.	108
Figure 12.3: Removing the battery cover.	109
Figure 12.4: Orientation of Lipo Battery.	109
Figure 12.5: Battery plug removed.	110
Figure 12.6: Remove the old tape.	110

Introduction

1.1 What is the Senquip QUAD



Senquip manufactures rugged, programmable telemetry devices that connect to industrial sensors and system and send the data measured to the Senquip Portal or a server of your choice.

The Senquip QUAD is designed for applications where the telemetry device needs to be hidden, is in a metal enclosure, and so needs external antennas.

Built in sensors allow measurement of supply voltage, battery voltage, time, position, speed, ambient temperature, pitch, roll and pressure. Interfaces are provided for RS232, RS485, MODBUS, CAN bus, Bluetooth, 4-20mA, pulse, frequency, and voltage.

Data measured by the Senquip QUAD is transmitted to the internet via Wi-Fi or 4G LTE4 and can be delivered to the Senquip Portal or to your own server or SCADA system.

Power to the Senquip QUAD can be supplied by a solar panel, or with 10V to 75V DC. If a solar panel is used, an internal LiPo battery will keep the device powered during periods without sunlight.

Senquip telemetry devices are programmable with JavaScript. Users can write their own scripts to manipulate data, create combinational alerts, execute local control, or create customised payloads for sending to 3rd party servers.

Typical markets include mining, utilities, and transport.

1.2 Who can use the Senquip QUAD

The extensive array of in-built sensors, ability to interface to any industrial sensor or system, programmability, versatile power supply and rugged enclosure mean that the Senquip QUAD can be used in a wide variety of applications across many industries. Typical applications are found in:

Mining, monitoring plant and equipment such as lighting plants, pumps, water tankers and more. Measure utilisation, location, fuel level, engine speed, temperature and more to ensure reliability and optimal performance.

Water Services, ensuring that drinking water is of the highest possible quality. Detection of chemical leaks in factories and in water treatment plants. Measure level, flow, temperature, pH, chemical makeup and more.

Fleet, connecting to the vehicle and load to provide more than just telematics. Interface to CAN-bus and other available sensors on a vehicle.

Smart Cities, measuring temperature, sound, asset utilisation, service delivery and other parameters to enhance the daily lives of citizens.

Environment, monitoring air-quality pollution, dust and pollen levels to provide early warnings and improve the health of local populations.

Emergency Services, monitoring of water levels and other environmental factors to provide early warning of flood, fire and other natural disasters.

Industrial Installations, interface to sensors using industry standard protocols like 4-20mA, voltage, MODBUS, and RS232.

Agriculture, soil and water monitoring to ensure fast growing, high quality crops and maximum yield.

Aquaculture, measuring water quality and temperature to ensure optimum growth and health of fish populations.

Health Services, monitoring of fridges to ensure safe storage of temperature sensitive medicines.

1.3 You can rely on the Senquip QUAD

The Senquip QUAD has been designed from the ground up to offer a reliable, capable, flexible and secure remote monitoring platform for industrial users.

Reliability, the Senquip QUAD has been designed for use in challenging environments where reliability is paramount. Where other devices fail, the Senquip QUAD will continue to deliver data, reducing overall cost of ownership and an enhanced user experience.

Capability, the Senquip QUAD has more on-board monitoring, allows connection to more external sensors and has the most versatile power requirements of any telemetry unit in its class.

Flexibility, the user interface is simple to use and yet allows enough flexibility to ensure compatibility with most industrial sensors and systems. User written scripts offer infinite opportunity for customisation.

Security, all data collected is encrypted and is transmitted using secure authenticated connections.

Ownership, at Senquip, we believe that the customer owns their data. We deliver your data to your servers in a private, secure manner. We will not access, use or resell your data - it is yours.