

产品说明书 尺寸:60x90mm 材质:80g书写纸 双面印刷 风琴折

MINISO

PRODUCT MANUAL

Wireless Earbud MS112

PLEASE READ THIS MANUAL CAREFULLY BEFORE USING THE PRODUCT AND KEEP IT IN A SAFE PLACE.

What's in the box

Charging case

2 Earphones

6 Ear cap

Quick Start Guide

USB-C cable

Components

Earphone LED

Earphone speaker

Charging case LED

Touchpad

Charging contacts

USB Type-C port

How to put on the earphones

1

2

Wear headphones correctly

(Incorrect use will make the following functions unavailable)

1- When testing, you must wear the left and right earphones.

2- The test must be conducted in a static environment (Attention: Cannot be used while exercising)

Heart Rate Detection

Heart Rate Detection

Heart Rate Detection, Blood Oxygen Saturation Sensor Area

Testing process

Click "Start Measurement" to enter the test, stay on the screen for 15-30s, and then the test results will be displayed. (Attention: first measurement wait for 30-50S)

Test result

After the test is finished, the heart rate value will be displayed on the screen. Historical records can be viewed.

Testing process

Click "Manual Detection" to enter the test, stay on the screen for 45-60s, and then the test results will be displayed.

Test result

After the test is finished, the blood oxygen level will be displayed on the screen. Historical records can be viewed, and the daily blood oxygen status can be recorded.

Basic operations

L

R

Power on/off

3s/5s

x1

x2s

Phone mode

x1

x2

x3

x3

Music mode

x2

x2

x3

x3

ANC

x1

x4

2s

2s

Reset earphones

x5

x5

How to reset the earphones

If the earphones fail to pair or reconnect to each other, reset them by tapping both earphones five times simultaneously. Note: Resetting the earphones will clear the wireless pairing history.

Key functions

• Play/Pause: Tap either earphone once.

• Volume up: Tap the right earphone twice.

• Volume down: Tap the left earphone twice.

• Play previous track: Tap the left earphone three times.

• Play next track: Tap the right earphone three times.

• Answer/End call: Tap either earphone once.

• Reject call: Press and hold either earphone for two seconds.

• Activate voice assistant: Press and hold the left earphone for two seconds.

Note: When using a single earphone only, press and hold the active earphone for two seconds.

• Switch between Game and Music modes: Music mode is the default mode. Press and hold the right earphone for two seconds to switch between modes. (The louder notification sound indicates Game mode.)

Note: Mode switching is disabled when you're using a single earphone only.

• Switch ANC noise reduction mode: noise is the default mode. Tap either earphone four times to switch between modes. (There are three modes to switch: Off / Noise / Transparent)

Indicator LEDs

Earphone LED	Status
Blinking blue and red	Both earphones: Powered on
Solid blue	Single earphones: Unpaired
Off	Earphone charging
Off	Paired or fully charged

Charging case LED	Status
Solid white	Earphone charging
Blinking red	Case charging
Solid red	Case fully charged

Power on

Taking the earphones out of the charging case will automatically turn them on.

To manually turn on each earphone, press and hold the touchpad for three seconds.

Power off

Placing the earphones in the charging case will automatically turn them off.

To manually turn off each earphone, press and hold the touchpad for five seconds.

Note: If the earphones are not paired with a Wireless device within three minutes after powering on, they will automatically power off. They will also power off after three minutes if the paired Wireless device moves out of the effective connection range and has not reconnected.

Connect with wireless device

On your device, turn on wireless and choose to connect to "MINISO-MS112".

FCC ID: 2BHJR-MS112

FCC Warning:
Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference
(2) this device must accept any interference received, including interference that may cause undesired operation.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.
*RF warning for Portable device:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

US REP

Company Name: MIRAMONT SOLUTIONS LLC
Address: 19 GEORGETOWN, IRVINE, CA 92612
United States
Contact Name: Wenyi Wang
Telephone No: (951) 401-3633
Email: wenyiwang@miramontsolutions.com

The above guarantee does not apply to the following situations

1. The validity period of the three guarantees has exceeded;

2. Altering of the warranty cards and product code do not match the product itself;

3. Failure of damages caused by misuse, abuse or improper transportation, use, maintenance or storage;

4. Failure of damages caused by force majeure (such as earthquake, war, fire, etc.) or accident;

5. Zippers and tower buckles are damaged due to excessive force;

6. Off-line or tear caused by overloading;

7. Any damage caused by sharp objects;

8. Products with signs of burn damage or water logging;

9. Damage caused by unauthorized dismantling and modification;

10. Aging, discoloration, wear, cracking and other losses that occur during normal use of the product.

11. If the product's original logo or label is changed or damaged, this warranty will be invalid.

The completeness and appearance of the product and accompanying materials are not covered by the warranty. You should inspect the product on site when receiving it and raise objections to any discrepancies.

MINISO Product service policy

If you encounter a problem, please contact our customer service to solve it.

Customer Service Email: customercare@yhemi.net

FC RoHS CE

Warranty Policy

Disclaimer:
This manual does not come with any form of warranty, position expression or other implication. The products, specifications and information mentioned in this manual are for reference only, and the content will be updated on the website at any time without prior notice.
Warranty statement:
The following guarantee is made for the products attached to this document: If the product is damaged due to quality defects under normal use within twelve (12) months from the date of your purchase (the "Warranty Period"), and if it can be repaired, it will be repaired free of charge; If the manufacturer confirms that it cannot be repaired, it will be replaced free of charge; the repaired product will continue to be covered by the warranty for the remaining warranty period (a minimum of not less than 30 days). The purchase date shall be based on the sales invoice date; if the purchase date cannot be determined, the warranty period shall be calculated as thirteen (13) months from the product production date.
If you want to apply for warranty, please call the product service hotline first and follow our instructions. When applying for a warranty, you are required to provide a valid sales invoice that is accurate, complete and clearly filled out.

Guidelines for safe and effective use

Note: Please read this information first before using your Bluetooth headset.
If the user makes modifications or modifications to this Bluetooth headset without permission, the user will lose the right to continue to enjoy the services included in the device
① Electromagnetic interference:
Electronic devices: To avoid the effects of electromagnetic interference or configuration incompatibility, please turn off your Bluetooth device in accordance with regulations in places with clear instructions.
Civil Aviation: After boarding the plane, please turn off your Bluetooth headset according to the flight attendant's instructions. It is strictly prohibited to use Bluetooth headsets during flight to avoid interference with the aircraft communication system.
② Safety matters:
Placement: It is recommended that when you are not using the Bluetooth headset, place it in a place where it will not be squeezed. Squeezing may cause damage to the product or personal injury.
Children: Do not let children play with Bluetooth headsets. Some of the small parts are detachable and may be swallowed and cause danger.

Important safety tips

• Except for the operation methods specifically marked in the manual, please do not attempt to disassemble or replace any parts in the product.

• This product contains a built-in rechargeable battery. It is prohibited to hit, squeeze, Puncture, or short-circuit the battery. If there are abnormal phenomena such as excessive temperature, deformation, bulging, or leakage, please stop using it. Do not expose the battery to open flames or sunlight. Do not use the battery after it has been immersed in water or in high-temperature or high-pressure environments such as the sun, heaters, or stoves. After using the earphones, do not place the earphones in a humid, dusty, oily smoke, steam, direct sunlight or other high-temperature and high-pressure environment to avoid damage to the earphones and battery. The battery can be charged and discharged for a limited number of times and will eventually age. If the battery is used abnormally, it can be replaced with a new one. However, do not replace the battery by yourself. If the battery is not replaced properly, there is a risk of explosion. It can only be replaced by an after-sales service provider of the same or equivalent type, battery usage.

• After the product is used and scrapped, do not throw the product into a fire. The waste should be disposed of in strict accordance with the garbage classification. Please use this product reasonably and correctly to avoid causing certain injuries and environmental damage.

• During the use of headphones, due to long distances, obstacles in the middle, or a series of interferences such as other radio signals, Bluetooth signals, WIFI signals, etc., the headphones are used when listening to music, watching videos, playing games, etc., there will be occasional lags, voice out-of-sync or disconnection. If this happens, please reconnect the headphones or stay away from interference.

• When charging, please use a charging device with an output voltage of DC 5V/1A. You must choose a charging device from a regular manufacturer that has obtained CCC safety certification. Do not use a fast-charging charger to avoid excessive battery load, which may cause The battery is damaged. Do not charge continuously for longer than the specified charging time. Do not use it while charging to avoid damage.

Enjoy the company of MINISO

MINISO

Creating sound to live with

Copyright©2025 MINISO Group affiliated companies and its licensors. All rights reserved