



Table of contents	
1.Troubleshooting & FAQs.....	1-3
2.Product overview	4-7
3.Safety precautions and installation instructions	8-14
4.Exercise recommendations and guidelines	14-15
5.Product functions and features	16-20
6.Maintenance and care	21-23
7.App user manual	24-26
8.Service and support.....	27-28

Read all instructions carefully before using this product.
Treadmill this owner's manual for future reference.
If the specification is not consistent with the product, the specific actual product shall prevail.

Troubleshooting & FAQs
1. Treadmill Won't Start
Ensure the power cord is plugged in securely.
Check if the safety key is properly in place.
2. Error Codes (E-05, E-06, E-07, etc.)
E-05: Reduce load, check assembly, try a different outlet.
E-06: Check and secure motor wiring.
E-07: Ensure the safety key is in place and reinstall the support frame, see page 3 for complete information.
3. Unusual Noise (Rattling, Grinding, or Squeaking)
Avoid prolonged use at high speeds.
Allow the motor to cool down and check ventilation.
4. Overheating or Burning Smell
Remove the battery installation tab before use.
Replace the battery if unavailable.
5. Remote Control Not Working
Ensure the battery is securely connected.
Try a different power outlet.
6. Display Screen Not Working
Ensure the cables are securely connected.
Try a different power outlet.
7. Missing or Damaged Parts
Contact our support team with your shipping address for a replacement.

Important:
Read all instructions carefully before using this product, besides this owner's manual for future reference.
The specifications of this product may vary from this photo, subject to change without notice.
Model: B30
FCC ID:
 Made in China

8. Why is there a crease on the treadmill belt?
This is a normal result of the treadmill belt manufacturing process. Each belt has a crease due to the production technique, and it does not affect performance or durability.
9. Treadmill belt loosening
If the treadmill belt is misaligned, you can adjust it using a hex wrench (screwdriver) following the markings on both sides of the treadmill adjustment steps.
If the belt shifts to the left, turn the left adjustment screw clockwise.
If the belt shifts to the right, turn the right adjustment screw clockwise.
Adjust in 1/4-turn increments and test until the belt is centered.

VII. Service and support
Dear Customer,
Thank you for choosing this treadmill for your needs. We are committed to providing you with an exceptional fitness experience and ensuring comprehensive post-purchase support.
Our mission is to deliver the highest quality products and services through innovation and care. As you use your treadmill, we guarantee:
Comprehensive after-sales support:
Our dedicated team is ready to provide timely and professional assistance with any issues you may encounter.
Attentive customer care: We value each customer's needs and strive for your satisfaction and trust through personalized service and communication.
Continual technical support:
Our specialized online support team is equipped with extensive expertise to assist with product warranty and maintenance.
We firmly believe that excellent after-sales service is essential not only for product continuity but also for building long-term customer trust and collaboration. We are committed to maintaining high standards and ensuring you enjoy the best shopping and user experience.
If you have any questions or require assistance regarding our treadmill products, please do not hesitate to contact our dedicated online support team at support@treadmillfitness.com. We are here to serve your understanding and look forward to helping you achieve your health and fitness goals. Thank you for your support and trust in our brand.
Best regards,
The Customer Service Team

Care and maintenance
A. Preparing walk belt of covered or slip
Ensuring walk belt process is follow
1. Unrolling treadmill at low speed with no load.
(Make sure there are no obstructions around)
2. Manual unrolling process is follow:
If the walk belt has shifted to the left, use the hex tool to turn the left roller roller screw clockwise (2 turn) (refer to figure 1).
If the walk belt has shifted to right, use the hex tool to turn the right roller roller screw clockwise (2 turn) (refer to figure 1).
3. Application MUST work 1-2 minutes, repeat manual unrolling process until the walk belt is centered.
Belt slip correcting process is follow
1. Running treadmill at low speed with no load.
(Make sure there are no obstructions around)
2. Using the hex tool, turn both roller roller screws clockwise (2 turn) (refer to figure 1).
3. After correction, please attempt to walking 1-2 minutes under empty speed setting (keep at 0) till the walk belt is properly alignment.
Attention:
1. If a person dry, injury, hurt, don't place any debris around treadmill before maintenance process.
2. User should read the manual.
3. Take care of maintenance process. Do not pinch fingers.