




正面

I . Content

1. Preparations Before Installation

2. [Central Console, Footlight] Main Module Installation

3. [Door Panel] Sub Module Installation

Note:

1. If you encounter any problems during installation, please remove the kit and connect directly to the car battery, and test again.

2. If the ambient light returns to normal operation, it is judged to be caused by installation error.

3. On the contrary, if the ambient light still cannot work normally, it is judged as a product fault and can apply for after-sales service.

4 . All products are not guaranteed by wire cutting.

II . Preparations before installation

①Distinguish the main module and sub module

1. Module with QR Code is the main control,

Function: Signal Projector, synchronously control all sub modules

2. Rest are sub module;

Function: Signal receiver, receive main module instructions, synchronous color change;

3. The main module must be powered on, then sub module will light up

4. Scan the QR code to download the APP, no need to select the pairing code, turn on bluetooth and it will connect automatically (note Android system needs turn on position function)

②Test the product

After receiving the product, connect the battery of the car (do not use external power supply) If no problem, We can starts the installation

③The power connection mode of the Main Module and the Sub Module

【Central Console, Footlight】 Main Module Installation

1. Positive pole: connect ACC 10-15A Fuse (recommend to add 5A from the original fuse current), pay attention to avoid the sensor interface

2. Negative pole: connect the car body cast iron/negative pole

3. Attn:Automatic headlights, Console GPS, DVD Wiring not available

(INPUT: 6-18V OUT PUT: 3V/5V)

【Door Panel】 Sub Module Installation

(INPUT: 6-18V OUT PUT: 3V/5V)

Test the power supply of Door Panel:

ACC Power or Constant Power?

NOTE: normally Germyen car is constant power, Janpanese& Korean car is Acc power.

Constant power:

Test Method 1: When the car flameout, if the door has a automatic window closed function, the door is constant power

Test Method 2: Press the shortcut key to start the car, without igniting the car, if the window lifter can move rise and fall, the door is constant power

ACC Power:

Test Method: If the door funcnaion not available until the car ignited, the door is ACC power.

►The door is ACC power:

Normally the door of Japanese and Korean car is ACC power.

1. MUST Igniting the car before test possitive& negative pole (the door of ACC power supply, do not ignore this step)

2. Find out the positive pole, Votage 6-18V available, choose the thick wire

3. Find out the negative pole (negative Power from door iron or screws is forbidden)

4. Connect sub-control module with the founded power supply, turn the window lifter, and check whether the ambient light works normal when window up and down. (Do not restore the door at the moment, turn the light to white color mode and keep testing for about 5 minutes)

5. If the ambient light goes off or flashes when the window is lifted, it means the power supply is unstable, please find workable positive wires again.

►The door is constant power:

Normally Germyen car is constant power

1. Igniting the car before test possitive& negative pole (the door of constant power supply, also recommend this step)

2. Find out the positive pole, Votage 6 - 18V available, choose the thick wire.

3. Find out the negative pole (negative Power from door iron or screws is forbidden)

4. Connect sub-control module with the founded power supply, turn the window lifter, and check whether the ambient light works normal when window up and down. (Do not restore the door at the moment, turn the light to white color mode and keep testing for about 5 minutes)

5. If the ambient light flashes when the window is lifted, it means the power supply is unstable. If the ambient light goes off, must first determine the positive or negative pole problem and find workable positive wires again.

④ Light strip installation steps

【Central Console】

1.Remove the trim panel of the center console, thread the light strip wires through the holes of the trim panel and connect to the main module.

2.Secure the light strip to the trim board with 3M tape and cut off excess strip.

3.Install the trim panel along with the light strip on the center console.

【Door Panel】

Four sub module are installed on each of the four doors

1. Remove the door panel.

2. Remove the screws of the door trim panel and remove the trim panel.

3. The acrylic light strip runs from the back of the door panel through the hole in the trim panel to the front of the door panel.

4. Fasten the light strip to the decorative board with 3m tape.

5. Install the trim panel along with the light strip to the door panel.

6. Connect the light strip wires on the back of the door panel to the sub module.

7. Install the door panel

Test

1. After the whole vehicle is installed, turn all the lights of the whole vehicle to white color mode and keep testing for about 5-10 minutes.

2. Move the window lift to observe whether the ambient light goes off or flashes.

3. Make sure there is no problem and load the door back.

反面

157克双铜 170*120mm

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

RF Exposure Statement

To maintain compliance with FCC'S RF Exposure guidelines, This equipment should be installed and operated with minimum 20cm between the radiator and your body. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.