

1. Drill a 20mm hole into the top of the water tank lid, ensuring that the lid is open to avoid debris going into the tank.
2. If there is no water tank lid, inspection hatch, or any access to the internal of the tank, a 32mm hole can be drilled and the transducer lowered into the tank through the hole.
3. Pull the transducer cable plug back through the hole, with the stainless-steel transducer in the tank, and secure the grommet around the cable. Place rubber grommet into the hole to seal. The grommet suits both 20mm and 32mm holes
4. The stainless-steel transducer can sit on the bottom of the tank along with any excess cable. If your tank has debris or sludge in the bottom, then the transducer can be raised above this level.
5. Secure the plug into the **Tank Level Pro**, ensuring that the *red dots are aligned* on the plug and socket.
6. Tighten the **metal** securing screw on to the socket.
7. *Open the battery compartment and remove the insulation tabs to connect the battery. Please note that the Pressure Transducer must be plugged in first, before the battery is connected.*
8. Secure the **Tank Level Pro** on the outside of the water tank with inbuilt magnets or the Velcro.
9. Download the App from the iOS or Android Play Store, searching for **tanklvlpro**, or scanning the QR Codes on the App Instruction Sheet
10. App setup is simple, but further instructions can be found by following the App Installation Instructions enclosed.

#### *For Corrugated Tanks (No Drilling Required)*

1. Place stainless steel transducer into tank and thread plug through the corrugation in the tank roof. In some instances, the transducer plug may not fit through the corrugations, and a screw may have to be loosened, this can be re-tightened once the plug is through.
2. Follow Steps 4 to 9 for Sealed Tanks

#### FCC Warning

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

#### Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.