



**AirMaster 4000D B12/17 LTE Outdoor CPE  
User Manual**

# Table of Contents

<b>1.</b>	<b>OVERVIEW</b> .....	<b>4</b>
1.1.	USER INTERFACE SPECIFICATION .....	4
1.2.	LTE INTERFACE SPECIFICATION .....	4
<b>2.</b>	<b>GETTING STARTED</b> .....	<b>4</b>
2.1.	PACKING LIST AND CPE UNIT .....	4
2.2.	INSTALLING THE EQUIPMENT .....	5
	■ <i>Device logic connection</i> .....	5
	■ <i>Installing Outdoor Unit (ODU)</i> .....	6
<b>3.</b>	<b>RF SIGNAL ADJUSTING</b> .....	<b>8</b>
	■ <i>RF Signal Adjusting</i> .....	8
	■ <i>Wireless Link Status</i> .....	8
	■ <i>LED Display</i> .....	9
<b>4.</b>	<b>MANAGING CPE DEVICE</b> .....	<b>9</b>
	■ <i>WEB GUI Login</i> .....	9
	■ <i>Device Status</i> .....	10
<b>5.</b>	<b>DEVICE RESET</b> .....	<b>13</b>
<b>6.</b>	<b>FAQ AND TROUBLESHOOTING</b> .....	<b>13</b>

## **PLEASE READ THESE SAFETY PRECAUTIONS!**

---

### **RF Energy Health Hazard**



The radio equipment described in this guide uses radio frequency transmitters. Although the power level is low, the concentrated energy from a directional antenna may pose a health hazard. Do not allow people to come in close proximity to the front of the antenna while the transmitter is operating.

### **Protection from Lightning**



Before connecting this instrument to the power line, make sure that the voltage of the power source matches the requirements of the instrument. The unit must be standards.

### **Disposal and Recycling Information**



Pursuant to the WEEE EU Directive electronic and electrical waste must not be disposed of with unsorted waste. Please contact your local recycling authority for disposal of this product.

### **Reduction of Hazardous Substances**



This CPE is compliant with the EU Registration, Evaluation, Authorization and Restriction of Chemicals (REACH) Regulation (Regulation No 1907/2006/EC of the European Parliament and of the Council) and the EU Restriction of Hazardous Substances (RoHS) Directive (Directive 2002/95/EC of the European Parliament and of the Council).

### **FCC Notice, USA**

The Airstream CPE units complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### **FCC Radiation Exposure Statement**

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

## 1. Overview

The AM4000D is a high performance 4G LTE outdoor CPE product designed to enable quick LTE fixed data service deployment to the remote customers. It provides high data throughput and networking features to end users who need both bandwidth and quality service in the remote area.



### 1.1. User Interface Specification

Model	Description & User Interface
<b>AM4000D</b>	<ul style="list-style-type: none"> <li>- Panel antenna: 5dBi</li> <li>- 1 RJ45 10/100M ETH Port</li> <li>- PWR, RUN, LAN, SIM, LTE (1-5) LEDs</li> <li>- 48 VDC PoE supply, ODU Power &lt;12 Watts</li> <li>- Dimensions: 203 mm (L) × 203 mm (W) × 161 mm (D)</li> <li>- Weight: &lt; 1.6 Kg</li> </ul>

### 1.2. LTE Interface Specification

Frequency Bands	Band 12/17
Radio Access	3GPP LTE Release9
Operation Mode	FDD, 2RX, 1Tx, DL-MIMO
Output Power	23dBm at antenna port
Throughput	Category 4
SIM Support	SIM card slot (2FF)

## 2. Getting Started

### 2.1. Packing list and CPE Unit

Upon receiving the product, please unpack the product package carefully. Each product is shipped with the following items:

**Table 2-1 Packing List**

Outdoor CPE Products	Quantity
CPE Main Unit	1
PoE Power Adapter	1

Power Cord	1
Mounting brackets	1
PC Ethernet Cable	1

If you find any of the items missed, please contact your local distributor immediately.

### CPE Packing List:

Please unpack the package and check the unit for the following items.




## 2.2. Installing the Equipment

### ■ Device logic connection

For outdoor CPE product, it is preferred that the CPE device be installed in a shaded area to avoid direct sun light exposure which may cause over heat in certain extreme weather condition. The CPE should be properly grounded for proper protection against lightning or power surge.


To power on the device, the outdoor CPE must use a 48V PoE integrated DC power supply adapter. The power adapters can operate in 100-250V AC range and therefore can be used in different country. Once the device is powered up, the user should wait for about 2 minutes before the device becomes operational. For CPE with the RUN LED indicator, the LED will stop fast flashing when the CPE completes the startup procedure.

To connect PC, LAN switch or other type of IP device to the CPE product, the user should use standard CAT5 Ethernet cable and connect to the appropriate LAN port. Once connect the CPE LAN LED indicator should come on.




■ **Installing Outdoor Unit (ODU)**

**Mounting Bracket:**



**Header Connection:**






### 3. RF Signal Adjusting

#### ■ RF Signal Adjusting

After the CPE outdoor unit has installed, the direction of antenna's azimuth and pitch angle needs to adjust for the best signal strength. In near line of sight condition, the CPE will have the best signal when the antenna is directly pointing the base station.

User can adjust the holder to change the direction and angle of the antenna while observing the RF LED on the outdoor unit which indicates the signal strength.



#### ■ Wireless Link Status

The user can further view more detailed wireless link through the WEB GUI interface under the device status link. The following wireless link information can be displayed.

Web GUI interface showing wireless link information. The interface includes tabs for Status and Setup, and buttons for Advanced and Exit. The LTE Information section displays the following data:

LTE Information			
<b>LTE Information</b>			
Manufacturer		UL/DL Bandwidth	- / - KHz
Model Name	AirMaster 4000D	UL/DL Earfcn	- / -
Serial Number	K4000DFD0C4E	UL/DL Throughput	0 / 0 Mbps
IMEI	862344030090392	Media State	DISCONNECTED
RSRP	0 / 0 dBm	Connection Time	0 sec
SINR	0 dB	IPv4/IPv6 Address	- / -

The Networking section displays the following data:

Device MAC Address	6C:AD:EF:FF:DC:4E
IP Address	192.168.0.1
Subnet Mask	255.255.255.0
Local DNS	

#### ■ LED Display

LED Indicator	Function	Description
PWR	Power Indicator	Green Color – Device is powered on
RUN	System Run Indicator	Fast Blinking – Device is rebooting Solid Green – Device is in normal operation
LAN	LAN port status	Solid Green – LAN port is up Blinking Green – LAN data activity in progress
SIM	SIM Card Indicator	Light is on – SIM card state ready.
RF(5LEDs)	RF Signal Strength	5 level signal strengths indication by 5 green LEDs 1 green LED: RSRP<= -118dBm 2 green LEDs: -118dBm <=RSRP< -105dBm 3 green LEDs: -105dBm<=RSRP< -95dBm 4 green LEDs: -95dBm<=RSRP< -85dBm 5 green LEDs: -85dBm<=RSRP

## 4. Managing CPE Device

#### ■ WEB GUI Login

It is a preferred to setup the CPE using a Web browser from a local PC connected to CPE LAN port. The user should ensure that the connected PC acquired IP address via DHCP from the device. After IP connectivity is established between the PC and CPE device, the user may launch a Web browser and specify <http://10.1.1.1> in the address bar. A window will pop up requesting password. Input the user login password and then click the “Log in” button. After successful log on, the default home page of the WEB GUI interface will appear. Note that the default user password is “user123”. The admin password is protected and only available to the network operator.



## ■ Device Status

Once the user is logged in, the following window device status window will be prompted for viewing. It contains both the wireless link information, networking and device information configured for the device. For wireless info gives quite detailed information about the radio connection and user can use it to determine the receiving signal strength and transmit power of the device.

Status Setup
Advanced Exit

LTE Information

**LTE Information**

Manufacturer		UL/DL Bandwidth	- / - KHz
Model Name	AirMaster 4000D	UL/DL Earfcn	- / -
Serial Number	K4000DFFDC4E	UL/DL Throughput	0 / 0 Mbps
IMEI	862344030090392	Media State	DISCONNECTED
RSRP	0 / 0 dBm	Connection Time	0 sec
SINR	0 dB	IPv4/IPv6 Address	- / -

**Networking**

Device MAC Address	6C:AD:EF:FF:DC:4E
IP Address	192.168.0.1
Subnet Mask	255.255.255.0
Local DNS	

## ■ LAN Configuration

Status Network LAN VPN Security Applications UPnP Maintenance
Back user Exit

LAN Setup

**Device IP**

Local IP Address	192	168	0	1
Subnet Mask	255	255	255	0
Local DNS	0	0	0	0

**Network Address Server Settings (DHCP)**

DHCP Server	<input checked="" type="radio"/> Enable <input type="radio"/> Disable
Start IP Address	192.168.0.100
Maximum DHCP Users	100

**DHCP Static Leases Map**

Index	IP Address	Device MAC Address
1	192.168.0.	: : : : : :
2	192.168.0.	: : : : : :
3	192.168.0.	: : : : : :

**Help**

**Local IP Address:**  
This is the address of the device.

---

**Subnet Mask:**  
This is the subnet mask of the device.

---

**DHCP Server:**  
Allows the device to manage your IP addresses.

---

**Start IP Address:**  
The address you would like to start with.

---

**Maximum DHCP Users:**  
You may limit the number of addresses your device hands out.

---

**DHCP Static Leases Map:**  
Configure the static IP lease for LAN device based on MAC address.

The LAN setting allows user to specify the DHCP server setting for the LAN devices including the pool address, IP and MAC binding and whether DHCP server should be enabled.

User is advised to leave the default setting unchanged for quick configuration and smooth device

operation.

The screenshot shows a web interface for configuring applications. At the top, there are navigation tabs: Status, Network, LAN, VPN, Security, Applications (selected), UPnP, and Maintenance. On the right, there are links for Back, user, and Exit. The main content area is divided into three sections: Port Range Forwarding, Port Forwarding, and Port Triggering. Each section has a 'Forwards' table with columns for Application, Start, End, Protocol, IP Address, Port to, and Enable. The tables are currently empty, showing '- None -'. Below each table are 'Add' and 'Remove' buttons, and a 'Save & Apply' / 'Cancel Changes' button. On the right side, there is a 'Help' section with three paragraphs of text explaining each configuration option.

**Port Range Forwarding:**  
Certain applications may require to open specific ports in order for it to function correctly. Examples of these applications include servers and certain online games. When a request for a certain port comes in from the Internet, the device will route the data to the computer you specify. Due to security concerns, you may want to limit port forwarding to only those ports you are using, and uncheck the *Enable* checkbox after you are finished.

**Port Forwarding:**  
Certain applications may require to open specific ports in order for it to function correctly. Examples of these applications include servers and certain online games. When a request for a certain port comes in from the Internet, the device will route the data to the computer you specify. Due to security concerns, you may want to limit port forwarding to only those ports you are using, and uncheck the *Enable* checkbox after you are finished.

**Triggered Port Range:**  
For each application, list the triggered port number range. Check with the Internet application documentation for the port number(s) needed.

**Forwarded Port Range:**  
For each application, list the forwarded port number range. Check with the Internet application documentation for the port number(s) needed.

## ■ Applications Configuration

### Port Range Forwarding:

Certain applications may require to open specific ports in order for it to function correctly. Examples of these applications include servers and certain online games. When a request for a certain port comes in from the Internet, the device will route the data to the computer you specify. Due to security concerns, you may want to limit port forwarding to only those ports you are using, and uncheck the Enable checkbox after you are finished.

### Port Forwarding:

Certain applications may require to open specific ports in order for it to function correctly. Examples of these applications include servers and certain online games. When a request for a certain port comes in from the Internet, the device will route the data to the computer you specify. Due to security

concerns, you may want to limit port forwarding to only those ports you are using, and uncheck the Enable checkbox after you are finished.

## ■ UPnP Setting

### Forwards:

Configure Port forwarding for UPnP. Click the trash sign to delete individual entry.

### UPnP Service:

Allows applications to automatically setup port forwarding.

## ■ Maintenance

### **Firmware Upgrade over HTTP:**

Click on the Browser button to select the firmware file to be uploaded to the device.

Click the Upgrade button to begin the upgrade process. Upgrade must not be interrupted.

### **Old Password:**

The password currently in use.

### **New Password:**

The new password must not exceed 63 characters in length and must not include any spaces. Enter the new password a second time to confirm it.

### **Firmware Update Checking:**

This will disable or enable the firmware update check during user login. The user will be promoted option to perform device firmware upgrade if new version is available.

### **Restore Factory Defaults:**

This will restore the device to original factory setting. User will need to reconfigure the authentication setting in order to get the device operational.

### **System Reboot:**

Click the Reboot button to restart the device.

## **5. Device Reset**

---

In case the user forgets the login password, a reset password can be obtained from the operator by given the device MAC address. The user can enter the reset password in the login window and a system reset will be performed and the unit will be rebooted. The user can then be allowed to use the original default login password to gain access to the unit WEB GUI again.

After factory reset, the device may need to be reconfigured by the user or even operator to gain network access. This is not a recommended operation and special care must be taken to ensure the device will be properly re-configured after factory reset.

## **6. FAQ and Troubleshooting**

---

### **1) My PC cannot connect to the CPE.**

- Re-plug the PC Ethernet cable and check if the PC LAN connection is up or showing activity.
- Check if the system run LED is on. If it is not, check the power cord and make sure it is connected properly. Also verify that the AC power supply is available.
- If the PC LAN shows no activity and system run LED is off but the power cord is connected properly and there is AC supply, then it is likely the adapter is damaged. Please contact distributor to obtain replacement part.

### **2) My PC cannot acquire IP from the CPE.**

- First check if the Network card is up and working properly. Then check the PC NIC

configuration and make sure the DHCP is enabled.

- To release and renew the correct IP address, please unplug the Ethernet cable from PC and wait for about 5 seconds, then connect it again.
- If the problem persists, please contact the operator or distributor for further diagnose.

**3) My CPE networking is not working properly.**

- You may want to check if the LTE connection is up and running properly. You can do this by login the WEB GUI and check the LTE Interface Info page.
- You may want to perform a factory reset and see if the problem is being corrected. You can do this by log into the WEB GUI perform restore the unit to default factory setting.
- If the problem cannot be corrected by factory reset, please contact the operator or distributor for further diagnose.

**4) I forget the login password and like to reset the unit to factory default.**

- Please contact the operator or distributor and give them the IMEI number of the unit. The operator or distributor can issue you a RESET password for you to enter in the WEB login window.
- After the unit is reset to factory default, you can login using the default password.