




5 Disc Audio System with Bluetooth® wireless technology

CD2767BE2

English (EN)



Scan for more user manual details

It's important to read these instructions prior to using your new product for the first time.

SAFETY PRECAUTIONS

FCC Information

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



SEE MARKING ON BOTTOM / BACK OF PRODUCT
CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.



This product contains a low power laser device.

THE LIGHTNING FLASH AND ARROWHEAD WITHIN THE TRIANGLE IS A WARNING SIGN ALERTING YOU OF "DANGEROUS VOLTAGE" INSIDE THE PRODUCT.

THE EXCLAMATION POINT WITHIN THE TRIANGLE IS A WARNING SIGN ALERTING YOU OF IMPORTANT INSTRUCTIONS ACCOMPANYING THE PRODUCT.

Caution:

This product utilizes a laser. Use of controls or adjustments or performance of procedures other than those specified may result in hazardous radiation exposure. Do not open covers and do not repair yourself. Refer servicing to qualified personnel.

WARNING: TO PREVENT FIRE OR ELECTRICAL SHOCK HAZARD, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.

CAUTION: USE OF CONTROLS OR ADJUSTMENTS OR PERFORMANCE OF PROCEDURES OTHER THAN THOSE SPECIFIED MAY RESULT IN HAZARDOUS RADIATION EXPOSURE.

CAUTION: DANGER OF EXPLOSION IF BATTERY IS INCORRECTLY REPLACED. REPLACE ONLY WITH THE SAME OR EQUIVALENT TYPE.

WARNING: MAINS PLUG IS USED AS DISCONNECT DEVICE AND IT SHOULD REMAIN READILY OPERABLE DURING INTENDED USE. IN ORDER TO DISCONNECT THE MAINS PLUG FROM MAINS COMPLETELY, THE MAINS PLUG SHOULD BE DISCONNECTED FROM THE MAINS SOCKET OUTLET COMPLETELY.

SAFETY PRECAUTIONS

For Your Safety

The AC power plug is polarized (one blade is wider than the other) and only fits into AC power outlets one way. If the plug won't go into the outlet completely, turn the plug over and try to insert it the other way. If it still won't fit, contact a qualified electrician to change the outlet, or use a different one. **Do not attempt to bypass this safety feature.**

CAUTION: TO PREVENT ELECTRIC SHOCK, MATCH WIDE BLADE OF PLUG TO WIDE SLOT, FULLY INSERT.

Technical Information

Product: 5 Disc Audio System

Brand: VENTURER

Power Supply: 120V ~ 60Hz

EN

Service Information

This product should be serviced only by those specially trained in appropriate servicing techniques. For instructions on how to obtain service, refer to the warranty included in this Guide.

IMPORTANT SAFETY INSTRUCTIONS

PLEASE READ AND SAVE THIS FOR FUTURE REFERENCE

Some of the following information may not apply to your particular product; however, as with any electronic product, precautions should be observed during handling and use.

- Read these instructions.
- Keep these instructions.
- Heed all warnings.
- Follow all instructions.
- Do not use this apparatus near water.
- Clean only with dry cloth.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong is provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
- Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- Only use attachments / accessories specified by the manufacturer.
- Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
- Unplug this apparatus during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.



Portable Cart
Warning

ADDITIONAL SAFETY INFORMATION

- Apparatus shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases, shall be placed on the apparatus.

IMPORTANT SAFETY INSTRUCTIONS

PLEASE READ AND SAVE THIS FOR FUTURE REFERENCE

- Always leave sufficient space around the product for ventilation. Do not place product in or on a bed, rug, in a bookcase or cabinet that may prevent air flow through vent openings.
- Do not place lighted candles, cigarettes, cigars, etc. on the product.
- Connect power cord only to AC power source as marked on the product.
- Care should be taken so that objects do not fall into the product.
- Do not attempt to disassemble the cabinet. This product does not contain customer serviceable components.
- Main plug is used as disconnect device and it should remain readily operable during intended use. In order to disconnect the apparatus from the mains completely, the mains plug should be disconnected from the mains socket outlet completely.

EN

IF YOUR PRODUCT OPERATES ON BATTERIES, adhere to the following precautions:

- A. Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.
- B. When the batteries become weak, the operating distance of the remote control is greatly reduced and you will need to replace them.
- C. Any battery may leak electrolyte or explode if disposed of in fire or an attempt is made to charge a battery not intended to be recharged.
- D. Discard leaky batteries immediately. Leaking batteries can cause skin burns or other personal injury. When discarding batteries, be sure to dispose of them in the proper manner, according to your state/provincial and local regulations.
- E. Batteries shall not be exposed to excessive heat such as sunshine, fire or the like.

IMPORTANT INFORMATION

Precautions

- This compact disc player uses a laser to read the music on the disc. The laser mechanism corresponds to the cartridge and stylus of a record player. Although this product incorporates a laser pick-up lens, it is completely safe when operated according to directions.
- Discs rotate at high speed inside the player. Do not use damaged, warped, or cracked discs.
- Do not touch the pick-up lens which is located inside the disc compartment. To keep dust from collecting on the pick-up lens, do not leave the compartment door open for an extended period of time. If the lens becomes dirty, clean it with a soft brush, or use an air blower brush designed for camera lenses.

Headset safety



- Make sure you turn down the volume on the unit before you put on headphones. Increase the volume to the desired level only after headphone are in place.
- Do not play your headset at high volume. Hearing experts warn against extended high-volume play.
- If you experience ringing in your ears, reduce volume or discontinue use.
- You should use with extreme caution or temporarily discontinue use in potentially hazardous situations. Even if your headset is an open-air designed to let you to hear outside sounds, do not turn up the volume so high that you are unable to hear what is around you.
- Excessive sound pressure from earphones and headphone can cause hearing loss.

GETTING STARTED

Unpacking the system


You should have the following:

- one main unit (with two speakers)
- one remote control
- user manual

Connections

Back view

1. FM pigtail antenna
2. Speaker jacks




Using FM antenna

Before you use your audio system, you'll want to make sure both the FM antenna are positioned properly. Uncoil the FM antenna at the back of the unit, making sure it is fully extended (you may even want to tape it to the wall behind the unit if possible, the higher the better).

Connecting Speakers


Each speaker has a black/red wire. the red/black wires connect main speaker to main unit. Match the red wires to the red jacks and the black wires to the black jacks on the main unit.



Note: Make sure the insulation is completely removed from the ends of the speaker wires at all connection points.


Installation

To ensure sufficient ventilation, keep the spacing shown below free from other surfaces:



UNIT CONTROLS


Unit-Front View



- 1) **TIMER**
To turn the timer on/off; press and hold to enter the timer setting mode.
- 2) **CLOCK**
To show time and enter clock setting mode.
- 3) **DIMMER**
To adjust display brightness.
- 4) **SLEEP**
To select the time interval in minutes before the unit turns off.
- 5) **►II• PAIR**
To play or pause CD; to pair the bluetooth.
- 6) **AUTO PROG**
To enter auto preset program in FM mode.
- 7,22) **◀◀/▶▶**
To tune radio frequency; to skip CD track; to fast search through the CD.
- 8) **SOURCE**
To select among CD, TUNER, BT and LINE IN sources.
- 9) **ON/STANDBY**
To turn power on or off (STANDBY mode).
- 10) **PROGRAM**
To enter program mode for CD and tuner.
- 11,20) **PRESET ◀/▶**
To select the previous or next preset stations in tuner mode.
- 12) **■**
To stop CD playback in CD mode.
- 13) **PLAY MODE**
To cycle between different play modes in CD mode.
- 14) **SHUFFLE**
To turn on/off random playback in CD mode.
- 15) **LINE IN**
Ø3.5mm jack for external sound input.
- 16) **USB**
For charging only.
- 17) **🎧**
Jack for connecting headphones.
- 18) **BASS**
To turn BASS on or off.
- 19) **EQ**
To select the equalizer presets.
- 20) **VOLUME**
To increase/decrease the volume.
- 21) **DISC SKIP**
To skip to the next CD in the tray in CD mode.
- 22) **▲**
To open or close the disc tray.
- 23) **Remote sensor**
To sense the remote control's signals.

REMOTE CONTROL

Remote Control



1) SOURCE

To select among CD, TUNER, BT and LINE IN sources.

2) ▲

To open or close the disc tray.

3) ⏻

To turn power on or off (STANDBY mode).

4) VOL+

To increase the volume.

5) DISC SKIP

To skip to the next CD in the tray in CD mode.

6) NEXT/▶▶

To tune radio frequency; to skip CD track; to fast search through the CD.

7) VOL-

To decrease the volume.

8) INFO

Press once to display the current time, and press again to exit.

9) FM ST.

To switch between FM ST ON and ST OFF.

10) SHUFFLE

To turn on/off random playback in CD mode.

11) SLEEP

To select the time interval in minutes before the unit turns off.

12) BASS

To turn BASS on or off.

13) 🔇

To mute and restore audio output.

14) INTRO/PAIRING

To turn INTRO mode on or off to play the first 10 seconds of each track in CD mode, to pair the bluetooth.

15) ◀ PRESET ▶

To select previous/next tuner preset station.

16) DIMMER

To adjust display brightness.

17) STOP

To stop playing in CD mode.

18) PREV/◀◀

To tune radio frequency; to skip CD track; to fast search through the CD.

19) ▶▶ II

To play and pause the current CD.


20) PLAY MODE

To cycle between different play modes in CD mode.

REMOTE CONTROL



ATTENTION

- Remove the plastic sheet before operating the remote control.



ATTENTION To install batteries

1. Open the battery door.
2. Insert one CR2025 (3V) size battery.



EN

Using the Remote Control

- Point the remote control at the REMOTE SENSOR located on the unit.
- When there is a strong ambient light source, the performance of the infrared REMOTE SENSOR may be degraded, causing unreliable operation.
- The recommended effective distance for remote operation is about 13 feet (4 meters).
- [The remote control supplied with] This product contains a coin/button cell battery. If the coin/button cell battery is swallowed, it can cause severe internal burns in just 2 hours and can lead to death.
- Keep new and used batteries away from children. If the battery compartment does not close securely stop using the product and keep it away from children.
- If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.

⚠ WARNING

- DO NOT INGEST BATTERY, CHEMICAL BURN HAZARD.

CLOCK AND TIMER

Setting the Clock

1. Press and hold **CLOCK** until the hour flashes on the display.
2. Press **◀** / **▶** to set the hour and then press **CLOCK** to shift to minute digits.
3. Press **◀** / **▶** to set the minute.
4. Press **CLOCK** to save settings.

Note: When system is ON, you can press **CLOCK** to display the current time for about 2 seconds.

Setting the Timer

- For RADIO timer, tune in to a desired station.
 - For CD timer, insert a CD into the unit.
1. Press and hold **TIMER** until ON (timer on time) appears with the hour flashing.
 2. For setting time, press **◀** / **▶** to set the hour and then press **TIMER** to shift to the minute digits.
 3. Press **◀** / **▶** to set the minute.
 4. Press **TIMER** to change to OFF (timer off time) with hour flashing. Repeat steps 2 & 3 for timer off time setting.
 5. Press **TIMER** to select the source. Press **◀** / **▶** to select among TUNER, CD, BT.
 6. Press **TIMER** to set the volume. Adjust the timer volume by **◀** / **▶** to select the desired volume level.
- Note:** To avoid startling you or other individuals in your home, this product will not turn on at a volume higher than 15.
7. Press **TIMER** to save settings.

Activating the Timer

Press and release **TIMER** to turn on/off the timer.

Sleep Mode

You can select the time interval in minutes before the unit turns off automatically.

1. Press **SLEEP** to select among OFF, 120 MIN, 90 MIN, 60 MIN, 45 MIN, 30 MIN, 15 MIN, 10 MIN and 5 MIN.
2. When sleep is activated, press **SLEEP** once to view remaining sleep time. Press **SLEEP** again when the remaining sleep time is displayed to change the sleep time.

Note: Sleep is automatically deactivated when the unit is turned off.

SOUND FEATURES

Bass Boost

Press **BASS** to turn on/off boosting the bass frequency.

Muting Audio

Press **M** on the remote control to cut or restore the sound.

Using Preset Equalizer Curves

Press **EQ** on the unit to select among FLAT, ROCK, POP, JAZZ, CLASSICAL and CUSTOM. The display shows your selection briefly.

Creating a Custom Curve

1. Press **EQ** on the unit to select the CUSTOM mode.
2. While CUSTOM is displayed, press **◀◀** / **▶▶** to cycle among the displayed BASS and TREB range levels.
3. While BASS or TREB is displayed, adjust the volume to set the associated gain between -10 - +10.
4. Press **EQ** to exit.

EN

DISPLAY

Display Brightness

1. Press and hold **DIMMER** for more than 3 seconds.
2. While "DIM" is displayed, press **DIMMER** repeatedly to select the desired level (DIM 1–3).

BLUETOOTH PAIRING

Before Bluetooth pairing, you should turn on the Bluetooth function of your other device (such as, mobile phone with Bluetooth function) and select CD2767BE2.

1. Press **SOURCE** repeatedly on the unit to select BT (Bluetooth) mode.
2. The "BT" blinks at slow speed and it auto searches for the last paired Bluetooth device in memory.
3. Once it enters the pairing status, the "BT" will blink at high speed.
4. Press **PAIR** on the player for 3 seconds to start pairing.
 - If the Bluetooth pairing is successful, the "BT" will not blink.
 - If the Bluetooth pairing is not fixed, the "BT" will blink at slow speed. Please try pairing again.

Note: If your Bluetooth device (such as, mobile phone) needs the password while pairing, please enter 4-digit number: 0000.

Enjoy the music through Bluetooth

- Press **▶||** to begin or pause playback.
- Press **◀◀** / **▶▶** to select a specific track.
- Press and hold **◀◀** / **▶▶** to start moving backward/forward at high speed.

Switch the unit to receive another Bluetooth device

1. Disconnect your Bluetooth device (such as mobile phone) from the player.
2. Press and hold the **PAIR** button on the player until the "BT" blinks at high speed.
3. Turn on the Bluetooth function of your other device (such as, mobile phone with Bluetooth function) and select CD2767BE2 for Bluetooth pairing.

CD PLAYBACK



This unit is compatible with CD-RW/ CD-R discs for playback.

Notes on CD-R/RW Disc:

- Do not affix any type of labels to either side (recordable or labeled side) of a CD-R/RW disc as this may result in the unit malfunctioning.
- To avoid damages to the CD-R/RW disc, do not open the disc compartment door while the disc is being read.
- Do not load an unrecorded CD-R/RW disc into the unit. This may take a longer time to read the disc.
- Playback capability for CD-RW discs may vary due to variations in the quality of the CD-RW disc and the recorder used to create the disc.

EN

Please take care when loading or unloading discs in the disc drawer. Read below for details.

- Remove all discs from the disc drawer before moving or transporting the unit.
- Do not put discs in the trays of the disc drawer when they are still moving.
- Do not push or force the rotation of the disc trays. Always use the **DISC SKIP** button.
- **Do not put discs in any unexposed disc trays.**
- If an error occurs and the disc drawer does not close, empty all disc trays and try again.

Loading Discs

1. Press **SOURCE** repeatedly to select CD mode.
2. Press **OPEN/CLOSE** or to open the drawer.
3. Insert up to five discs with label face up. (Press **DISC SKIP** to rotate the disc carrier.)
4. Press **OPEN/CLOSE** or to close the drawer. Loaded disc position icon lights.

Selecting Discs

Press **DISC SKIP** to skip discs.

Playing Discs

- Press to begin or pause playback, and to stop playback.
- Press / to select a specific track.

Searching through a CD

Press and hold / to search through a CD while it is playing.

Shuffling Play Order

Press **SHUFFLE** to turn on/off the playing of tracks in random order.

Sampling Tracks

Press **INTRO** to play the first 10 seconds of each track on the current disc, all discs in the tray, or turn INTRO mode off.

Play Mode

Press **PLAY MODE** to cycle between RPT 1, RPT 1D, RPT ALL DIC, ONE DIC, and ALL DIC.

CD PROGRAM

You can program the CD player to play up to any 20 tracks on the CDs in the tray.

1. While the CD player is stopped, press **PROGRAM** to enter program mode. The system displays the next available program number: "3- - P 01", prompts you for the first track in the program list.

Note: "3- - P 01" - 3 indicates the No. of the current disc.

2. Press **◀◀** / **▶▶** to select a track.
3. Immediately press **PROGRAM** to assign the selected track to the program number. You are prompted for the next track in the program list.

Playing a Program List

While in PROGRAM mode, press **▶▶**.

Displaying the Program List

1. While the CD player is stopped, press **PROGRAM** to enter PROGRAM mode.
2. Press **PROGRAM** repeatedly to list each track assignment in the program list.

EN

RADIO

Press **SOURCE** to select TUNER.

Tuning to a Station

Press **◀◀** / **▶▶** to select frequencies. Press and hold **◀◀** / **▶▶** to start auto searching for the next available station.

Preset and Tune Modes

The tuner can be in either TUNER or PRESET mode.

Presetting Stations

Manually setting presets

1. Press **◀◀** / **▶▶** to access the desired frequency.
2. Press **PROGRAM** button. The most recently accessed program location will be displayed.
3. If a different program location is preferred, press **◀ PRESET ▶** to select the desired preset number (1-32) .
4. Press **PROGRAM** to store the selected frequency at that preset.

Auto Preset Programming (FM only)

Press and hold **AUTO PROG** for 2 seconds to scan stations in the FM band. The stations will then be stored as preset channels. A maximum of 32 stations can be stored.

Beware of your preset channels being erased accidentally because the scanning and storing process is automatic upon pressing and holding the button. You can stop the automatic scan by pressing **TUNE+/TUNE-** button, but the erased stations cannot be recovered.

Using Presets

Press **◀ PRESET ▶** to access the previous or next preset station. The display first shows the preset program number and after a few seconds, the frequency will be displayed. (e.g. P:01 is preset 1)

Suppressing Stereo Signal

Press **FM ST.** to select between ST ON and ST OFF for stereo FM stations.

LINE IN

Play External Sound through the Speaker System

Press **SOURCE** on the unit repeatedly to select LINE IN mode.

Note:

Suggest using Ø3.5mm LINE IN jack for MP3 player.

TROUBLESHOOTING TIPS

EN

System will not turn on

- Check power cord for a secure connection.
- Unplug the unit for a moment, and then plug into power source again.
- Check the outlet by plugging in another device.

No sound

- Increase the volume setting.
- Check connection to speakers.
- Check that you have selected the appropriate function: CD, TUNER, BT and LINE IN.
- Make sure mute is off.
- Make sure headphones are not plugged in.

Poor radio reception

- Check antenna connection.
- Move antenna.
- Turn off nearby electrical appliances, such as hair dryer, vacuum cleaner, microwave, fluorescent lights.

CD does not play

- Check that CD is in the tray.
- Check that CD label is facing up.
- Check that PAUSE mode is not on.
- Check that CD function is selected.
- Use CD lens cleaner.
- Clean the disc.
- Try another CD.

CD sound skips

- Clean the disc.
- Check disc for warping, scratches, or other damage.
- Check if something is causing the system to vibrate. If so, move the system.
- Make sure the speakers are at least 3 feet away or on a different surface from the main unit.

CD button will not respond, or does not change discs when you press DISC SKIP

- Switch to another function (TUNER, BT and LINE IN) and then back to CD.

Remote control does not work

- Check that the batteries are properly installed.
- Replace weak batteries.
- Check the system is plugged into power source.
- Point the remote directly at the system's front panel.
- Move closer to the system.
- Remove any obstacles between the remote and the system.

ADDITIONAL INFORMATION

Disconnect the audio system from the power source before performing any maintenance.

Cleaning

Clean the exterior of the system using a soft dust cloth.

CD Player

CAUTION! This system operates with a laser. It must be opened by only a qualified technician.

Handling CDs

- Do not touch the signal surfaces. Hold CDs by the edges, or by one edge and the hole. Do not affix labels or adhesive tapes to the label surfaces. Do not scratch or damage the label. CDs rotate at high speeds inside the player. Do not use damaged (cracked or warped) CDs.

Cleaning CDs

- Dirty CDs can cause poor sound quality. Always keep CDs clean by wiping them gently with a soft cloth from the inner edge toward the outer perimeter.
- If a CD becomes dirty, wet a soft cloth in water, wring it out well, wipe the dirt away gently, and then remove any water drops with a dry cloth.
- Do not use record cleaning sprays or antistatic agents on CDs. Also, never clean CDs with benzene, thinner, or other volatile solvents which may cause damage to disc surface.

Technical specifications

Rating Plate: Look for it at the back of the set.

The descriptions and characteristics given in this document are given as a general indication and not as a guarantee. In order to provide the highest quality product possible, we reserve the right to make any improvement or modification without prior notice. The English version serves as the final reference on all products and operational details should any discrepancies arise in other languages.

EN